

[Manuals.plus](#) /

› [travel inspira](#) /

› travel inspira 60L Expandable Vacuum Backpack Instruction Manual

travel inspira TIBP02BKAD

travel inspira 60L Expandable Vacuum Backpack Instruction Manual

Model: TIBP02BKAD

1. PRODUCT OVERVIEW

The travel inspira 60L Expandable Vacuum Backpack is designed for efficient and organized travel, featuring innovative vacuum compression technology, multiple compartments, and enhanced security features. Its versatile design makes it suitable for various travel needs, from short business trips to longer adventures.

Key Features:

- **Vacuum Compression:** Maximize packing space with the integrated vacuum bag and electric pump.
- **Expandable Design:** Gain additional capacity with a 5cm expansion zipper.
- **Multiple Compartments:** Dedicated pockets for clothes, toiletries, a 17-inch laptop, and quick-access items.
- **TSA Anti-Theft Lock:** Secure your belongings with a built-in combination lock.
- **Water-Resistant Material:** Constructed from durable Oxford cloth and TPU fabric to protect contents.
- **Ergonomic Comfort:** Features soft, breathable shoulder straps and back padding for extended wear.
- **Integrated USB Charging Port:** Conveniently charge your devices on the go (power bank not included).



Feel relaxed with
it on your back



Lumbar
support



Ergonomic
shoulder straps



Airflow



Image: The travel inspira 60L Expandable Vacuum Backpack, highlighting its features for business and leisure travel.

2. SETUP AND INITIAL USE

2.1 Unpacking and Inspection

Carefully remove the backpack from its packaging. Inspect all zippers, straps, and compartments for any signs of damage. Ensure all accessories, including the electric vacuum pump and its nozzles, are present.

2.2 Setting the TSA Combination Lock

The laptop compartment is secured with a TSA-approved combination lock. Follow these steps to set your personal code:

1. The default code is usually 0-0-0. Ensure the lock is set to this combination.
2. Locate the small reset button (often recessed) on the side or bottom of the lock. Use a pen or a pointed object to press and hold this button.
3. While holding the reset button, set your desired 3-digit combination by turning the dials.
4. Release the reset button. Your new combination is now set. Test it by scrambling the numbers and then entering your new code to open the lock.

Your browser does not support the video tag.

Video: Demonstrates how to set or reset the TSA combination lock on the travel inspira backpack.

2.3 Charging the Electric Vacuum Pump

The electric vacuum pump is rechargeable. Connect the provided USB cable to the pump and a suitable USB power source (e.g., wall adapter, power bank). The charging indicator light will show its status. A full charge typically takes about 2 hours.

3. OPERATING INSTRUCTIONS

3.1 Using the Vacuum Compression Feature

This feature allows you to significantly reduce the volume of your clothes, maximizing space within the main compartment.

1. **Open the Vacuum Liner Bag:** Unzip the internal compression vacuum liner bag located in the main compartment.
2. **Load Clothes:** Place your clothes neatly inside the vacuum liner bag. Ensure the clothes are dry.
3. **Zip Up Airtight:** Carefully zip up the airtight zipper of the vacuum liner bag, leaving a small gap near the exhaust valve.
4. **Open Exhaust Valve:** Locate the exhaust valve on the vacuum liner bag and open its cap. Flatten the surface of the bag to remove as much air as possible manually.
5. **Use the Electric Pump:** Attach the electric vacuum pump to the exhaust valve. Press the ON/OFF button on the pump to start suction. The pump will automatically draw out the air, compressing your clothes.
6. **Seal the Valve:** Once the desired compression is achieved, quickly remove the pump and close the exhaust valve cap securely to maintain the vacuum seal.



Travel Business Backpack With Vacuum Pump

Ideal for *traveling, business trips*



Image: Step-by-step visual guide on how to use the electric air pump for vacuum compression within the backpack.

Your browser does not support the video tag.

Video: Demonstrates the vacuum compression feature of the backpack, showing how to pack clothes and use the pump to reduce volume.

Your browser does not support the video tag.

Video: A user demonstrating how the backpack shrinks in size after utilizing the vacuum compression feature, allowing for more compact packing.

3.2 Expanding the Backpack

For times when you need extra space, the backpack features an expandable section. Simply unzip the expansion zipper located around the perimeter of the main compartment to increase its depth by approximately 5cm.

Vacuum airtight bag Specially designed to accommodate up to 20 pieces of lightweight clothing.



Image: Visual representation of the backpack's expandable space, showing its volume increase from 25L to 36L (expanded) and up to 55L (vacuum compressed).

3.3 Utilizing Multiple Compartments

- **Main Compartment:** Houses the vacuum compression bag for clothing.
- **Wet/Dry Pocket:** A dedicated waterproof pocket to separate toiletries or wet items from dry belongings.
- **Laptop Compartment:** Padded and shock-resistant, designed to hold up to a 17-inch laptop.
- **Back Hidden Pockets:** Secure pockets on the back panel for quick access to valuables like phones or passports.
- **Expandable Side Pockets:** Ideal for water bottles or other items needing easy access.

Rationally divided can hold a 17.3 inch laptop, 10.7 inch iPad.



Image: Detailed layout of the backpack's versatile pockets, including front, dry-wet separation, compression bag, laptop, and anti-theft compartments.

3.4 Using the Integrated USB Charging Port

To use the external USB charging port, connect your own power bank (not included) to the internal USB cable located within one of the backpack's compartments. Then, connect your device to the external USB port for convenient charging.

4. MAINTENANCE

4.1 Cleaning Instructions

- For general cleaning, wipe the exterior of the backpack with a damp cloth and mild soap.
- Do not machine wash, tumble dry, or iron the backpack.
- For the internal vacuum bag, wipe with a damp cloth and ensure it is completely dry before storing.
- The water-resistant Oxford cloth and TPU fabric are designed to repel water, but the backpack is not submersible.

Your browser does not support the video tag.

Video: Demonstrates the water-resistant properties of the backpack's fabric, showing how water beads and rolls off the surface.

4.2 Storage

Store the backpack in a cool, dry place away from direct sunlight when not in use. Ensure the vacuum bag is clean and dry to prevent mold or mildew.

5. TROUBLESHOOTING

- **Vacuum Pump Not Working:** Ensure the pump is fully charged. Check the ON/OFF button and ensure it's pressed correctly.
- **Vacuum Bag Not Compressing / Losing Air:** Verify that the airtight zipper of the vacuum liner bag is completely sealed. Ensure the exhaust valve cap is tightly closed after removing the pump. Check for any punctures or damage to the vacuum bag.
- **TSA Lock Issues:** If you forget your combination, refer to the lock's specific instructions (usually involves pressing the reset button while setting a new code). Ensure the shackle is fully inserted before attempting to lock.
- **USB Charging Not Working:** Confirm your power bank is charged and correctly connected to the internal USB cable. Ensure your device is properly connected to the external USB port.

6. SPECIFICATIONS

Feature	Detail
Brand	travel inspira
Model Name	Expandable Backpack
Model Number	TIBP02BKAD
Color	Black
Storage Volume	40 Liters (expandable to 60L with vacuum compression)
Item Dimensions (D x W x H)	12.6"D x 5.91"W x 19.3"H

Feature	Detail
Item Weight	1.8 Kilograms (approx. 3.96 lbs)
Material Type	Oxford cloth (Outer), TPU fabric (Vacuum Bag Liner)
Water Resistance Level	Water Repellent
Compatible Device Size Maximum	17 Inches (Laptop)
Number of Compartments	3 main compartments
Other Special Features	Adjustable, Anti-Theft, Breathable, Expandable, Electric Vacuum Pump, USB Charging Port, Reflective Strips, Whistle

Packing power, bank, wallet
book, pen, Water cup etc.



Image: Visual specifications of the backpack, including dimensions (12.5x7.9x19 inches), capacity (25L-55L), and weight (4.4 Pounds).

7. WARRANTY AND SUPPORT

For warranty information, product support, or any inquiries, please contact travel inspira customer service through their official website or the retailer where the product was purchased. Please retain your proof of purchase for warranty claims. Visit the [travel inspira Store](#) for more products and information.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question