



Manuals.plus /

› MYICY /

› MYICY 27 INCH Evaporative Air Cooler, Windowless Swamp Cooler Portable Air Conditioners w/Normal/Natural/Sleep/Cooling Mode,3 Speeds,Double Tanks& Remote & Smart Timer, Bladeless Air Cooler for Room

MYICY L36Y

MYICY 27 INCH Evaporative Air Cooler User Manual

Model: L36Y

1. INTRODUCTION

This manual provides essential information for the safe and efficient operation of your MYICY 27 INCH Evaporative Air Cooler. Please read this manual thoroughly before use and retain it for future reference. The MYICY Evaporative Air Cooler is a versatile 3-in-1 device, combining the functions of an evaporative air cooler, humidifier, and cooling fan. It is designed to provide a comfortable environment by lowering air temperature and adding humidity, particularly effective in hot and dry climates.

2. SAFETY INSTRUCTIONS

To ensure safe operation and prevent damage, please observe the following precautions:

- Always keep the unit balanced and upright. Do not tilt the cooler when it is operating or contains water.
- Do not exceed the maximum water level indicator when filling the water tank.
- Do not operate the cooling function without water in the tank.
- Ensure the power supply matches the unit's requirements (120V).
- Keep the unit away from direct sunlight and heat sources.
- Do not block the air inlet or outlet.
- Unplug the unit before cleaning or maintenance.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

3. PACKAGE CONTENTS

Verify that all items are present in the package:

- 1 x Freestanding Air Conditioner
- 1 x Remote Control

- 4 x Ice Crystal Boxes
- 1 x User Manual

4. PRODUCT FEATURES

- **3-in-1 Functionality:** Combines evaporative air cooling, humidification, and fan operation.
- **Adjustable Settings:** 3 wind speed settings (Low, Medium, High) and 4 modes (Normal, Natural, Sleep, Cooling).
- **Large Water Tank:** 1-gallon (approximately 3.78 liters) removable water tank for 6-12 hours of continuous operation. Features a visible water level indicator.
- **Enhanced Cooling:** Includes 4 high-density ice packs for faster cooling.
- **Convenient Control:** User-friendly touch panel and a remote control with up to 16 ft range.
- **Energy Efficient:** Consumes only 80W of power.
- **Wide Air Distribution:** Features a 360° auto-rotating outlet for even air distribution, effectively cooling up to 250 square feet.
- **Low Noise Operation:** Designed with an inner turbine wind guide for stronger wind with lower noise.

5. SETUP

1. **Unpacking:** Carefully remove the air cooler and all accessories from the packaging.
2. **Placement:** Place the unit on a flat, stable, and level surface. Ensure there is adequate space around the unit for proper airflow.
3. **Filling the Water Tank:**
 - Locate the water tank. The unit features a top tank and a removable bottom tank for easy filling and cleaning.
 - Fill the water tank with clean, cool water. Do not exceed the "MAX" water level indicator.
 - For enhanced cooling, place the provided ice crystal boxes in a freezer until frozen, then add them to the water tank.
4. **Power Connection:** Plug the power cable (6 ft length) into a standard 120V electrical outlet.

6. OPERATING INSTRUCTIONS

The air cooler can be operated using the touch panel on the unit or the included remote control.

6.1. Power On/Off

- Press the **Power** button on the control panel or remote to turn the unit on or off.

6.2. Mode Selection

Press the **Mode** button to cycle through the available modes:

- **Normal Mode:** Provides a consistent airflow.
- **Natural Mode:** Simulates a natural breeze with varying fan speeds.
- **Sleep Mode:** Operates at a lower speed and noise level for quiet operation during sleep.
- **Cooling Mode:** Activates the evaporative cooling function, utilizing water and ice packs to lower air temperature. Ensure water is present in the tank for this mode.

6.3. Wind Speed Adjustment

Press the **Speed** button to select desired wind speed:

- Low (20 ft/s)
- Medium (23 ft/s)
- High (26 ft/s)

6.4. Timer Function

Press the **Timer** button to set an automatic shut-off time, up to 7 hours.

6.5. Oscillation

Press the **Oscillation** button to activate or deactivate the 360° auto-rotating outlet for wider air distribution.

6.6. Remote Control

The remote control uses one CR2025 battery (included). Point the remote control towards the unit's receiver to operate. Ensure there are no obstructions between the remote and the unit.

7. MAINTENANCE

Regular maintenance ensures optimal performance and longevity of your air cooler.

7.1. Cleaning the Water Tank

- Unplug the unit from the power outlet before cleaning.
- The bottom water tank is removable for easy cleaning. Carefully detach it.
- Clean the tank with mild soap and water. Rinse thoroughly to remove any residue.
- Ensure the tank is completely dry before reattaching it to the unit.
- Regularly clean the water tank to prevent mold or mildew buildup.

7.2. Cleaning the Exterior

- Wipe the exterior of the unit with a soft, damp cloth.
- Do not use abrasive cleaners or solvents, as they may damage the surface.

7.3. Storage

- If storing the unit for an extended period, ensure the water tank is empty and dry.
- Store the unit in a cool, dry place, away from direct sunlight.

8. TROUBLESHOOTING

If you encounter issues with your MYICY Evaporative Air Cooler, refer to the following common solutions:

Problem	Possible Cause	Solution
Unit does not power on.	No power supply; power cord not properly connected.	Ensure the power cord is securely plugged into a working 120V outlet. Check the power button.
No cooling effect.	Water tank is empty; cooling mode not selected; ice packs not frozen.	Fill the water tank to the appropriate level. Select "Cooling Mode". Ensure ice packs are frozen and placed in the tank.
Water leakage.	Water tank overfilled; unit tilted.	Do not exceed the maximum water level. Ensure the unit is on a flat, level surface and not tilted.
Weak airflow.	Air inlet/outlet blocked; fan speed set too low.	Clear any obstructions from the air inlet/outlet. Increase the fan speed setting.
Remote control not working.	Battery depleted; obstruction between remote and unit.	Replace the CR2025 battery. Ensure a clear line of sight to the unit's receiver.

9. SPECIFICATIONS

Feature	Detail
Model	L36Y (Also referred to as JH-200Y in some descriptions)
Power Supply	120V
Rated Power	80 W
Operating Noise Level	35 dB (approx.)
Functions/Modes	Normal, Natural, Sleep, Cooling
Wind Speed Settings	Low, Mid, High (20 ft/s, 23 ft/s, 26 ft/s)
Timer	Up to 7 Hours
Remote Control Battery Type	(1) x CR2025 (Included)
Power Cable Length	6 ft
Water Tank Capacity	1 Gallon (approx. 3.78 liters)
Coverage Area	Up to 250 sq ft
Product Dimensions	26.01 x 24.99 x 67.01 cm (approx. 10.24 x 9.84 x 26.38 inches)
Item Weight	4.99 kg (approx. 11 lbs)
Color	Pure White

Note: Specifications are subject to change without notice.

10. WARRANTY AND SUPPORT

For warranty information or technical support, please contact MYICY customer service. Details for contacting support are typically found on the product packaging or the official MYICY website.

Please have your model number (L36Y) and purchase date available when contacting support.

11. IMPORTANT NOTES ON MEDIA

No product images or official product videos were provided in the input data for this manual. Therefore, no visual media could be embedded.