

iPazzPort B0F193D3K5

iPazzPort 2.4G+Bluetooth Wireless Mini Keyboard Instruction Manual

Model: B0F193D3K5

1. PRODUCT OVERVIEW

The iPazzPort 2.4G+Bluetooth Wireless Mini Keyboard is a compact and portable input device designed for versatile use across various platforms. It features both 2.4G wireless and Bluetooth connectivity, a built-in touchpad, and essential multimedia keys, making it suitable for controlling smart TVs, PCs, Android/iOS devices, and more.



Figure 1.1: iPazzPort Mini Keyboard Layout

Key Features:

- **Dual-Mode Connectivity:** Seamlessly switch between 2.4G wireless (via USB dongle) and Bluetooth modes for broad compatibility.
- **Integrated Touchpad:** Features a sensitive touchpad with left and right mouse buttons for precise navigation.
- **Compact and Portable:** Designed to be lightweight and palm-sized for easy carrying and comfortable handheld use.
- **Energy-Efficient:** Operates on 2 AAA batteries (not included), eliminating the need for frequent charging.
- **Plug and Play:** Requires no driver installation for most compatible devices, ensuring quick setup.

PRODUCT OVERVIEW



- More information in the manual.

Figure 1.2: Product Dimensions and Key Components


The keyboard measures approximately 6 x 3 x 0.6 inches and weighs 2.47 ounces, making it highly portable.

2. SETUP AND INSTALLATION

2.1 Battery Installation

The keyboard requires two AAA batteries (not included) for operation. The 2.4G USB dongle is also stored within the battery compartment.

1. Locate the battery compartment cover on the back of the keyboard.
2. Slide open the cover.
3. Insert two AAA batteries, ensuring correct polarity (+/-).
4. Retrieve the 2.4G USB dongle from its storage slot if you intend to use 2.4G wireless mode.
5. Close the battery compartment cover securely.



Put in two AAA batteries (Not included)

2.4G USB dongle is placed in the battery compartment

Figure 2.1: Battery and USB Receiver Compartment

2.2 Connecting the Keyboard

The keyboard supports two connection modes: 2.4G RF Wireless and Bluetooth.

2.2.1 2.4G RF Wireless Mode (Recommended for Firestick TV, PC, HTPC)

1. Ensure batteries are installed.
2. Take out the 2.4G USB dongle from the battery compartment.
3. Plug the USB dongle into an available USB port on your device (e.g., Smart TV, PC, Android TV Box, Firestick).
4. The keyboard should automatically connect. The indicator light will blink orange once to confirm 2.4G mode.
5. The keyboard is now ready for use.

2.2.2 Bluetooth Mode (Recommended for Laptops, Android/iOS Devices)

1. Ensure batteries are installed.
2. Turn on the keyboard.
3. On the keyboard, short press **Fn + ~** to switch to Bluetooth mode. The indicator light will blink blue once.
4. Long press **Fn + RF** (the key with the Bluetooth symbol) to enter pairing mode. The indicator light will blink continuously.
5. On your device (e.g., smartphone, tablet, laptop), go to Bluetooth settings and search for new devices.
6. Select "iPazzPort Keyboard" or a similar name from the list of available devices.
7. Once paired, the indicator light on the keyboard will stop blinking, indicating a successful connection.

Dual Modes Connection



Short press: Fn+ ~ to switch modes (indicator blinks once)

Orange light: 2.4Ghz mode

Blue light: Bluetooth mode

Long press: Fn+RF to find device (indicator blinks continuously)

Indicator stops blinking, connection is successful

Figure 2.2: Dual Mode Connection Instructions

3. OPERATING INSTRUCTIONS

3.1 Basic Keyboard and Touchpad Use

- **Typing:** Use the QWERTY keyboard layout for text input.
- **Touchpad:** Use your finger to move the cursor on the screen. The touchpad supports multi-touch gestures for scrolling (two fingers).
- **Left/Right Mouse Buttons:** Dedicated left and right mouse buttons are located next to the touchpad for clicking and context menus.
- **Page Up/Page Down:** Buttons for page navigation are located on the side of the keyboard.



Figure 3.1: Two-Handed Operation

3.2 Function Keys (Fn)

The **Fn** key allows access to secondary functions printed in blue on certain keys.

- **Fn + Esc:** Adjust touchpad direction. This is useful if the touchpad orientation feels inverted.
- **Fn + F1-F12:** Access multimedia controls (play/pause, volume, etc.) and other system functions.
- **Fn + RF:** Used for Bluetooth pairing (as described in Setup).
- **Fn + ~:** Used to switch between 2.4G and Bluetooth modes.

Adjust touchpad direction via **Fn+**




Figure 3.2: Adjusting Touchpad Direction


3.3 Wireless Range

The keyboard offers a strong wireless range of up to 10 meters (33 feet), providing flexibility for use in various environments, such as living rooms or conference rooms.

COMPATIBLE DEVICES



HTPC/IPTV
VR Glasses



PC/Macintosh Laptops



Tablets



Smart TV



Figure 3.3: Wireless Operating Range

4. MAINTENANCE

4.1 Battery Replacement

When the keyboard's performance degrades or it stops responding, it may be time to replace the AAA batteries. Follow the steps in Section 2.1 to replace them.

4.2 Cleaning

- Use a soft, dry cloth to wipe the surface of the keyboard.
- For stubborn dirt, slightly dampen the cloth with water or a mild, non-abrasive cleaner.
- Avoid using excessive liquid or harsh chemicals, as they can damage the electronics.
- Do not immerse the keyboard in water.

4.3 Storage

When not in use for extended periods, store the keyboard in a cool, dry place. It is recommended to remove the batteries if storing for several months to prevent leakage.

5. TROUBLESHOOTING

Problem	Possible Cause	Solution
Keyboard not responding (2.4G mode)	• Low or dead batteries. • USB dongle not properly inserted. • Dongle not recognized by device. • Keyboard is in Bluetooth mode.	• Replace AAA batteries. • Ensure USB dongle is fully inserted into a working USB port. • Try a different USB port or restart the device. • Press Fn + ~ to switch to 2.4G mode (orange light).
Keyboard not connecting (Bluetooth mode)	• Keyboard not in pairing mode. • Bluetooth on device is off. • Device already paired with too many Bluetooth devices. • Keyboard is in 2.4G mode.	• Press Fn + ~ to switch to Bluetooth mode (blue light), then long press Fn + RF to enter pairing mode. • Enable Bluetooth on your device. • Remove old Bluetooth connections from your device. • Ensure the keyboard is in Bluetooth mode.
Touchpad not working or erratic	• Touchpad direction inverted. • Surface obstruction. • Low battery.	• Press Fn + Esc to adjust touchpad direction. • Ensure the touchpad surface is clean and free of debris. • Replace batteries.
Keys not responding	• Low battery. • Connection issue.	• Replace batteries. • Reconnect the keyboard (refer to Section 2.2).

6. SPECIFICATIONS

Feature	Detail
Model Number	B0F193D3K5
Brand	iPazzPort
Connectivity Technology	2.4G RF, Bluetooth
Keyboard Layout	QWERTY
Compatible Devices	Television, Google/Android TV Box, 4K Media Stick, Notebook, Firestick, Fire TV, PC, Mac OS, iOS, Raspberry Pi, HTPC
Product Dimensions	6 x 3 x 0.6 inches (152.4 x 76.2 x 15.24 mm)

Feature	Detail
Item Weight	2.47 ounces (70 grams)
Power Source	2 x AAA Batteries (not included)
Color	Black
Special Features	Lightweight, Mini, Integrated Trackpad, Wireless
Hand Orientation	Ambidextrous

7. WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the documentation included with your purchase or contact iPazzPort customer service directly. Contact details can typically be found on the manufacturer's official website or on the product packaging.

For further assistance, you may visit the [iPazzPort Store on Amazon](#).

© 2025 iPazzPort. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0F193D3K5>

More documents and user manuals: <https://manuals.plus/>