

## WMARK NG-XT1

# WMARK NG-XT1 Professional Cordless Detail Hair Trimmer User Manual

Model: NG-XT1 | Brand: WMARK

## 1. INTRODUCTION

Thank you for choosing the WMARK NG-XT1 Professional Cordless Detail Hair Trimmer. This manual provides essential information for the safe and effective use, maintenance, and care of your new trimmer. Please read it thoroughly before first use and keep it for future reference.

## 2. SAFETY INFORMATION

### Important Safety Instructions:

- Always unplug the trimmer before cleaning or replacing parts.
- Keep the trimmer away from water sources.
- Do not use the trimmer on infants or children.
- Always use the trimmer with caution and keep it out of reach of children when not in use.
- Always follow the manufacturer's instructions for cleaning and maintenance.

*Statements regarding dietary supplements have not been evaluated by the FDA and are not intended to diagnose, treat, cure, or prevent any disease or health condition.*

## 3. PRODUCT FEATURES

The WMARK NG-XT1 trimmer is engineered for precision and durability, offering a professional grooming experience.

- **10,000 RPM High-Power Maglev Motor:** Equipped with a professional maglev vector motor that delivers steady 10,000 RPM power, easily tackling thick hair, tight fades, and dense beards without bogging down. It operates quietly, suitable for both professional and home use.
- **Durable DLC-Coated Blade:** Features a diamond-like carbon (DLC) coated blade that is 3x more wear-

resistant than standard stainless steel. The precision-ground edge stays sharp, preventing pulling or snagging. Its rounded tip design ensures safe detailing around ears, hairlines, and beards, minimizing nicks or irritation on sensitive skin.

- **2000mAh Battery with Dual Charging:** Powered by a 2000mAh high-capacity lithium battery, providing up to 150 minutes of continuous use after 3-4 hours of charging. It includes a charging base for convenient placement charging and a USB Type-C cable for on-the-go charging via adapters or power banks.
- **3-Size Clipper Guards:** Comes with 3 clipper guards (1.5mm/3mm/6mm) to accommodate various styling needs, from short fades and layered cuts to full-head trims.
- **Ergonomic Design:** The sleek, lightweight ergonomic body fits comfortably in hand, reducing fatigue during prolonged use.



Image: The WMARK NG-Xt1 trimmer highlighting its 10,000 RPM Maglev motor.

# DLC

## **DLC T-STYLE BLADES**

0.1MM GAPPED STAINLESS STEEL



Image: Close-up of the WMARK NG-XT1 trimmer's durable DLC T-Style blades.



Image: Illustration of the WMARK NG-XT1 trimmer's 2000mAh battery and 150 minutes usage time.

## 4. COMPONENTS AND WHAT'S IN THE BOX

---

Your WMARK NG-XT1 Professional Cordless Detail Hair Trimmer package includes the following items:

- WMARK NG-XT1 Trimmer
- Charging Base
- Cleaning Brush
- Extra Cover (Modular Lids)
- Precision Screwdriver
- USB Type-C Charging Cable
- 3 Clipper Guards (1.5mm, 3mm, 6mm)



Image: All components included with the WMARK NG-XT1 trimmer.

Video: An unboxing demonstration of the WMARK Professional NG-XT1 trimmer, showing all included accessories and their placement within the packaging.

## 5. SETUP

### 5.1 Initial Charging

Before first use, fully charge your WMARK NG-XT1 trimmer. Connect the USB Type-C cable to the trimmer or the charging base, and then to a suitable power adapter. A full charge typically takes 3-4 hours and provides up to 150 minutes of continuous operation.

### 5.2 Attaching Clipper Guards

Select the desired clipper guard (1.5mm, 3mm, or 6mm) for your preferred cutting length. Align the guard with the trimmer blade and snap it securely into place. Ensure it is firmly attached before use.

### 5.3 Blade Adjustment (Zero-Gap)

The trimmer blades can be adjusted for a closer cut (zero-gap). Use the provided precision screwdriver to carefully loosen the two screws on the blade. Adjust the moving blade to align with the fixed blade, ensuring it does not extend beyond the fixed blade to prevent skin irritation. Tighten the screws firmly after adjustment.

## 6. OPERATING INSTRUCTIONS

---

The WMARK NG-XT1 trimmer is designed for versatile use on all hair types, suitable for both professional and personal grooming.

### 6.1 General Operation

1. Ensure the trimmer is fully charged.
2. Attach the desired clipper guard, if needed.
3. Press the power button to turn on the trimmer.
4. Hold the trimmer at a comfortable angle and move it against the direction of hair growth for an even cut.
5. Press the power button again to turn off the trimmer after use.

### 6.2 Specific Uses

- **Beard & Sideburn Shaping:** Use without a guard or with a short guard (1.5mm) for precise lines and shaping.
- **Hairline & Sideburns Detailing:** The sharp DLC blade is ideal for creating crisp hairlines and detailed sideburns.
- **Professional Fade Haircuts:** Utilize the various clipper guards (1.5mm, 3mm, 6mm) to achieve smooth transitions and fades.

Video: A demonstration of the WMARK NG-XT1 trimmer's powerful 7,500-10,000 RPM Maglev Vector Motor in action, showcasing its cutting performance.

## 7. MAINTENANCE

---

### 7.1 Cleaning the Trimmer

1. Ensure the trimmer is turned off and unplugged from any charging source.
2. Remove the clipper guard.
3. Use the provided cleaning brush to remove loose hairs from the blades and the trimmer body.
4. For thorough cleaning, you may carefully detach the blade assembly (refer to blade adjustment section for screw locations) and clean underneath. Reattach securely.
5. Do not rinse the trimmer under water unless explicitly stated as waterproof (this model is not specified as waterproof, so avoid direct water contact).

### 7.2 Blade Care

The DLC-coated blades are designed for long-lasting sharpness. To maintain optimal performance, regularly brush away hair debris. Oiling the blades periodically (with a few drops of clipper oil, not included) can help reduce friction and extend blade life.

## 8. TROUBLESHOOTING

---

If you encounter any issues with your WMARK NG-XT1 trimmer, please refer to the following common solutions:

- **Trimmer not turning on:** Ensure the battery is fully charged. Connect to the charger and check the charging indicator.
- **Poor cutting performance:** Clean the blades thoroughly to remove any trapped hair. Ensure the blades are properly aligned and oiled. The battery might be low; try recharging.
- **Unusual noise:** Check for any obstructions in the blade area. Ensure the blade assembly is securely attached.

If the problem persists, please contact WMARK customer support for assistance.

## 9. SPECIFICATIONS

| Feature                | Detail                                                         |
|------------------------|----------------------------------------------------------------|
| Model Number           | NG-XT1                                                         |
| Product Dimensions     | 5.91 x 1.69 x 1.38 inches                                      |
| Weight                 | 2.64 Pounds                                                    |
| Motor                  | 10,000 RPM Maglev Vector Motor                                 |
| Blade Material         | DLC (Diamond-Like Carbon)                                      |
| Battery                | 2000mAh Lithium Battery (1 AA battery required, included)      |
| Charging Time          | 3-4 hours                                                      |
| Usage Time             | Up to 150 minutes                                              |
| Charging Type          | USB Type-C, Charging Base                                      |
| Minimum Cutting Length | 1.5 Millimeters                                                |
| Maximum Cutting Length | 6 Millimeters                                                  |
| Included Components    | Charge Base, Cleaning Brush, Extra Cover, Screwdriver, Trimmer |
| Operation Mode         | Cordless                                                       |
| Hair Type              | All                                                            |
| Manufacturer           | SHENZHEN NEW GAIN IMPORT & EXPORT LTD.                         |

## 10. WARRANTY AND SUPPORT

For warranty information, product support, or to purchase replacement parts, please contact WMARK customer service through their official website or the retailer where you purchased the product. Please have your model number (NG-XT1) and proof of purchase ready when contacting support.

**Manufacturer:** SHENZHEN NEW GAIN IMPORT & EXPORT LTD.

### ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question

and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question