



Manuals.plus /

› Sands Original Products /

› Instruction Manual for Split In Half Titanic Bath Boat and Pool Toy

Sands Original Products B0F1BC4888

Instruction Manual: Split In Half Titanic Bath Boat and Pool Toy

Brand: Sands Original Products

1. INTRODUCTION

Thank you for purchasing the Sands Original Products Split In Half Titanic Bath Boat and Pool Toy. This unique and historically accurate model offers an interactive way to explore the story of the Titanic. Designed for both display and water play, it features a splitting mechanism to recreate the ship's dramatic moment.

This manual provides essential information for the proper use, care, and maintenance of your new toy.

2. WHAT'S INCLUDED

- One (1) Split In Half Titanic Boat (8 inches long)
- One (1) Iceberg accessory



Image: The Titanic boat, separated into two halves, with the accompanying iceberg accessory.

3. SETUP AND ASSEMBLY

The Split In Half Titanic Toy comes pre-assembled and ready for use. No additional assembly is required.

Connecting the Boat Halves:

1. Align the front and rear sections of the Titanic boat.
2. Gently push the two sections together until they securely connect. The connection is designed to be firm yet allow for easy separation during play.



Image: Demonstrates the Titanic boat in both its connected and separated states, alongside the iceberg.

4. OPERATING INSTRUCTIONS

Water Play:

This toy is suitable for use in baths, pools, and other shallow water environments. Ensure the water is clean and free of debris.

- Place the assembled Titanic boat gently onto the water surface. It is designed to float.
- To simulate the historical event, gently apply pressure to the middle section of the boat to cause it to split into two halves.
- The iceberg accessory can be placed in the water alongside the boat for imaginative play.

Display Use:

The detailed design makes this toy an excellent display piece for collectors and history enthusiasts. It can be displayed assembled or with the halves separated to depict different stages of the Titanic's story.



Image: The Titanic boat and iceberg displayed on a vintage map, highlighting its historical accuracy and detail.

5. CARE AND MAINTENANCE

- **Cleaning:** After water play, rinse the toy with clean, fresh water. Use a soft cloth to gently wipe away any residue.
- **Drying:** Allow the toy to air dry completely before storing to prevent mold or mildew. Ensure all crevices are dry.
- **Storage:** Store the toy in a cool, dry place away from direct sunlight and extreme temperatures.
- **Avoid Harsh Chemicals:** Do not use abrasive cleaners or harsh chemicals, as these may damage the toy's finish or materials.

6. SAFETY INFORMATION

- **Recommended Age:** This toy is recommended for ages 4 to 13 years. Adult supervision is advised for younger children during water play.
- **Choking Hazard:** The toy contains small parts (iceberg accessory). Keep away from children under 3 years of age.
- **Water Safety:** Never leave children unattended in or near water.

- **Durability:** While durable, avoid excessive force or dropping the toy from heights to prevent damage.

7. PRODUCT SPECIFICATIONS

Model:	B0F1BC4888
Brand:	Sands Original Products
Dimensions:	Approximately 8 inches (20.3 cm) long
Material:	3D Printed Material
Recommended Age:	4 - 13 years
Country of Origin:	USA
First Available:	March 12, 2025



Image: The Titanic boat shown next to a ruler, indicating its approximate 8-inch length.

8. WARRANTY AND SUPPORT

This product is covered by a 30-day return policy. For any issues or support inquiries, please contact Sands Original Products directly through the retailer's platform where the purchase was made.

As a small, Michigan-based business, Sands Original Products values your satisfaction and support.