

**287456812**

## Mini Fridge User Manual

Model: 287456812 | Brand: Generic

### PRODUCT OVERVIEW

This manual provides essential information for the safe and efficient operation of your new 4.4 Cu. Ft. One-Door Mini Fridge. Please read all instructions carefully before use and retain this manual for future reference.



Image: Front view of the Mini Fridge. This compact refrigerator features a sleek black stainless steel finish and a single door design, ideal for various settings.



#### All Fridge Design

All-refrigerator (freezer less) design provides desired usable capacity for food and beverages.

#### E-star

Energy star-certified.

#### 2L bottle storage and can dispenser

Allows you to put daily milk and drinks bottles.

#### Interior light

Allows to search your items in dark surroundings.

#### Removable glass shelves

Easy to put large and irregular items by removing shelves.

#### Adjustable Legs

Allows for leveling, the freezer is easy to fit any spot of your room.

#### Reversible door hinge for right or left opening

Allows the door to be installed at right or left side.

Image: Diagram illustrating key features of the Mini Fridge, including its all-fridge design, E-star energy rating, 2L bottle storage, interior light, removable glass shelves, adjustable legs, and reversible door hinge.

## SAFETY INFORMATION

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, and injury to persons.

- Ensure the appliance is properly grounded.
- Do not operate if the power cord is damaged.
- Keep ventilation openings clear of obstruction.
- Unplug before cleaning or maintenance.
- This appliance is equipped with a child lock feature. Ensure it is engaged when necessary to prevent accidental opening by children.

## SETUP AND INSTALLATION

### Unpacking

Carefully remove all packaging materials, including foam and adhesive tape. Dispose of packaging responsibly. Check for any shipping damage.

### Placement

Place the refrigerator on a flat, stable surface away from direct sunlight and heat sources (e.g., stove, heater). Allow at least 4 inches of space around the back and sides for proper air circulation.



Image: Product dimensions of the Mini Fridge, showing a height of 33.9 inches, width of 19.7 inches, and depth of 21.3 inches.

These measurements are crucial for proper placement.

## Leveling the Appliance

Your mini fridge is equipped with adjustable leveling legs. To level the appliance, turn the leveling legs clockwise to raise the unit or counter-clockwise to lower it. Ensure the fridge is stable and level to prevent vibrations and ensure proper door sealing.



Image: Close-up view of the adjustable leveling leg located at the bottom of the Mini Fridge, used for stabilizing the unit on uneven surfaces.

## Reversible Door Hinge

The door hinge on your mini fridge is reversible, allowing the door to open from either the right or left side. Refer to the detailed instructions in the separate installation guide for reversing the door swing, if desired.



Image: Diagram illustrating the reversible door hinge mechanism, showing how the door can be re-installed to open from either the right or left side.

## Power Connection

Before plugging in, allow the refrigerator to stand upright for at least 2 hours. Connect the appliance to a dedicated 120 Volt, 60 Hz, AC only, 15 Amp fused electrical outlet. Do not use an extension cord.

## OPERATING INSTRUCTIONS

### Temperature Control

The temperature inside the refrigerator is controlled by a thermostat knob, typically located inside the unit. Turn the knob to adjust the cooling level. Higher numbers usually indicate colder temperatures. Allow several hours for the temperature to stabilize after adjustment.

### Storage Organization

Your mini fridge features adjustable glass shelves, a crisper drawer, and door bins for efficient storage. The removable shelves allow for flexible organization of items of various sizes.



Image: Interior view of the Mini Fridge, showcasing its spacious design with various food and beverage items stored on adjustable shelves and in door bins.




Image: Interior view of the Mini Fridge, highlighting the removable glass shelves for flexible storage and the dedicated 2L bottle storage and can dispenser in the door.

## Child Lock

This appliance is equipped with a child lock feature to prevent unauthorized access. Consult the specific mechanism on your unit for engagement and disengagement instructions.

## MAINTENANCE

## Cleaning

Always unplug the refrigerator before cleaning. Clean the interior with a solution of mild detergent and warm water. Wipe dry thoroughly. The exterior can be cleaned with a soft cloth and mild soap. Do not use abrasive cleaners or harsh chemicals.

## Manual Defrost

This refrigerator features a manual defrost system. When frost accumulates to about 1/4 inch thickness, unplug the unit and remove all contents. Allow the frost to melt naturally. Do not use sharp objects to remove ice. Once defrosted, clean and dry the interior before plugging back in.

## TROUBLESHOOTING

Before contacting customer support, review the following common issues and their potential solutions:

- **Refrigerator does not operate:** Check if the power cord is securely plugged in. Verify the circuit breaker or fuse. Ensure the temperature control is not set to "OFF".
- **Temperature is not cold enough:** Check the temperature setting. Ensure the door is closed properly. Avoid frequent door openings. Do not overload the refrigerator.
- **Unusual noises:** Slight vibrations are normal. Ensure the unit is level. Check if anything is touching the back or sides of the refrigerator.
- **Door does not close completely:** Check if shelves or items are obstructing the door. Ensure the gasket is clean and not damaged. Level the unit.

## SPECIFICATIONS

Feature	Detail
Brand Name	Generic
Model Info	4515417415
Item Model Number	287456812
Capacity	4.4 Cubic Feet
Product Dimensions (D x W x H)	21.3" x 19.7" x 34"
Item Weight	49 Pounds
Annual Energy Consumption	250 Kilowatt Hours
Installation Type	Freestanding
Special Features	Child Lock, Reversible Door Hinges, Removable Shelves
Color	Black
Voltage	120 Volts
Defrost System	Manual
Number of Doors	1

## WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the documentation included with your purchase or contact the manufacturer directly. General customer support information may be available through the retailer where the product was purchased.

For assistance, you may contact customer support via the details provided on the product packaging or the manufacturer's official website.