Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

INSIGNIA NS-43F501NA26

INSIGNIA 43" Class F50 Series 4K UHD Smart Fire TV User Manual

Model: NS-43F501NA26

Introduction

This manual provides essential information for setting up, operating, maintaining, and troubleshooting your INSIGNIA 43" Class F50 Series LED 4K UHD Smart Fire TV. Please read this manual thoroughly before using your television to ensure proper and safe operation.



Front view of the INSIGNIA 43" Class F50 Series 4K UHD Smart Fire TV. This television features a sleek design with thin bezels and a central INSIGNIA logo.

The INSIGNIA F50 Series Smart Fire TV offers a 4K Ultra HD (2160p) resolution, providing four times the detail of Full

HD. It supports High Dynamic Range (HDR10) for enhanced contrast and a wider range of colors. Integrated with Fire TV, it provides access to various streaming services and smart home capabilities, all controllable with the included Voice Remote with Alexa.

1. Setup

1.1 What's in the Box

- INSIGNIA 43" Class F50 Series 4K UHD Smart Fire TV
- Power Cable
- TV Stand (2 pieces)
- Screws for Stand
- Voice Remote with Alexa
- AAA Batteries (2)
- User Manual (this document)
- Warranty Card

1.2 Stand Installation

1. Carefully place the TV face-down on a soft, clean surface to prevent screen damage.
2. Align the stand pieces with the screw holes on the bottom of the TV.
3. Secure each stand piece with the provided screws.
4. Place the TV upright on a stable, level surface.

1.3 Wall Mounting

Your TV is compatible with VESA pattern 200 x 300 mm wall mounts. Ensure you use a wall mount designed for your TV's size and weight. Follow the instructions provided with your wall mount kit.




Rear view of the television, highlighting the VESA mounting points for wall installation.


1.4 Connecting Devices

The TV offers versatile connections for various home theater components.

- **HDMI Ports (3):** Connect Blu-ray players, game consoles, cable boxes, and other HDMI-enabled devices. HDMI 1 supports eARC/ARC for enhanced audio return channel functionality.
- **USB Port (1):** Connect USB storage devices for media playback.
- **Composite (AV) Jacks:** For older devices using RCA connections (Video, L-Audio, R-Audio).
- **Digital Optical Output:** For connecting to soundbars or audio receivers.
- **Headphone Jack:** For private listening.
- **Coaxial (ANT/CABLE) Jack:** For connecting an antenna or cable TV.
- **Ethernet Port:** For a wired internet connection. Wi-Fi is also supported.



Rear input ports: Ethernet LAN, Composite video, RCA analog audio, and Cable/Antenna input.



Side input ports: 3.5 mm audio jack, Digital optical output, USB 2.0, HDMI 1 (eARC/ARC), HDMI 2, and HDMI 3.

2. Operating Your TV

2.1 Power On/Off


Press the **Power** button on the remote control or on the TV itself to turn the TV on or off.

2.2 Voice Remote with Alexa

The included Voice Remote allows you to control your TV and access Alexa features. Insert the two AAA batteries into the remote. Press and hold the **Voice** button (microphone icon) to activate Alexa and issue commands such as finding content, launching apps, controlling smart home devices, or checking information.

2.3 Fire TV Interface and Streaming


Your TV features the Fire TV operating system, providing a centralized hub for entertainment. You can access a wide range of streaming applications and services.



Separate subscriptions may be required. Feature and content availability may vary.

The Fire TV interface, showing a selection of streaming applications like Prime Video, Netflix, Disney+, Hulu, and HBO Max.

- **Access Apps:** Navigate through the Fire TV home screen to find and launch apps like Prime Video, Netflix, Disney+, Hulu, and HBO Max. Subscriptions may be required for some services.
- **Free Content:** Stream free movies and TV episodes from ad-supported apps such as Fire TV Channels, Pluto TV, and Tubi.
- **User Profiles:** Create up to six personalized user profiles to customize viewing experiences for different household members.




Subscriptions may be required. Feature and content availability may vary.

The user profile selection screen, allowing personalized viewing experiences for different users.

2.4 Smart Home Integration

Pair your Fire TV with compatible smart home devices to control them directly from your television. You can view live camera feeds, adjust lighting, and manage thermostats using voice commands via Alexa.



The TV displaying a live feed from a smart home camera, demonstrating smart home integration.

2.5 Parental Controls

Manage content access for children by blocking programs based on ratings or restricting entire channels. A PIN can be set to secure access to restricted content.

3. Maintenance

3.1 Cleaning Your TV

- Always unplug the TV before cleaning.
- Use a soft, dry cloth to wipe the screen and cabinet.
- For stubborn marks, lightly dampen the cloth with water or a mild, non-abrasive screen cleaner. Do not spray cleaner directly onto the screen.
- Avoid using harsh chemicals, abrasive pads, or solvents.

3.2 Software Updates

Your Fire TV will periodically receive software updates to improve performance and add new features. Ensure your TV is connected to the internet to receive these updates automatically. You can also manually check for updates in the TV's settings menu.

4. Troubleshooting

Problem	Possible Solution
No power	Ensure the power cable is securely plugged into the TV and a working electrical outlet. Try a different outlet.
No picture, but sound is present	Check the input source. Ensure all video cables are securely connected. Try a different HDMI port.
No sound, but picture is present	Check volume levels and ensure the TV is not muted. Verify audio cable connections. If using external audio, check its settings.

Problem	Possible Solution
Remote control not working	Replace batteries. Ensure there are no obstructions between the remote and the TV. Repair the remote if necessary (refer to TV settings).
Cannot connect to Wi-Fi	Check your router and modem. Ensure the Wi-Fi password is correct. Try restarting the TV and your network equipment.
Picture quality issues (e.g., blurry, distorted)	Check cable connections. Ensure the input source is providing a high-quality signal. Adjust picture settings in the TV menu.

5. Specifications

Feature	Detail
Model Name	NS-43F501NA26
Screen Size	43 inches
Display Technology	4K Ultra LED
Resolution	4K (2160p)
Refresh Rate	60 Hz
HDR Format Supported	HDR10
Operating System	FireTV
Voice Control	Alexa Voice Remote
Connectivity Technology	Bluetooth, Wi-Fi
HDMI Ports	3 (1 with eARC/ARC)
USB Ports	1
Audio Output	Digital Optical, 3.5mm Headphone Jack
Speaker Description	DTS Virtual-X Sound
Mounting Type	Wall Mount (VESA 200 x 300 mm)
Product Dimensions (D x W x H)	8.27"D x 36.68"W x 23.6"H
Annual Energy Consumption	165 kWh

6. Warranty Information

Your INSIGNIA 43" Class F50 Series 4K UHD Smart Fire TV comes with a**1-Year Limited Warranty**. This warranty covers defects in materials and workmanship under normal use. For specific terms and conditions, please refer to the Warranty Card included with your product or visit the official INSIGNIA support website.

7. Support

For technical assistance, troubleshooting, or customer service, please refer to the following resources:

- **Online Support:** Visit the official INSIGNIA website for FAQs, product registration, and digital copies of manuals.
- **Customer Service:** Contact INSIGNIA customer support via phone or email (details typically found on the warranty card or official website).
- **Software Updates:** Ensure your TV is connected to the internet to receive the latest software updates for optimal performance.

© 2025 INSIGNIA. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0F1BWZTJN

More documents and user manuals: **https://manuals.plus/**