

[Manuals.plus](#) /

› [Cool-Living](#) /

› 10,000 BTU Window Mount Room Air Conditioner with Installation Kit and Remote Control, Cools Rooms Up To 450 Square Feet, White

## Cool-Living CL-10CMD1

# 10,000 BTU Window Mount Room Air Conditioner User Manual

Brand: Cool-Living | Model: CL-10CMD1

## INTRODUCTION

---

This manual provides comprehensive instructions for the safe and efficient operation, installation, and maintenance of your Cool-Living 10,000 BTU Window Mount Room Air Conditioner, model CL-10CMD1. Please read this manual thoroughly before using the appliance and retain it for future reference.



Image: The Cool-Living 10,000 BTU Window Mount Room Air Conditioner, a white rectangular unit with front grilles and a digital display.

## IMPORTANT SAFETY INFORMATION

---

To reduce the risk of fire, electrical shock, or injury when using your air conditioner, follow these basic precautions:

- Read all instructions before using the appliance.
- Connect to a properly rated, grounded 115V outlet only. Do not use extension cords or adapter plugs.
- Do not operate the air conditioner if the power cord or plug is damaged.
- Ensure the unit is securely installed in a window according to the installation instructions to prevent falling.
- Do not block air openings. Maintain proper clearance around the unit for optimal performance and safety.
- Unplug the unit before cleaning or performing any maintenance.
- Keep flammable materials away from the air conditioner.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

## WHAT'S IN THE BOX

---

Verify that all components are present before beginning installation:

- Air Conditioner Unit
- Remote Control
- Window Installation Kit (includes side panels, top rail, sash lock, foam seals, screws)

## SPECIFICATIONS

---

| Feature                        | Detail                                                                     |
|--------------------------------|----------------------------------------------------------------------------|
| Brand Name                     | Cool-Living                                                                |
| Model Number                   | CL-10CMD1                                                                  |
| Cooling Power                  | 10,000 BTU                                                                 |
| Coverage Area                  | Up to 450 Square Feet                                                      |
| Installation Type              | Window Mounted                                                             |
| Voltage                        | 115 Volts                                                                  |
| Wattage                        | 870 watts                                                                  |
| Noise Level                    | 59 dB                                                                      |
| Annual Energy Consumption      | 700 Kilowatt Hours                                                         |
| Product Dimensions (D x W x H) | 19"D x 18"W x 14.5"H                                                       |
| Special Features               | Energy Saver, Auto Restart, Remote Control, 3 Fan Speeds, 3 Cooling Speeds |
| Color                          | White                                                                      |



# 10,000 BTU Window Mount Room Air Conditioner

Cools rooms up to 450 square feet




Image: The air conditioner unit with its key dimensions (height, width, depth) and weight indicated.

## SETUP AND INSTALLATION

This air conditioner is designed for installation in standard double-hung windows. Follow these general steps. Refer to the detailed installation guide included with your unit for specific instructions and diagrams.

1. **Prepare the Window:** Ensure the window opening is clean and clear of obstructions. The window must be able to support the weight of the unit.
2. **Attach Side Panels:** Slide the accordion side panels into the side channels of the air conditioner unit.
3. **Place Unit in Window:** Carefully lift the unit and place it into the window opening, ensuring the bottom rail rests securely on the window sill. Tilt the unit slightly outwards to allow for proper drainage.
4. **Extend Side Panels:** Extend the side panels to fill the window opening completely and secure them with screws as indicated in the detailed guide.
5. **Secure the Unit:** Install the sash lock and foam seals to secure the window and prevent air leakage.
6. **Plug In:** Plug the unit into a standard, grounded 115V electrical outlet.



## Our Mission

At Cool-Living, we recognize the challenge many consumers face due to the high costs of effective cooling systems. We aim to make comfort accessible to everyone by offering affordable cooling solutions and ensuring that cooling products are not a luxury but a standard amenity for all households.



Image: The air conditioner unit properly installed in a window, showing the extended side panels.

### OPERATING INSTRUCTIONS

---

Your Cool-Living air conditioner features user-friendly digital controls and a remote control for convenient operation.

#### Control Panel and Remote Control



Image: Close-up of the air conditioner's front panel, highlighting the digital display and control buttons.

- **Power Button:** Turns the unit ON or OFF.
- **Mode Button:** Cycles through cooling modes (Cool, Fan, Dry, Auto).
- **Fan Speed Button:** Adjusts fan speed (Low, Medium, High).
- **Temperature Up/Down Buttons:** Sets the desired temperature.
- **Sleep Mode:** Activates a quiet, energy-saving mode for nighttime comfort.
- **Timer:** Sets a timer for automatic ON/OFF operation.
- **Auto-Restart Function:** The unit will automatically restart with previous settings after a power outage.

### Airflow Direction

The multi-directional vent allows you to direct the airflow where it is needed most. Adjust the horizontal and vertical louvers manually to optimize cooling coverage in your room.



### High Cooling Capacity

10,000 BTU power efficiently cools rooms up to 450 square feet. Ideal for bedrooms, offices, dorms, and small apartments.



### Multi-Directional Airflow

Easily direct cool air where you need it most with adjustable vents for optimal room coverage.

Image: The air conditioner operating in a bedroom, illustrating the multi-directional airflow effectively cooling the space.

## MAINTENANCE

Regular maintenance ensures optimal performance and extends the lifespan of your air conditioner.

### Air Filter Cleaning

The air filter should be cleaned every two weeks or more frequently depending on usage and air quality. The unit features convenient side-out filter access.

1. **Unplug the unit** from the power outlet.
2. Locate the filter access on the side of the unit and gently pull out the filter.
3. Wash the filter with warm, soapy water. Rinse thoroughly.
4. Allow the filter to dry completely before reinserting it into the unit.

### General Cleaning

- Wipe the exterior of the unit with a soft, damp cloth. Do not use harsh cleaners or abrasives.
- Ensure the drainage area at the back of the unit is clear of debris.
- For long-term storage, clean the unit thoroughly, allow it to dry, and cover it to protect from dust.

## TROUBLESHOOTING

Before contacting customer support, refer to the following common issues and solutions:

| Problem                                  | Possible Cause                                                           | Solution                                                                                                                 |
|------------------------------------------|--------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------|
| Unit does not turn on.                   | No power; tripped circuit breaker; unit unplugged.                       | Check power cord connection; reset circuit breaker; ensure outlet is functional.                                         |
| Air conditioner not cooling effectively. | Dirty air filter; blocked air vents; room too large; windows/doors open. | Clean air filter; clear obstructions from vents; ensure room size is within specifications; close all windows and doors. |
| Unit is noisy.                           | Loose installation; foreign object in fan; normal operating sounds.      | Check installation for secure fit; inspect for debris (unplug first); some sounds (fan, refrigerant) are normal.         |
| Water dripping outside.                  | Normal condensation drainage.                                            | This is normal. Ensure the unit is slightly tilted outwards for proper drainage.                                         |

## WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the warranty card included with your product or contact Cool-Living customer service. Keep your purchase receipt as proof of purchase.

**Customer Service:** Please visit the Cool-Living official website or refer to your product packaging for contact details.

### ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

**Submit question**