

Flieks W50443250-MZJ

Flieks Loft Twin Bed Frame with Staircase Instruction Manual

Model: W50443250-MZJ

1. INTRODUCTION

This manual provides instructions for the assembly, use, and maintenance of your Flieks Loft Twin Bed Frame with Staircase, Model W50443250-MZJ. Please read all instructions carefully before assembly and use to ensure safe operation and longevity of the product.



Image 1: Fully assembled Flieks Loft Twin Bed Frame with integrated staircase.

2. SAFETY INFORMATION

WARNING: Failure to follow these warnings and instructions could result in serious injury or death.

- Always follow the manufacturer's recommended assembly instructions.
- Ensure all connections are tight and secure before use. Periodically check and tighten hardware.
- Do not allow children under 6 years of age on the upper bunk.
- Use only a mattress that is 6 inches or less in thickness.
- The maximum weight capacity for this bed is 200 lbs. Do not exceed this limit.
- Always use the staircase for entry and exit from the loft bed. Do not jump on or off the bed.
- Keep children away from the assembly area during construction.
- This product is designed for indoor use only.

3. PACKAGE CONTENTS

Before beginning assembly, ensure all parts listed in the included hardware and parts manual are present. If any parts are missing or damaged, do not proceed with assembly. Contact customer support for assistance.

Typical components include:

- Bed frame components (side rails, end panels, support beams)
- Staircase components (steps, side panels, handrails)
- Wood slats for mattress support
- Hardware pack (screws, bolts, nuts, washers, Allen wrench)
- Assembly instruction manual (separate document)

4. SETUP AND ASSEMBLY INSTRUCTIONS

Assembly of the Flieks Loft Twin Bed Frame requires two adults and approximately 1-2 hours. Please follow the detailed step-by-step instructions provided in the separate assembly manual included with your product. Ensure you have adequate space for assembly and keep all small parts out of reach of children.

Key Assembly Steps:

1. Unpack all components and verify against the parts list.
2. Assemble the main bed frame structure, attaching side rails to end panels.
3. Construct the staircase unit, ensuring all steps and handrails are securely fastened.
4. Attach the assembled staircase to the main bed frame.
5. Install the wood slats onto the bed frame for mattress support.
6. Tighten all hardware connections. Do not overtighten.




Image 2: Side view illustrating the integrated staircase for safe access.

5. OPERATING AND USAGE INSTRUCTIONS

Once assembled, the loft bed is ready for use. Place a twin-sized mattress (6 inches or less in thickness) directly onto the wooden slats. The space underneath the bed can be utilized for storage, play, or study areas.

- **Mattress Placement:** Ensure the mattress fits snugly within the bed frame to prevent gaps.
- **Under-Bed Space:** The area beneath the bed measures approximately 28"H x 76"L x 42"W, offering versatile use.
- **Staircase Storage:** The integrated staircase features storage compartments for organizing items.



Image 3: View highlighting the spacious under-bed area and staircase storage.

6. MAINTENANCE

Regular maintenance will help prolong the life and safety of your loft bed.

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners.
- **Hardware Check:** Periodically (e.g., every 3-6 months) inspect all bolts, screws, and connections. Tighten any loose hardware to ensure stability.
- **Structural Integrity:** Check for any signs of wear, damage, or cracks in the wood. If damage is found, discontinue use and contact customer support.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Bed feels wobbly or unstable.	Loose hardware connections.	Inspect and tighten all bolts and screws. Ensure the bed is on a level surface.
Squeaking noises.	Loose connections or friction between wood parts.	Tighten all hardware. Apply a small amount of paraffin wax or silicone spray to contact points if squeaking persists.
Missing parts during assembly.	Packaging error.	Do not proceed with assembly. Contact Flieks customer support immediately for replacement parts.

8. SPECIFICATIONS

The following are the technical specifications for the Flieks Loft Twin Bed Frame, Model W50443250-MZJ:

- **Product Type:** Loft Bed with Staircase

- **Size:** Twin
- **Material:** Pine Wood + Plywood + PB
- **Overall Product Dimensions:** 93.5"L x 42.1"W x 44.5"H
- **Overall Product Weight:** 103.6 lbs
- **Bed Weight Capacity:** 200 lbs
- **Number of Slats:** 14 pcs
- **Suggested Mattress Thickness:** 6 inches or less
- **Under-Bed Clearance:** Approximately 28 inches
- **Assembly Required:** Yes
- **Country of Origin:** Vietnam

UNIT INCH




Image 4: Dimensional drawing showing key measurements of the loft bed.

9. WARRANTY AND SUPPORT

For warranty information, missing parts, or technical support, please refer to the warranty card included with your purchase or contact Flieks customer service directly. Keep your purchase receipt for warranty claims.

Contact Information: Please visit the official Flieks website or refer to your purchase documentation for the most current customer support contact details.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question