

- Manuals.plus /
- › HONOR /
- › HONOR 400 Lite 5G Smartphone User Manual

HONOR 400 Lite

HONOR 400 Lite 5G Smartphone User Manual

Model: HONOR 400 Lite (ABR-NX1)

1. INTRODUCTION

This manual provides essential information and instructions for using your new HONOR 400 Lite 5G Smartphone. Please read this manual thoroughly before using the device to ensure proper operation and to maximize its features. Keep this manual for future reference.



Image: Front and back view of the HONOR 400 Lite 5G Smartphone, highlighting its sleek design and camera module.

2. INITIAL SETUP

2.1. What's in the Box

- HONOR 400 Lite 5G Smartphone (Battery Included)
- USB Type-C Cable
- SIM Ejection Tool
- Quick Start Guide

Note: The power adapter is not included and is sold separately.

Contenuto della confezione



Telefono (batteria inclusa) X1



Punta per rimuovere la scheda X1



Cavo USB di tipo C X1



Guida rapida X1



***AVVISO:** La confezione non include l'alimentatore. L'alimentatore è venduto separatamente.

Image: Illustration of the items included in the HONOR 400 Lite 5G Smartphone package: the phone, USB cable, SIM ejector tool, and quick guide.

2.2. Inserting the SIM Card

1. Locate the SIM card tray on the side of your device.
2. Insert the SIM ejection tool into the small hole next to the tray and press firmly until the tray pops out.
3. Place your Nano-SIM card(s) into the tray with the gold contacts facing down. Ensure the card is correctly oriented. The device supports Dual SIM functionality.
4. Carefully push the tray back into the slot until it is flush with the device.

2.3. Powering On and Initial Setup

1. Press and hold the Power button until the HONOR logo appears.
2. Follow the on-screen prompts to select your language, connect to a Wi-Fi network, and set up your Google account.
3. You can transfer data from an old device during this process.

2.4. Charging the Device

The HONOR 400 Lite 5G is equipped with a 5230 mAh battery. Use the provided USB Type-C cable to connect your device to a compatible power adapter (sold separately). The device supports fast charging, with a full charge typically taking approximately 75 minutes. Optimized power management ensures reliable performance throughout the day.



Image: The HONOR 400 Lite 5G Smartphone connected to a charger, displaying a 100% charge status on its screen.

3. OPERATING YOUR SMARTPHONE

3.1. Display and Navigation

The device features a 6.7-inch AMOLED Eye-Care Display with a 120 Hz refresh rate and 3500 nits peak brightness, ensuring vivid visuals and reduced eye strain. Navigation is primarily via the touchscreen. You can unlock the device instantly with a single tap on the screen using the in-display fingerprint sensor.



Image: The HONOR 400 Lite 5G Smartphone display showcasing a vibrant, detailed image, emphasizing its visual quality.

3.2. Camera Features

Capture high-quality photos with the 108 MP main camera, featuring a 1/1.67-inch sensor and 3X lossless zoom. The device also includes a wide & depth camera and a 16 MP front camera with a selfie light.

- **AI Camera Button:** Launch the camera in 1 second. Press to focus, swipe to zoom, and use Google Lens for real-time translation, shopping, or exploration.
- **Street-Style Portraits:** Utilize AI-based multifocal portraits (1X/2X/3X) for professional-quality shots.
- **AI Eraser:** Remove unwanted distractions from your photos.
- **AI Outpainting:** Optimize photo composition by intelligently extending the background.
- **Underwater Photography:** The device's IP64 rating allows for photography in wet conditions.



Image: Detailed view of the HONOR 400 Lite 5G Smartphone's camera module and examples of photos taken with its 108MP main camera, wide & depth camera, and 16MP front camera, highlighting AI enhancements.



Image: Visual guide demonstrating how to use the camera button: tap to open, hold to record video, and pinch to zoom.

3.3. AI Features and Connectivity

The HONOR 400 Lite 5G integrates advanced AI capabilities and comprehensive connectivity options:

- **Google Lens Integration:** Use the AI button to quickly translate text, identify objects for shopping, or explore information in real-time.
- **NFC:** For contactless payments and quick pairing with other NFC-enabled devices.
- **Mobile Hotspot:** Share your device's 5G internet connection with other devices.
- **USB OTG (On-The-Go):** Connect USB devices like flash drives or keyboards directly to your smartphone.
- **Bluetooth & Wi-Fi:** Standard wireless connectivity for accessories and internet access.




Image: The HONOR 400 Lite 5G Smartphone demonstrating the Google Lens translation feature, translating text from English to Italian.

4. MAINTENANCE AND CARE

4.1. Durability Features

The HONOR 400 Lite 5G is designed for durability:

- **IP64 Rating:** Provides resistance against dust and splashes of water. While resistant, avoid prolonged submersion or exposure to high-pressure water.
- **SGS 5-Star Drop Resistance:** Certified to withstand drops from up to 1.5 meters, offering enhanced protection against accidental falls.



Image: The HONOR 40 Lite 5G Smartphone being splashed with water, illustrating its IP64 water resistance rating.



Image: The HONOR 40 Lite 5G Smartphone shown with shattered debris around it, indicating its SGS 5-Star drop resistance.

resistance from 1.8 meters.

4.2. Battery Care

To prolong battery life, avoid exposing your device to extreme temperatures. It is recommended to use the original charging cable. While the device has a large 5230 mAh battery, consistent overcharging or fully draining the battery can impact its long-term health.

4.3. Software Updates

Your HONOR 400 Lite 5G runs on Android 15. Regularly check for and install software updates to ensure your device has the latest features, security patches, and performance improvements. Updates are typically delivered over-the-air (OTA).

5. TROUBLESHOOTING

If you encounter issues with your device, try the following common troubleshooting steps:

- **Device Unresponsive:** Press and hold the Power button for about 10 seconds to force a restart.
- **Network Issues:** Check if your SIM card is correctly inserted. Try toggling Airplane Mode on and off. Ensure Wi-Fi or mobile data is enabled and you have a strong signal.
- **Battery Draining Quickly:** Reduce screen brightness, close unused apps, and disable unnecessary features like GPS or Bluetooth when not in use. Check battery usage in settings to identify power-hungry apps.
- **App Not Responding:** Force close the app through your device settings or restart the phone.
- **Fingerprint Sensor Issues:** Ensure your finger is clean and dry. Re-register your fingerprint if problems persist.

For more complex issues, refer to the official HONOR support website or contact customer service.

6. SPECIFICATIONS

Feature	Specification
Brand	HONOR
Model Name	HONOR 400 Lite
Model Number	ABR-NX1
Operating System	Android 15
RAM	8 GB
Internal Storage	256 GB
Display Size	6.7 Inches
Display Type	AMOLED
Display Resolution	2412 x 1080 Pixels
Refresh Rate	120 Hz
Max Brightness	3500 nits
Main Camera Resolution	108 MP

Feature	Specification
Front Camera Resolution	16 MP
Video Resolution	3840 x 2160 (4K)
Battery Capacity	5230 mAh (Lithium Polymer)
Charging Time	Approx. 75 Minutes
Processor Speed	2.5 GHz
Connectivity	5G, Bluetooth, NFC, USB, Wi-Fi
Water & Dust Resistance	IP64
Drop Resistance	SGS 5-Star (up to 1.5m)
Dimensions	16.1 x 7.5 x 0.73 cm
Weight	177 g
Additional Features	Mobile Hotspot, Dual SIM, GPS, USB OTG



ENERG⚡



HONOR

ABR-NX1





48 h 56 min

A
B
C
D
E



A
B
C
D
E



1400x



IP64

2023/1669

Image: EU Energy Label for the HONOR 400 Lite 5G Smartphone (ABR-NX1), showing energy efficiency class B, battery duration, and IP64 rating.

For detailed product information, refer to the [EU EPREL database \(QR/2335727\)](#).

7. WARRANTY AND SUPPORT

HONOR provides comprehensive customer support for its products. For warranty information, please refer to the warranty card included with your device or visit the official HONOR website for your region. Software updates are guaranteed for an unspecified period.

7.1. Customer Service

For technical assistance, repairs, or general inquiries, please contact HONOR customer support:

- **Manufacturer:** HONOR Technologies Germany GmbH
- **Email:** de.support@honor.com
- **Website:** honor.com/de/support/
- **Telephone:** +49008005833722
- **Address:** Toulouser Allee 27, 40211 Düsseldorf, Germany

Please note that contact details may vary by region. Refer to your local HONOR website for the most accurate support information.

Scheda informativa del prodotto

REGOLAMENTO DELEGATO (UE) 2023/1669 DELLA COMMISSIONE per quanto riguarda l'etichettatura energetica degli smartphone e dei tablet

1. Marchio HONOR		2. Identificativo del modello ABR-NX1
3. Parametri generali del prodotto:		
Parametro		Valore
4. Tipo di dispositivo		Smartphone
5. Sistema operativo		Android
6. Classe di efficienza energetica		B
7. Batteria sostituibile da parte dell'utente		Sì
8. Durata della batteria per ciclo (END _{device} [h])		48
9. Durata della batteria in cicli – impostazioni predefinite [cicli]		1 400
10. Capacità nominale della batteria (C _{rated} [mAh])		5 100
11. Commercializzato con custodia protettiva		No
12. Prova di affidabilità in caso di caduta libera ripetuta – cadute senza riportare difetti [n]		180
13. Prova di affidabilità in caso di caduta libera ripetuta – cadute senza riportare difetti, prova effettuata in stato completamente esteso [n]		n.a.
14. Classe di affidabilità in caso di caduta libera ripetuta		B
15. Grado di protezione da agenti esterni		IP64
16. Profondità di immersione in acqua specifica, in caso di IPx8 [m]		n.a.
17. Resistenza ai graffi dello schermo sulla scala di Mohs		4
18. Carica-batterie	Potenza di uscita richiesta [W]	10
	Tipo di presa (all'estremità del dispositivo)	USB-C
Informazioni sulla riparabilità:		
19. Disponibilità minima garantita di aggiornamenti di sicurezza, aggiornamenti correttivi e aggiornamenti delle funzionalità del sistema operativo (anni)		5
20. Classe di riparabilità (in base all'indice riportato di seguito)		B
21. Indice di riparabilità		3,63
21a. Punteggio relativo alla profondità di smontaggio (S _{DD}) punteggio		3,80
21b. Punteggio relativo al tipo di elementi di fissaggio (S _F)		3,60
21c. Punteggio relativo al tipo di attrezzi (S _T)		4,30

Pagina 1 / 2

21d. Punteggio relativo ai pezzi di ricambio (S _{SP})	4
21e. Punteggio relativo alla durata degli aggiornamenti software (S _{SD})	1
21f. Punteggio relativo alle informazioni sulla riparazione (S _R)	5
22. Link alle informazioni sulla disponibilità di pezzi di ricambio per riparatori professionisti e utenti finali	https://honor.gsmnet.eu/
23. Link alle istruzioni relative alle riparazioni per gli utenti finali	https://www.honor.com/de/support/self-repair
24. Link ai prezzi indicativi ante imposte	https://honor.gsmnet.eu/
Informazioni supplementari:	
25. Durata minima della garanzia offerta dal fornitore [mesi]	24

Modello immesso sul mercato dell'Unione.



Numero di registrazione EPREL: 2335727

<https://eprel.ec.europa.eu/qc/2335727>

Fornitore: Honor Technologies Germany GmbH (Fabbricante)

Sito web:

Servizio di assistenza alla clientela:

Nome: Honor Technologies Germany GmbH

Sito web:

E-mail: de.support@honor.com

Telefono: +4908005893722

Indirizzo:

Toulouse Allee 27
40211 Düsseldorf
Germania

Image: A product information sheet detailing specifications, energy efficiency, and customer support contact information for the HONOR 400 Lite 5G Smartphone.

© 2025 HONOR. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0F1CK8HF3>

More documents and user manuals: <https://manuals.plus/>