

Tailulu MJ35

Tailulu MJ35 Cordless Vacuum Cleaner User Manual

Model: MJ35 | Brand: Tailulu

1. IMPORTANT SAFETY INSTRUCTIONS

Please read all instructions carefully before using this appliance. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- Do not use outdoors or on wet surfaces.
- Do not allow to be used as a toy. Close attention is necessary when used by or near children.
- Use only as described in this manual. Use only manufacturer's recommended attachments.
- Do not use with damaged cord or plug. If appliance is not working as it should, has been dropped, damaged, left outdoors, or dropped into water, return it to a service center.
- Do not pull or carry by cord, use cord as a handle, close a door on cord, or pull cord around sharp edges or corners. Keep cord away from heated surfaces.
- Do not unplug by pulling on cord. To unplug, grasp the plug, not the cord.
- Do not handle plug or appliance with wet hands.
- Do not put any object into openings. Do not use with any opening blocked; keep free of dust, lint, hair, and anything that may reduce airflow.
- Keep hair, loose clothing, fingers, and all parts of body away from openings and moving parts.
- Do not pick up anything that is burning or smoking, such as cigarettes, matches, or hot ashes.
- Do not use to pick up flammable or combustible liquids, such as gasoline, or use in areas where they may be present.
- Do not pick up toxic material, such as chlorine bleach, ammonia, or drain cleaner.
- Do not use without dust bag and/or filters in place.
- Turn off all controls before unplugging.
- Use extra care when cleaning on stairs.
- Store the appliance indoors.
- Recharge only with the charger specified by the manufacturer.

2. PRODUCT OVERVIEW

The Tailulu MJ35 Cordless Vacuum Cleaner is designed for efficient and versatile cleaning. It features a powerful motor, intelligent controls, and a modular design for various cleaning tasks.

Key Features:

- **Powerful Suction:** Up to 90,000Pa with a 550W brushless motor for thorough cleaning.
- **Lightweight Design:** Main body weighs approximately 1.2kg for easy maneuverability.
- **Intelligent LCD Display:** Provides real-time information on battery level, charging status, filter blockage, brush head blockage, and overheating protection.
- **Automatic Dust Detection & AUTO Mode:** Sensors detect dust particle size and floor type, automatically adjusting suction power for optimal cleaning with minimal energy loss.
- **Multiple Suction Modes:** Eco, Standard, Strong, and AUTO modes for different cleaning needs.
- **Long Runtime:** Up to 60 minutes of continuous operation on a single charge.
- **7-Layer Cyclone Filtration System:** Captures 99.97% of fine dust particles (0.3µm) and prevents secondary air pollution with a high-performance HEPA filter.
- **Large Capacity Dust Cup:** 1.5L dust cup reduces the frequency of emptying. One-touch emptying design keeps hands clean.
- **2-Way Design:** Easily converts between stick vacuum and handheld vacuum for versatile cleaning.
- **Tangle-Free V-shaped Brush Head:** Prevents hair from tangling, making maintenance easier.
- **LED Lights on Brush Head:** Illuminates dark areas, making hidden dust visible.
- **Detachable Battery:** Allows for flexible charging options and extended runtime with an optional spare battery.
- **2-in-1 Charging & Storage Stand:** Self-standing design for convenient storage and charging without drilling walls.

90000PA

驚愕の吸引力

新発!!**AUTO**モード
自動調整三段階吸引力

550W

高速回転ブラシレスモーター



Image: The Tailulu MJ35 Cordless Vacuum Cleaner in use, highlighting its 90KPa suction power and 550W brushless motor. A woman is vacuuming a rug while a child and cat are nearby, demonstrating its quiet operation.

超強力吸引力 & 絡まないV字型ブラシ

3段階吸引力調整可能



Image: Close-up of the V-shaped tangle-free brush head, illustrating the three adjustable suction levels: Eco (35KPa), Standard (50KPa), and Strong (90KPa).

先端的なLED タッチディスプレイ

知能提示により、稼働状態を一眼瞭然



Image: The intelligent LCD touch display showing battery percentage, filter status, overheating warning, and AUTO mode indicator. A finger is shown interacting with the touch screen.

3. SETUP

3.1 Assembly

1. Unpack all components and ensure all parts are present.
2. Attach the extension pipe to the main unit until it clicks into place.
3. Connect the brush head to the other end of the extension pipe, ensuring it is securely fastened.
4. For handheld use, attach desired nozzle (crevice tool or 2-in-1 brush) directly to the main unit.

3.2 Initial Charging

Before first use, fully charge the battery. The vacuum cleaner comes with a 2-in-1 charging and storage stand.

1. Place the 2-in-1 charging stand in a convenient location near a power outlet.
2. Mount the vacuum cleaner onto the stand. Ensure the charging contacts align.
3. Connect the power adapter to the charging stand and plug it into a wall outlet.
4. The LCD display will show the charging status. A full charge takes approximately 4 hours.
5. The detachable battery can also be charged independently by removing it from the main unit and placing it in the designated charging slot on the stand.

3つの充電方法 & 2in1充電収納スタンド

自立式スタンドで壁に穴を開けず、収納したまま充電もでき！



Image: The Tailulu MJ35 Cordless Vacuum Cleaner docked in its 2-in-1 charging and storage stand, with accessories neatly stored. This stand allows for charging without wall-mounting.

4. OPERATING INSTRUCTIONS

4.1 Power On/Off

Press the power button once to turn on the vacuum cleaner. It will start in the last used mode or default to Eco mode.

Press the power button again to turn it off.

4.2 Adjusting Suction Modes

The vacuum cleaner offers four suction modes:

- **Eco Mode (35KPa):** For light cleaning and extended runtime (up to 60 minutes).
- **Standard Mode (50KPa):** For daily cleaning tasks.
- **Strong Mode (90KPa):** For deep cleaning and stubborn dirt.
- **AUTO Mode:** The intelligent dust detection sensor automatically adjusts suction power based on the amount of dust and floor type. Activate this mode for optimized cleaning efficiency.

Use the '+' and '-' buttons on the LCD display to cycle through Eco, Standard, and Strong modes. Press the 'A' button to activate or deactivate AUTO mode.

4.3 Using Attachments

The vacuum cleaner comes with various attachments for different cleaning needs:

- **Main Brush Head:** Ideal for floors, carpets, and large surfaces. Features LED lights for improved visibility.
- **Crevice Tool:** Perfect for narrow gaps, corners, and hard-to-reach areas like car interiors or sofa crevices.
- **2-in-1 Brush Nozzle:** Combines a brush and a wide nozzle for cleaning delicate surfaces, keyboards, curtains, or upholstery.

To change attachments, press the release button on the main unit or extension pipe and swap the desired tool.

着脱式バッテリー

パワフル・大容量で部屋を一気に掃除できる



Image: The Tailulu MJ35 demonstrating its 2-way functionality (stick and handheld) and the LED lights on the brush head, which illuminate dust in dark areas.

5. MAINTENANCE

Regular maintenance ensures optimal performance and extends the lifespan of your vacuum cleaner.

5.1 Emptying the Dust Cup

1. Ensure the vacuum cleaner is turned off.
2. Hold the main unit over a trash bin.
3. Press the one-touch release button on the dust cup to open the bottom flap and empty the contents.
4. Close the dust cup flap securely until it clicks.

取り回し良い&LEDライト搭載

微細なホコリが可視化する、見逃げし掃除を防ぎます





Image: A hand demonstrating the one-touch dust cup emptying mechanism, showing debris falling into a trash bin without direct contact, ensuring clean hands.

5.2 Cleaning Filters

The 7-layer filtration system includes a washable HEPA filter. Clean filters regularly to maintain suction power.

1. Twist and remove the dust cup from the main unit.
2. Remove the HEPA filter and other filter components.
3. Tap off loose dust. Rinse the HEPA filter and other washable components under cold running water until the water runs clear.
4. Allow all filter components to air dry completely for at least 24 hours before reassembling. Do not use a dryer or direct heat.
5. Reassemble the filters and dust cup, ensuring they are securely in place.

7段階サイクロンろ過システム

99.99%の高効率な濾過を実現、汚れを効率よく分離




Image: An exploded view of the Tailulu MJ35's 7-layer cyclone filtration system, showing the various filter components including the HEPA filter, designed to capture fine particles and prevent secondary pollution.

5.3 Cleaning the Brush Head

The V-shaped tangle-free brush head minimizes hair tangles, but occasional cleaning may be necessary.

1. Ensure the vacuum cleaner is turned off and disconnected from the extension pipe.
2. Locate the release tab on the side of the brush head and open it to remove the brush roller.
3. Remove any tangled hair or debris from the brush roller and the brush head cavity. A pair of scissors may be used carefully to cut tangled hair.
4. Reinsert the brush roller and close the release tab until it clicks.

6. TROUBLESHOOTING

If you encounter issues with your Tailulu MJ35, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Vacuum does not turn on	Battery is depleted; Battery not properly installed; Power button malfunction.	Charge the battery fully; Ensure battery is clicked into place; Contact customer support if button is faulty.
Loss of suction power	Dust cup is full; Filters are clogged; Blockage in the nozzle or pipe; Brush head tangled.	Empty the dust cup; Clean or replace filters; Check for and remove blockages; Clean the brush head.
Battery not charging	Charger not properly connected; Power outlet not working; Damaged charger or battery.	Ensure charger is securely plugged in; Test outlet with another device; Contact customer support for replacement parts.
Brush head not rotating	Brush head is blocked or tangled; Brush head not properly attached.	Clean the brush head and remove any obstructions; Reattach the brush head securely.
Unusual noise during operation	Blockage in the air path; Damaged motor or brush roller.	Check for and remove any blockages; Contact customer support if noise persists.

7. SPECIFICATIONS

Feature	Detail
Manufacturer	Tailulu
Model Number	MJ35
Package Dimensions	44.2 x 31.8 x 18.6 cm
Color	Light Purple
Size	Large
Noise Level	62 dB
Battery Type	Lithium Ion (Battery Included)
Item Weight (Package)	3.48 kg
Capacity	1.5 Liters
Filter Type	HEPA Filter
Recommended Use	Floor, Carpet, Curtains, Sofa, Tatami, Car
Power Source	Battery Powered

8. WARRANTY AND SUPPORT

The Tailulu MJ35 Cordless Vacuum Cleaner comes with a **12-month warranty** from the date of purchase. You can extend this warranty by an additional year, totaling **2 years of quality assurance**, by contacting customer support.

For product malfunctions, exchanges, or any inquiries, please contact our customer service team through your Amazon account:

1. Go to "Account Service".
2. Select "Order History".
3. Find your order from "Tailulu Direct Store".
4. Click "Ask a Question".

Our dedicated customer support team is available to assist you with any issues or questions you may have.

© 2025 Tailulu. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Answered questions about this manual

Why did my Tailulu MJ35 cordless vacuum suddenly turn off during use and stop working entirely?

If your Tailulu MJ35 suddenly stopped working during use, it is likely due to a safety protection feature or a battery issue. Please follow these troubleshooting steps: Check for Overheating: The MJ35 features an intelligent...

[Read full answer](#)

I am using the Tailulu MJ35 (MJ3507) vacuum cleaner, but suddenly the suction stopped working when I press the switch, and the battery level is no longer displayed on the monitor. I have tried reattaching the battery and cleaning the dust, but the issue persists. Power seems to reach the dust box section as I can operate the panel there to trigger suction. How can I fix this?

Based on your description of the Tailulu MJ35 (MJ3507), it appears there is a communication or connection failure between the main handle (where the power switch and LCD are located) and the motor/battery assembly,...

[Read full answer](#)

My Tailulu MJ35 vacuum cleaner hit an object while cleaning and has stopped working. What should I do?

If your Tailulu MJ35 stopped working after hitting an object, it may have triggered a safety protection feature or suffered a physical blockage. Please follow these troubleshooting steps: Check for Blockages: Inspect the brush head,...

[Read full answer](#)

Why is my Tailulu MJ35 Cordless Vacuum Cleaner not working and the LED screen is blank even though the battery is charged?

If your Tailulu MJ35 vacuum is not turning on and the LED screen remains blank despite the battery being charged, please follow these troubleshooting steps: Check Battery Installation: Ensure the detachable battery is fully seated...

[Read full answer](#)