

AGM B3

AGM B3 Wireless Earbuds User Manual

INTRODUCTION

This manual provides detailed instructions for the use and maintenance of your AGM B3 Wireless Earbuds. These earbuds feature advanced Hybrid Active Noise Cancellation (ANC) and Environmental Noise Cancellation (ENC) for clear audio and calls, ergonomic touch controls, and Bluetooth 5.4 connectivity. Please read this manual thoroughly before using the product to ensure optimal performance and longevity.

WHAT'S IN THE BOX

- AGM B3 Wireless Earbuds (Left and Right)
- Charging Case
- USB Type-C Charging Cable
- User Manual

PRODUCT OVERVIEW

The AGM B3 Wireless Earbuds are designed for comfort and high-quality audio. Each earbud features a touch-sensitive area for control and an ergonomic design for a secure fit. The compact charging case protects the earbuds and provides additional battery life.

Block Out the World with ANC + ENC Combo



Image: AGM B3 Wireless Earbuds and Charging Case, front view.



ENC allows you to be heard clearly during phone calls by isolating your voice.




Image: Close-up of an AGM B3 earbud, highlighting its ergonomic design.

SETUP

1. Charging the Earbuds and Case

Before first use, fully charge the earbuds and charging case. Connect the provided USB Type-C cable to the charging port on the case and to a power source. The indicator lights on the case will show the charging status.

- Earbuds charging time: Approximately 25 minutes.
- Case charging time: Approximately 1.5 hours.

2. Initial Pairing

1. Open the charging case. The earbuds will automatically power on and enter pairing mode.
2. On your device (smartphone, tablet, etc.), enable Bluetooth.
3. Search for available Bluetooth devices and select "AGM B3" from the list.
4. Once connected, a voice prompt will confirm successful pairing.

The earbuds will automatically reconnect to the last paired device when removed from the case and Bluetooth is enabled on the device.

OPERATING INSTRUCTIONS

Power On/Off

- **Power On:** Open the charging case, or press and hold the touch control area on both earbuds for 3 seconds.
- **Power Off:** Place the earbuds back into the charging case and close the lid, or press and hold the touch control area on both earbuds for 5 seconds.

Touch Controls

The AGM B3 earbuds feature intuitive touch controls on each earbud. Refer to the diagram below for the touch control area.

Tap & Go – Touch Control Made Easy

With the AGM Buds 3, control is literally at your fingertips. Want to pause the track, adjust the volume, or pick up a call? Just tap or press. No more fumbling with your phone—everything is smooth and effortless, right on the buds themselves.



Image: AGM B3 Earbuds with the touch control area indicated.

Function	Action
----------	--------

Function	Action
Play/Pause Music	Single tap on either earbud
Next Track	Double tap on the right earbud
Previous Track	Double tap on the left earbud
Volume Up	Triple tap on the right earbud
Volume Down	Triple tap on the left earbud
Answer/End Call	Single tap on either earbud
Reject Call	Press and hold on either earbud for 2 seconds
Activate Voice Assistant	Press and hold on either earbud for 3 seconds (when not on a call)
Switch ANC/Transparency Mode	Press and hold on the left earbud for 2 seconds
Switch Game/Music Mode	Press and hold on the right earbud for 2 seconds

Noise Control Modes (ANC & ENC)

The AGM B3 earbuds offer two primary noise control modes:

- **Active Noise Cancellation (ANC):** Reduces ambient noise by up to 35dB, providing an immersive audio experience. This mode is ideal for listening to music or podcasts in noisy environments.
- **Transparency Mode (Environmental Noise Cancellation - ENC):** Allows you to hear your surroundings while still enjoying your audio. ENC also enhances call clarity by isolating your voice from background noise during phone calls.

To switch between ANC and Transparency modes, press and hold the touch control area on the **left** earbud for 2 seconds.

All Day Play

4 Hours

Music playback

6 Hours

Talk time

180 Days

Standby



Image: Illustration of ANC and ENC technology in action.

Go the Distance with Bluetooth

Say goodbye to short-range frustrations! The AGM Buds 3 come with an extended Bluetooth range of over 10 meters. You can leave your device in the room and move freely while staying connected, enjoying a seamless audio experience.

Bluetooth



Image: Earbud in use, demonstrating noise cancellation.

Game and Music Modes

The earbuds feature dedicated modes optimized for different audio experiences:

- **Game Mode:** Provides low-latency audio, reducing delay between video and sound, which is beneficial for gaming.
- **Music Mode:** Optimizes audio for a balanced and rich music listening experience.

To switch between Game and Music modes, press and hold the touch control area on the **right** earbud for 2 seconds.

MAINTENANCE

Cleaning

- Regularly clean the earbuds and charging case with a soft, dry, lint-free cloth.
- Do not use abrasive cleaners, alcohol, or chemical solvents.
- Gently remove any earwax or debris from the ear tips and speaker mesh using a small, soft brush or cotton swab.

Storage

- When not in use, always store the earbuds in their charging case to protect them and ensure they remain charged.
- Store the product in a cool, dry place, away from extreme temperatures and direct sunlight.

TROUBLESHOOTING

Earbuds not pairing or connecting

- Ensure both earbuds are charged.
- Make sure Bluetooth is enabled on your device.
- Place the earbuds back in the case, close the lid, wait a few seconds, then open it again to re-enter pairing mode.
- Forget/delete "AGM B3" from your device's Bluetooth list and try pairing again.
- Try pairing with a different device to rule out device-specific issues.

No sound or low volume

- Check the volume level on both your device and the earbuds.
- Ensure the earbuds are properly connected to your device.
- Clean any debris from the earbud speaker mesh.
- Try resetting the earbuds (see below).

Earbuds not charging

- Ensure the charging cable is securely connected to both the case and the power source.
- Check if the charging case has power.
- Clean the charging contacts on both the earbuds and inside the case.

- Try a different USB Type-C cable and power adapter.

Resetting the Earbuds

If you experience persistent issues, you can try resetting the earbuds:

1. Place both earbuds into the charging case.
2. On your device, remove or forget "AGM B3" from your Bluetooth device list.
3. With the earbuds in the case and the lid open, press and hold the reset button (if available, usually a small button inside the case or on the back) for approximately 10-15 seconds until the indicator lights flash. If no physical button, try holding the touch areas on both earbuds for 10 seconds while in the case.
4. Close the case, then open it again and attempt to re-pair with your device.

SPECIFICATIONS

Feature	Specification
Model Name	B3
Bluetooth Version	5.4
Bluetooth Range	Up to 33 feet (10 meters)
Ear Placement	In Ear
Noise Control	Active Noise Cancellation (ANC), Environmental Noise Cancellation (ENC)
Audio Driver Size	10 mm Dynamic Driver
Frequency Range	20Hz - 20kHz
Sensitivity	125 dB \pm 3dB
Impedance	32 Ohms
Earbud Battery Life (Music)	Up to 4 hours
Earbud Battery Life (Talk)	Up to 6 hours
Charging Case Battery Capacity	400 mAh
Charging Case Battery Life	Extends total usage to approximately 30 hours
Earbud Charging Time	Approx. 25 minutes
Case Charging Time	Approx. 1.5 hours
Control Method	Touch
Material	Plastic

Feature	Specification
Color	Black & Orange

WARRANTY AND SUPPORT

Warranty Information

The AGM B3 Wireless Earbuds come with a **1-year warranty** from the date of purchase. This warranty covers manufacturing defects and workmanship under normal use. It does not cover damage caused by misuse, accidents, unauthorized modifications, or normal wear and tear.

Customer Support

For technical assistance, warranty claims, or any questions regarding your AGM B3 Wireless Earbuds, please contact AGM customer support. Refer to the product packaging or the official AGM website for the most current contact information.