

M100

M100 Clip On Ear Headphones User Manual

Model: M100 | Brand: Generic

1. PRODUCT OVERVIEW

The M100 Clip On Ear Headphones are designed for versatile audio streaming and communication. Featuring a unique clip-on design, these headphones offer comfort and stability for various activities, including sports. The integrated touch screen provides intuitive control over music, calls, and device settings. With a durable, waterproof, and sweatproof construction, the M100 is suitable for active lifestyles.



Image: The M100 Clip On Ear Headphones with their charging case, showcasing the compact and innovative design.

2. WHAT'S IN THE BOX

- M100 Clip On Ear Headphones (1 pair)
- Charging Cable (1)
- User Manual (1)

3. KEY FEATURES

- **Bluetooth Connectivity:** Wireless headphones compatible with multiple devices including phones, laptops, and desktops for versatile audio streaming.
- **Touch Controls:** Features intuitive touch screen interface for easy control of volume, music playback, and phone calls.
- **Battery Performance:** Quick 1.5-hour charging time ensures extended wireless listening sessions with built-in rechargeable battery.
- **Durability:** Waterproof and sweatproof design makes these headphones perfect for sports and active lifestyles.
- **Call Quality:** Built-in microphone with noise cancellation technology ensures clear voice calls in any environment.





Image: Diagram illustrating key features such as high-resolution sound quality, noise reduction, open-ear design, HD voice, and Wireless 5.4 technology.



Comfortable to wear Open ears

Always perceive environmental sounds to reduce weight loss Lightweight and comfortable to wear

Image: A woman wearing the M100 headphones, highlighting the comfortable and open-ear design that allows perception of environmental sounds.

4. SETUP

4.1 Charging the Headphones

Before first use, fully charge the M100 headphones. The charging case also has an internal battery to recharge the headphones on the go.

1. Connect the provided charging cable to the charging port on the case.
2. Connect the other end of the cable to a USB power source (e.g., computer USB port, wall adapter).
3. The touch screen on the case will indicate charging status. A full charge takes approximately 1.5 hours.

Smart Screen Touch IC

Lossless sound

Dual core 5.4

TYPE-C charge



Smart screen

Noise reduction

Image: The M100 charging case displaying its smart screen, indicating features like lossless sound and Type-C charging.

4.2 Bluetooth Pairing

To connect your M100 headphones to a device:

1. Ensure the headphones are charged and inside the charging case.
2. Open the charging case. The headphones will automatically enter pairing mode.
3. On your device (phone, laptop, etc.), enable Bluetooth and search for available devices.
4. Select "M100" from the list of found devices.
5. Once connected, the touch screen on the case may display a connection icon, and you will hear an audio confirmation.

Your browser does not support the video tag.

Video: A demonstration of the M100 Clip On Ear Headphones, showing the charging case and the headphones being used with a smartphone for music playback.

5. OPERATING INSTRUCTIONS

5.1 Touch Screen Controls

The M100 charging case features a full-color LCD touch screen for convenient control of various functions without needing to access your paired device directly.




Image: A detailed view of the M100's touch screen interface, showing various control options including music playback, volume, noise reduction, language settings, and more.

- **Music Control:** Play, pause, skip tracks directly from the screen.
- **Volume Control:** Adjust audio volume.
- **Noise Reduction Mode:** Toggle between different noise reduction settings (e.g., Off, On, Balanced).
- **Equilibrium Mode:** Adjust equalizer settings.
- **Alarm Clock Setting:** Set alarms.
- **Screen Brightness:** Adjust the display brightness.
- **Language Switching:** Change the interface language.
- **Wallpaper Switching:** Customize the screen background.
- **Find Headphones:** Locate misplaced headphones (L/R indicators).
- **Time Setting:** Adjust the device time.
- **Short Video/Photo Control:** Remotely control your phone's camera for photos or short videos.

5.2 Call Management

The M100 headphones allow for hands-free calling with their built-in microphone and noise cancellation.

- **Answer/End Call:** Tap the touch area on either earbud once.
- **Reject Call:** Press and hold the touch area on either earbud for 2 seconds.
- **Voice Assistant:** Triple-tap the touch area on either earbud to activate your device's voice assistant.

6. MAINTENANCE

6.1 Cleaning

Regular cleaning helps maintain the performance and longevity of your M100 headphones.

- Use a soft, dry, lint-free cloth to wipe the headphones and charging case.
- For stubborn dirt, slightly dampen the cloth with water. Avoid using harsh chemicals or abrasive materials.
- Ensure the charging contacts on both the headphones and the case are clean and free of debris.

6.2 Storage

When not in use, store the headphones in their charging case to protect them and keep them charged.

- Store in a cool, dry place away from direct sunlight and extreme temperatures.
- Avoid exposing the headphones to excessive moisture or corrosive materials.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Headphones not pairing	Low battery; out of range; not in pairing mode; device Bluetooth off.	Charge headphones; ensure device is within 33 feet; open case to activate pairing; turn on device Bluetooth.
No sound	Volume too low; not connected; incorrect audio output selected on device.	Increase volume; re-pair headphones; check device audio settings.
Touch screen unresponsive	Temporary software glitch; low battery.	Place headphones back in case and close/open; charge case fully.
Poor call quality	Weak signal; microphone obstruction; environmental noise.	Move closer to paired device; ensure microphone is clear; use noise reduction mode if available.

8. SPECIFICATIONS

Model Name	Hy M100
Connectivity Technology	Wireless, Bluetooth

Wireless Communication Technology	Bluetooth
Charging Time	1.5 Hours
Compatible Devices	Cellphones, Phone, Laptops, Desktops
Control Type	Volume Control
Water Resistance Level	Waterproof
Control Method	Touch, Voice
Bluetooth Range	33 Feet
Bluetooth Version	5.0
Batteries	1 A batteries required (included)
Manufacturer	Hyundai

9. WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the contact details provided with your purchase or visit the official Generic brand website. Keep your proof of purchase for warranty claims.