TVD SW608-01

TVD SW-608 Steam Cleaner Nylon Brush Accessories User Manual

Model: SW608-01

Introduction

This manual provides instructions for the proper use and maintenance of your TVD SW-608 Steam Cleaner Nylon Brush Accessories. Please read this manual thoroughly before use to ensure safe and effective operation.

Product Overview

The TVD SW-608 Nylon Brush Accessories are designed for use with the TVD SW608 steam cleaner. These small nylon brushes are ideal for scrubbing adhering dirt and grime from delicate surfaces, including tile surfaces and crevices.



Image: A set of three small black nylon brushes, designed as accessories for a steam cleaner. Each brush features stiff bristles angled for effective scrubbing.



Image: A yellow and black TVD SW608 steam cleaner unit, shown with its hose and nozzle attachment. Below the main unit, three small black nylon brush accessories are displayed, indicating their compatibility.

Safety Information

Always ensure the steam cleaner is unplugged and cooled down before attaching or detaching accessories. Avoid direct contact with hot steam or hot brush surfaces during and immediately after use. Use appropriate personal protective equipment, such as gloves, when handling hot components.

Setup

1. **Ensure Compatibility:** Verify that the nylon brushes are compatible with your TVD SW608 steam cleaner model.
2. **Power Off and Cool Down:** Before attaching the brush, ensure your steam cleaner is turned off, unplugged, and has cooled sufficiently to prevent burns.
3. **Attach Brush:** Securely attach the nylon brush to the appropriate nozzle or accessory holder of your steam cleaner. Refer to your steam cleaner's main manual for specific attachment instructions.

Operating Instructions

1. **Prepare Surface:** Clear the area to be cleaned of any loose debris.
2. **Power On Steam Cleaner:** Follow your steam cleaner's instructions to power it on and allow it to heat up to operating temperature.
3. **Apply Steam and Scrub:** Direct the steam nozzle with the attached nylon brush towards the surface to be cleaned. Apply steam while gently scrubbing the surface with the brush. The bristles are designed to loosen adhering dirt and grime.
4. **Target Areas:** These brushes are particularly effective for cleaning grout lines, tile surfaces, and tight crevices.
5. **Wipe Clean:** After scrubbing, wipe the cleaned area with a clean cloth to remove loosened dirt and excess moisture.

Maintenance

- **Cleaning the Brushes:** After each use, allow the brushes to cool. Rinse them under running water to remove any accumulated dirt or debris. If necessary, use a mild soap.
- **Inspect for Wear:** Regularly inspect the nylon bristles for signs of wear, such as flattening or excessive fraying. Worn brushes may be less effective and should be replaced.
- **Storage:** Store the brushes in a clean, dry place away from direct sunlight and extreme temperatures.

Troubleshooting

Problem	Possible Cause	Solution
Brush not cleaning effectively	Bristles are worn or dirty.	Clean the brush or replace it with a new one. Ensure sufficient steam is being applied.
Brush detaches during use	Brush not securely attached.	Ensure the brush is firmly clicked into place on the steam cleaner's nozzle. Allow the steam cleaner to cool before reattaching.

Specifications

- **Model:** SW608-01
- **Brand:** TVD
- **Material:** Nylon bristles, Plastic handle
- **Color:** Black
- **Item Firmness:** Medium
- **Package Includes:** 3 small nylon brushes
- **Recommended Surfaces:** Grout, Porcelain, Tile
- **Package Dimensions:** 6 x 4 x 1 inches
- **Item Weight:** 2.39 ounces

Warranty and Support

For warranty information or technical support regarding your TVD SW-608 Steam Cleaner Nylon Brush Accessories,

please refer to the documentation provided with your main TVD SW608 steam cleaner unit or visit the official TVD website. You may also contact customer service through the retailer where the product was purchased.

TVD Store: Visit the TVD Store on Amazon

© 2025 TVD. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question