

AZZUNO AZ05-BF001

AZZUNO Cordless Brushless Leaf Blower

MODEL: AZ05-BF001 USER MANUAL

1. Safety Information

Always read and understand all safety warnings and instructions before operating this product. Failure to follow all instructions may result in electric shock, fire, and/or serious injury.

General Power Tool Safety Warnings

- Keep work area clean and well-lit. Cluttered or dark areas invite accidents.
- Do not operate power tools in explosive atmospheres, such as in the presence of flammable liquids, gases, or dust. Power tools create sparks which may ignite the dust or fumes.
- Keep children and bystanders away while operating a power tool. Distractions can cause you to lose control.

Electrical Safety

- Power tool plugs must match the outlet. Never modify the plug in any way.
- Do not expose power tools to rain or wet conditions. Water entering a power tool will increase the risk of electric shock.
- Do not abuse the cord. Never use the cord for carrying, pulling or unplugging the power tool. Keep cord away from heat, oil, sharp edges or moving parts.

Personal Safety

- Stay alert, watch what you are doing and use common sense when operating a power tool.
- Dress properly. Do not wear loose clothing or jewelry. Keep your hair, clothing, and gloves away from moving parts.
- Avoid accidental starting. Ensure the switch is in the off-position before connecting to battery pack, picking up or carrying the tool.

2. Package Contents

The AZZUNO Cordless Brushless Leaf Blower package includes the following items:

- 1 × Leaf Blower Unit

- 1 × Blower Tube
- 1 × Extension Nozzle
- 2 × 4.0Ah Lithium Batteries
- 1 × Battery Charger
- 1 × User Manual




Image: All components included in the AZZUNO Leaf Blower package.

3. Product Overview

Familiarize yourself with the main parts of your AZZUNO Leaf Blower:




Image: Labeled diagram of the leaf blower showing the battery interface, ergonomic handle, speed control switch, blower tube release button, blower tube, and extension tube.

- **Battery Interface:** Connects the battery to the blower unit.
- **Ergonomic Handle:** Designed for comfortable grip and reduced fatigue during operation.
- **Speed Control Switch:** Allows selection of three different speed levels.
- **Blower Tube Release Button:** Used to detach and attach the blower tube.
- **Blower Tube:** Directs the airflow.
- **Extension Nozzle:** Provides a narrower, more focused airflow for specific tasks.

4. Setup

Follow these steps to assemble your leaf blower:

1. Push the blower tube onto the tool body buckle. Rotate and lock it into place.
2. Install the charged battery onto the blower body until it clicks securely.
3. Attach the extension nozzle to the blower tube if desired, ensuring it is firmly secured.

3 Steps Assembly



Image: Visual guide for the 3-step assembly process: attaching the blower tube, installing the battery, and securing the chassis.

Your browser does not support the video tag.

Video: This video demonstrates the assembly of the leaf blower, including attaching the tube and battery, and shows the three-mode adjustment in action for various cleaning tasks.

5. Charging the Battery

The leaf blower is equipped with two 4.0Ah lithium-ion batteries. Each battery includes overheat protection for safe and reliable operation. A fast charger is included and fully charges the batteries in approximately 2 hours.


- Connect the charger to a standard power outlet.
- Insert the battery into the charger. The indicator light on the charger will show the charging status.
- Once fully charged, remove the battery from the charger.



1-Hour Fast Charging



Maximum 21V Battery



Advanced Brushless Motor



Ergonomic Design

Image: The battery charger connected to a power outlet, indicating the charging process.



580 $\frac{\text{CFM}}{\text{MAX}}$
120 $\frac{\text{MPH}}{\text{MAX}}$

Image: Two 4.0Ah lithium batteries, highlighting their capacity and runtime capabilities.

6. Operating Instructions

The AZZUNO Cordless Brushless Leaf Blower features a powerful brushless motor and turbine technology, delivering up to 580 CFM / 120 MPH. It offers three speed levels for various cleaning needs.

Starting and Stopping


- To start the blower, press and hold the ON/OFF button until the display illuminates.
- To stop the blower, press and hold the ON/OFF button again.

Adjusting Speed Modes

Use the 'CYCLE SPEED' button to switch between the three available modes:

- **Low-Speed Mode:** Ideal for indoor cleaning tasks, such as light dust and debris. Provides up to 120 minutes of runtime.
- **Mid-Speed Mode:** Suitable for general outdoor tasks like clearing dry leaves.
- **High-Speed Mode (Turbine Mode):** Provides powerful airflow for stubborn leaves, heavy debris, and even light snow removal. Offers up to 30 minutes of runtime.

BRUSHLESS MOTOR



30%
Reduce Weight



50%
Air Volume Increased



30%
Efficiency Increased



OLP
Overload Protection

Image: The leaf blower in operation, demonstrating its maximum air volume of 580 CFM and maximum wind speed of 120 MPH.



Blowing Leaves



Blowing Snow

Multiple scene usage



Blowing Dust



Blowing Grass

Image: The leaf blower being used in various scenarios, including blowing leaves, snow, dust, and grass.

7. Maintenance and Inspection

Regular maintenance ensures the longevity and optimal performance of your leaf blower.

- **General Inspection:** Regularly inspect all mounting screws and ensure they are properly tightened. Loose screws may result in serious injury.
- **Cleaning:** After each use, clean the blower thoroughly of any dust or debris. Use a soft, dry cloth. Do not use water or chemical cleaners.
- **Battery Care:** Store batteries in a cool, dry place away from direct sunlight. Do not store batteries in a discharged state for extended periods.
- **Motor Maintenance:** The brushless motor is designed for long-term reliability. If you notice any unusual noise or performance drop, contact customer support.

8. Troubleshooting

If you encounter issues with your leaf blower, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Blower does not start	Battery not installed correctly or discharged	Ensure battery is fully charged and properly inserted.
Reduced airflow	Blower tube or nozzle is clogged with debris	Clear any obstructions from the blower tube and nozzle.
Short runtime	Battery not fully charged or operating in high-speed mode constantly	Ensure battery is fully charged. Use lower speed modes for longer runtime.
Overheating	Continuous heavy use or blocked vents	Allow the tool to cool down. Ensure vents are clear of debris.

9. Specifications

Feature	Specification
Brand	AZZUNO
Model	AZ05-BF001
Power Source	Battery Powered
Voltage	20V
Air Volume (Max)	580 CFM
Wind Speed (Max)	120 MPH
Motor Type	Brushless
Battery Type	Lithium-ion (2 x 4.0Ah included)
Runtime (Low Speed)	Up to 120 minutes
Runtime (High Speed)	Up to 30 minutes
Charging Time	Approx. 2 hours
Item Weight	3.1 pounds (blower unit only)
Special Feature	Adjustable Tube Length, 3 Speed Modes

10. Warranty and Support

AZZUNO is committed to providing high-quality products and customer satisfaction. If you experience any issues with your AZZUNO cordless leaf blower, please do not hesitate to contact us.

- **Warranty:** Please refer to the product packaging or contact customer support for specific warranty details.
- **Customer Support:** We offer 24-hour customer support and will provide a satisfactory solution for any product-related concerns.

For assistance, please visit the AZZUNO store on Amazon or contact us via the information provided in your purchase documentation.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question