Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

GRUSIGN CWG-CF-BLK

GRUSIGN 72" Tall Storage Cabinet User Manual

Model: CWG-CF-BLK

1. Safety Information

Please read and understand all instructions before assembly and use. Keep this manual for future reference.

- Always follow the assembly instructions carefully.
- Do not exceed the maximum load capacity of 100 pounds for the entire cabinet. Individual shelf capacities are detailed in the specifications.
- Secure the cabinet to the wall using the provided anti-tip hardware to prevent tipping, especially in households with children or pets.
- Always use appropriate safety gear when handling heavy items or during assembly.
- Ensure all connections are tight before use. Periodically check and re-tighten fasteners as needed.
- Do not stand or climb on the cabinet.


2. Product Overview

The GRUSIGN 72" Tall Storage Cabinet is a versatile furniture piece designed for various rooms, including kitchens, dining rooms, and living rooms. It features a farmhouse design with barn doors and offers ample storage solutions.

Key Features:

- **Ample Storage Space:** Includes 4 adjustable shelves and an extra-large drawer.
- **Barn Doors with Storage:** Features 8 built-in compartments on the inside of the barn doors for bottles, seasonings, and small items.
- **Durable Construction:** Crafted from high-density engineered wood and reinforced with a sturdy steel frame.
- **Anti-Tip Hardware:** For enhanced stability and safety.
- **Versatile Design:** Suitable for various storage needs across different rooms.

Dimensions and Capacity:



This image illustrates the overall dimensions and weight capacities of the GRUSIGN 72" Tall Storage Cabinet. The cabinet measures 15.6 inches deep, 29.9 inches wide, and 72 inches high. The top shelves can hold up to 50 lbs each, the middle shelf 100 lbs, the drawer 50 lbs, and the bottom shelves 50 lbs and 100 lbs respectively.



This image displays the GRUSIGN 72" Tall Storage Cabinet in its closed position, highlighting its black finish and farmhouse-style barn doors.

3. Parts List

All necessary hardware and accessories for assembly are included in the package. Please refer to the detailed instruction manual provided in the box for a complete list of parts and hardware. Before beginning assembly, ensure all components are present and undamaged.

4. Assembly Instructions

A detailed instruction manual is included with your GRUSIGN 72" Tall Storage Cabinet. Please follow the step-by-step guide carefully. Due to the size and complexity of this cabinet, assembly may take some time and is recommended for two people.

Important Assembly Tips:

- Lay out all components on a clean, soft surface to prevent scratches.
- Identify each part by its label before starting.
- Do not overtighten screws during initial assembly; tighten fully once the section is complete.
- Utilize the anti-tip hardware to secure the cabinet to a wall stud for maximum stability.



This image shows the fully assembled GRUSIGN 72" Tall Storage Cabinet in a kitchen, demonstrating its height and how it fits into a home environment.

5. Operating Instructions

The GRUSIGN storage cabinet is designed for easy access and organization.

Adjustable Shelves:

- The cabinet features 4 adjustable shelves. To adjust a shelf, carefully remove any items, then lift the shelf and reposition the shelf pins to the desired height. Ensure all four pins are securely inserted before placing items back

on the shelf.

Large Drawer:

- The extra-large drawer operates on smooth-gliding tracks. Pull the drawer gently to open and push to close. Avoid slamming the drawer to ensure longevity of the mechanism.

Barn Doors with Storage:

- The four barn doors open outwards. The upper doors feature 8 built-in compartments, ideal for storing smaller items like spices, bottles, or frequently used condiments. Ensure items are placed securely to prevent them from falling when opening or closing the doors.



This image shows the GRUSIGN cabinet with all its doors open, illustrating the extensive storage options, including adjustable shelves and door compartments, filled with kitchen essentials.



A detailed view of the open cabinet doors, emphasizing the 8 door shelves and the adjustable main shelf, organized with various food containers and dishes.



This image focuses on the large pull-out drawer, showcasing its capacity for storing plates, cutlery, and other dining accessories.

Product Video: GRUSIGN Black 72" Tall Storage Cabinet

Your browser does not support the video tag.

This video provides a visual overview of the GRUSIGN Black 72" Tall Storage Cabinet, demonstrating its features and how it functions in a kitchen setting.

Product Video: Farmhouse Kitchen Pantry Cabinet

Your browser does not support the video tag.

This video highlights the farmhouse design and practical storage capabilities of the kitchen pantry cabinet, showing various ways to organize items within its compartments.

6. Maintenance

Proper care will extend the life and appearance of your GRUSIGN storage cabinet.

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners, which can damage the finish.
- **Spills:** Clean spills immediately to prevent staining or damage to the engineered wood.
- **Hardware:** Periodically check all screws and fasteners to ensure they are tight. Re-tighten as necessary.
- **Placement:** Avoid placing the cabinet in direct sunlight or near heat sources, which can cause fading or warping.

7. Troubleshooting

If you encounter any issues with your GRUSIGN storage cabinet, please refer to the following common solutions:

Problem	Possible Cause	Solution
Cabinet is wobbly or unstable.	Loose fasteners; uneven floor; anti-tip hardware not installed.	Ensure all screws are tightened. Adjust floor levelers if present, or place shims under the base. Install or properly secure the anti-tip hardware to the wall.
Doors do not close properly or are misaligned.	Loose hinge screws; uneven assembly.	Check and tighten hinge screws. Review assembly steps to ensure the frame is square.
Drawer sticks or does not slide smoothly.	Obstruction in the drawer slide; misaligned drawer.	Check for any objects obstructing the slides. Ensure the drawer is correctly seated on its tracks. Verify that the drawer slides are properly installed and aligned.
Door compartments do not hold items securely.	Items are too large or heavy for the compartments.	Ensure items placed in door compartments are within their size and weight limits. Use lighter, smaller items for these areas.

If you encounter any issues not listed here, or if the suggested solutions do not resolve the problem, please contact customer support.

8. Specifications

Feature	Detail
Brand	GRUSIGN
Model Number	CWG-CF-BLK
Color	Black
Material	Engineered Wood, Metal
Product Dimensions (D x W x H)	15.6"D x 29.9"W x 72"H
Item Weight	115 Pounds
Weight Capacity Maximum	100 Pounds (overall)
Number of Shelves	4 (adjustable)

Feature	Detail
Number of Drawers	1
Number of Doors	4
Number of Door Compartments	8
Installation Type	Freestanding
Required Assembly	Yes
Additional Features	Adjustable Shelf, Anti-Tipping, Heavy Duty, Scratch Resistant

9. Warranty and Support

Your GRUSIGN 72" Tall Storage Cabinet comes with a**12-month warranty** for worry-free use, covering manufacturing defects and material flaws.

If you encounter any issues during assembly or use, or have questions regarding the product, please contact GRUSIGN customer support. We aim to respond within 12-24 hours (due to time differences) to assist you. Customer experience is our top priority.

Please have your model number (CWG-CF-BLK) and purchase information ready when contacting support.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0F1D7GR55

More documents and user manuals: **https://manuals.plus/**