Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

SEDETA B0F1D8Z5CZ

SEDETA Farmhouse L-Shaped Standing Desk Instruction Manual

Model: B0F1D8Z5CZ
Brand: SEDETA

Introduction

This manual provides comprehensive instructions for the assembly, operation, and maintenance of your SEDETA Farmhouse L-Shaped Standing Desk. Please read all instructions carefully before beginning assembly and retain this manual for future reference. Proper assembly and usage ensure the longevity and safe operation of your desk.

Safety Information

For your safety and to prevent damage to the product, please adhere to the following guidelines:

- Always ensure the desk is properly assembled and anchored to the floor to prevent tipping.
- Do not exceed the weight limit of the desk (176 lbs) to maintain stability.
- Keep the desk away from heat sources and avoid placing heavy objects on the edges to prevent damage.
- Always follow the instructions provided for safe operation and maintenance.
- Ensure all screws and fasteners are tightened securely during assembly and periodically check for looseness.
- Keep children and pets away from the desk during height adjustments.
- Do not sit or stand on the desk.

Product Features

- **Adjustable Height Standing Desk:** Electrically adjustable height from 28 to 47 inches with memory function for 3 preferred settings. Features a quiet and durable motor.
- **Ample Storage Space:** Includes two drawers and a storage cabinet. The large file cabinet accommodates letter, A4, and legal-sized documents. Smooth sliding tracks ensure effortless operation.
- **Integrated Power Outlets:** Equipped with a charging station featuring 2 AC outlets (125V/12A) and 2 USB ports (5V/2A) to power up to 4 devices simultaneously. Includes a 6.56-foot power cord.
- **Farmhouse Design:** Constructed from FSC-Certified wood with a sturdy structure and thickened top. Features a sliding barn door and elegant, textured grooves.

- **Spacious Work Surface:** The 55-inch L-shaped design maximizes corner space and provides a generous tabletop for office essentials.
- **Curved Edges:** Tabletop edges are rounded for enhanced safety and a refined appearance.

Assembly Instructions

Assembly of the SEDETA Farmhouse L-Shaped Standing Desk requires careful attention to detail. It is recommended to have two people for assembly. Please follow the numbered steps in the provided video tutorial and written instructions.

Assembly Video Tutorial

Your browser does not support the video tag.

Video Description: This video provides a step-by-step visual guide for assembling the SEDETA L-Shaped Standing Desk. It demonstrates the process of connecting various components, including the frame, storage units, and tabletop, ensuring proper alignment and secure fastening.

General Assembly Steps:

1. **Unpack and Identify Parts:** Carefully unpack all components and hardware. Refer to the parts list (not included in this HTML, but typically found in the physical manual) to identify each piece.
2. **Assemble the Storage Unit Base:** Begin by assembling the base of the storage unit, attaching the side panels and internal shelves.
3. **Construct Drawers:** Assemble the two storage drawers, ensuring the drawer slides are correctly installed.
4. **Attach Sliding Barn Doors:** Install the hardware for the sliding barn doors onto the storage unit.
5. **Assemble the Standing Desk Leg:** Construct the main standing desk leg, integrating the lifting mechanism.
6. **Connect Frame to Storage Unit and Leg:** Securely attach the metal frame to both the storage unit and the standing desk leg. Ensure all connections are tight.
7. **Install Tabletop:** Place the main tabletop onto the assembled frame and secure it with the provided fasteners.
8. **Connect Control Panel and Power:** Attach the control panel to the underside of the desk and connect all necessary power cables for the lifting mechanism and integrated outlets.
9. **Final Checks:** Verify that all components are securely fastened and the desk is stable. Test the height adjustment function.

Image Description: This diagram illustrates the overall dimensions of the L-shaped standing desk, including the main tabletop (55" L x 23.6" W), the height adjustment range (28.7" to 46.8"), and the dimensions of the storage drawers (16.9" L x 11" W x 6.3" H for the smaller, 16.9" L x 11" W x 11.8" H for the larger file drawer). It also indicates a load capacity of 176 lbs.

Operating Instructions

Height Adjustment

Image Description: A close-up view of the desk's control panel, showing an LED display, up/down arrows, three memory height buttons (1, 2, 3), and a reset button (RST). The display shows "119" which likely indicates the current height in centimeters or a similar unit.

1. **Adjusting Height:** Use the **Up (∧)** and **Down (∨)** arrow buttons on the control panel to raise or lower the desk to your desired height. The current height will be displayed on the LED screen.
2. **Saving Memory Presets:** The desk allows you to save up to three preferred height settings.
   - Adjust the desk to your desired height using the Up/Down arrows.
   - Press and hold one of the memory buttons (**1**, **2**, or **3**) until the display flashes or beeps, indicating the height has been saved.
3. **Recalling Memory Presets:** To move the desk to a saved height, simply press the corresponding memory button (**1**, **2**, or **3**). The desk will automatically adjust to that height.
4. **Reset Function:** If the desk encounters an error or needs recalibration, press and hold the **RST** button until the desk moves to its lowest position and resets.

Using Power Outlets

Image Description: A close-up of the recessed power strip on the desk, showing two standard AC outlets and two USB charging ports. A smartphone is shown charging via one of the USB ports.

The desk includes a built-in power strip for convenient charging of your devices:

- Plug the desk's main power cord into a wall outlet.
- Use the 2 AC outlets (125V/12A) for laptops, monitors, or other electronic devices.
- Use the 2 USB ports (5V/2A) to charge smartphones, tablets, and other USB-powered devices.

Storage Features

Image Description: This image displays the two storage drawers of the desk. One drawer is shown with general office supplies, while the other is configured as a file cabinet, demonstrating its capacity for Letter, A4, and Legal-sized hanging files.

- **Drawers:** The desk features two smooth-gliding drawers. The larger drawer is designed to accommodate hanging files of Letter, A4, or Legal size.
- **Sliding Barn Door Cabinet:** The cabinet section features a sliding barn door mechanism. Slide the doors to access the internal shelves for additional storage.

Maintenance

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners that may damage the finish. The desk surface is waterproof and scratch-resistant.
- **Hardware Check:** Periodically inspect all screws and fasteners to ensure they remain tight. Re-tighten if necessary to maintain stability.
- **Motor Care:** The lifting motor is designed for durability and quiet operation. No special maintenance is typically required for the motor itself. Avoid obstructing the lifting mechanism.

- **Cable Management:** Utilize the cable management features to keep cords tidy and prevent them from getting caught in the moving parts of the desk.

Image Description: This image shows two close-up views of the desk's surface. On the left, a hand wipes a wet spot with a cloth, demonstrating its waterproof nature. On the right, a screwdriver is shown attempting to scratch the surface, highlighting its scratch-resistant properties.

Troubleshooting

If you encounter issues with your desk, please refer to the following common troubleshooting steps:

- **Desk Not Adjusting Height:**
  - Check if the power cord is securely plugged into both the desk and the wall outlet.
  - Ensure there are no obstructions preventing the desk from moving up or down.
  - Try the reset function by pressing and holding the **RST** button until the desk moves to its lowest position and resets.
- **Unstable Desk:**

- Verify that all assembly screws and fasteners are tightened.
- Ensure the desk is placed on a level surface.
- Confirm that the weight on the desk does not exceed the maximum load capacity of 176 lbs.

- **Power Outlets Not Working:**
  - Check the main power connection of the desk.
  - Ensure the devices you are trying to charge are functioning correctly.

If these steps do not resolve the issue, please contact customer support for further assistance.

Specifications

Feature	Detail
Brand	SEDETA
Model	B0F1D8Z5CZ
Product Dimensions	47.2"D x 55"W x 28.7"H
Color	Black
Style	Modern Farmhouse
Base Material	Legs (Wood)
Top Material Type	Engineered Wood
Item Weight	125.66 Pounds
Minimum Height	28.7 Inches
Maximum Height	46.8 Inches
Number of Height Positions	3 (Memory Presets)
Storage Options	2 drawers, 1 storage cabinet
Power Outlets	2 AC Outlets (125V/12A), 2 USB Ports (5V/2A)
Power Cord Length	6.56 Feet
Required Assembly	Yes

Warranty and Support

Your SEDETA Farmhouse L-Shaped Standing Desk comes with a limited warranty. For specific warranty details, please refer to the documentation included with your purchase or contact SEDETA customer service.

If your desk arrives damaged, scratched, or with missing parts, please contact us for a free replacement or partial refund. Our customer support team is available to assist with any questions or concerns regarding your product.

For customer support, please visit the SEDETA Store on Amazon or refer to the contact information provided in your purchase documentation.

Product Overview Video

Your browser does not support the video tag.

Video Description: This video provides a general overview of the SEDETA Farmhouse L-Shaped Standing Desk, showcasing its key features such as the adjustable height, integrated storage solutions, and overall design aesthetics in a home office setting.

© 2025 SEDETA. All rights reserved.
Please recycle this manual responsibly.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0F1D8Z5CZ

More documents and user manuals: **https://manuals.plus/**