

- Manuals.plus /
- › Micool /
- › Micool Ear Clip Headphones Bluetooth 5.4 User Manual

Micool M100

Micool Ear Clip Headphones User Manual

Model: M100

1. INTRODUCTION

Thank you for choosing Micool Ear Clip Headphones. These open-ear earbuds feature Bluetooth 5.4 connectivity, a touchscreen display, and AI noise-cancelling technology, designed for comfort and high-fidelity sound. This manual provides essential information for setting up, operating, and maintaining your headphones.



Image: Micool Ear Clip Headphones (Black) with their charging case, featuring a touchscreen display.

2. PACKAGE CONTENTS

Please check the package for the following items:

- Micool Ear Clip Headphones (Left and Right)
- Wireless Charging Case
- USB Type-C Charging Cable (not explicitly listed but implied by "Type-C Fast Charging")
- User Manual (this document)

3. PRODUCT FEATURES

- **Open Ear Design:** Allows awareness of surroundings while enjoying audio, ideal for outdoor activities.
- **Touchscreen Display:** Provides intuitive control over calls, volume, and music playback directly from the charging case.
- **AI Noise Cancelling & CVC Call Clarity:** Ensures clear conversations in noisy environments.
- **Dual Independent Use:** Each ear clip can function separately for flexible usage.
- **Bluetooth 5.4:** Offers fast pairing, stable connectivity, and ultra-low power consumption.
- **Comfort Fit:** Ergonomic design ensures secure and comfortable wear.

- **Long Battery Life & Type-C Fast Charging:** Extended usage time with quick recharging capabilities.




Image: A woman wearing the Micool Ear Clip Headphones, demonstrating their comfortable, open-ear fit. An inset diagram shows how the ear clip sits on the ear.



Directional sound Eliminate sound leakage



**DIRECTIN
TONE**
Directional sound

The eighth generation directional transmission technology,
Reverse sound wave reduces sound leakage

Image: A diagram illustrating the directional sound technology of the headphones, showing sound waves directed into the ear canal and minimizing leakage.

Wireless V5.4 More stable

V5.4 chip module brings more stability
A smoother and faster transmission experience



Image: A stylized image of the Micool Ear Clip Headphones, with an internal view highlighting the Bluetooth 5.4 chip for stable and fast wireless connection.

4. SETUP

4.1 Charging the Headphones and Case

1. Place both ear clips into the charging case, ensuring they are properly seated.
2. Connect the USB Type-C charging cable to the charging port on the case and plug the other end into a compatible USB power source (e.g., wall adapter, computer USB port).
3. The touchscreen display on the case will indicate the charging status. A full charge typically takes approximately 1.5-2 hours for the case and headphones.

4.2 Bluetooth Pairing

1. Ensure the headphones are charged.
2. Open the charging case. The headphones will automatically enter pairing mode, indicated by a flashing light on the earbuds or a prompt on the case's display.

3. On your device (smartphone, tablet, computer), go to the Bluetooth settings.
4. Search for new devices and select "Micool M100" from the list.
5. Once connected, the headphones will confirm the successful pairing, and the indicator light will stop flashing.
6. For subsequent use, the headphones will automatically connect to the last paired device when removed from the case.

5. OPERATING INSTRUCTIONS

5.1 Wearing the Headphones

Gently clip each earbud onto your ear, ensuring the speaker portion is positioned comfortably near your ear canal and the clip rests securely behind your ear. Adjust for optimal sound and comfort. The open-ear design allows you to hear ambient sounds.

5.2 Touchscreen Display Controls (on Charging Case)

The charging case features a touchscreen display for convenient control. Specific functions may vary, but generally include:

- **Battery Level:** Displays remaining battery for both earbuds and the case.
- **Volume Control:** Swipe or tap to adjust playback volume.
- **Music Playback:** Play/Pause, Next/Previous track controls.
- **Call Management:** Answer/End calls.
- **Mode Selection:** Switch between different sound modes or noise-cancelling settings if available.

5.3 Earbud Touch Controls

Each earbud may have touch-sensitive areas for quick control. Common functions include:

- **Single Tap:** Play/Pause music, Answer/End call.
- **Double Tap (Left/Right):** Previous/Next track.
- **Triple Tap:** Activate voice assistant.
- **Long Press:** Reject call, toggle noise cancelling/transparency mode.

Refer to the specific on-screen prompts or included quick start guide for detailed touch control gestures.

6. MAINTENANCE

6.1 Cleaning

- Wipe the headphones and charging case with a soft, dry, lint-free cloth.
- Do not use abrasive cleaners, alcohol, or chemical solvents.
- Keep the charging contacts on both the earbuds and the case clean and dry.

6.2 Storage

When not in use, store the headphones in their charging case to protect them from dust and damage. Store in a cool, dry place away from extreme temperatures.

7. TROUBLESHOOTING

Problem	Possible Solution
Headphones not pairing	• Ensure headphones are charged. • Turn off and on Bluetooth on your device. • Forget "Micool M100" from your device's Bluetooth list and re-pair. • Ensure no other devices are connected to the headphones.
No sound or low volume	• Check headphone and device volume levels. • Ensure headphones are properly connected. • Re-pair the headphones.
Charging case display unresponsive	• Ensure the case is charged. • Try connecting the charging cable to reset.
Headphones not charging in case	• Ensure earbuds are correctly seated in the case. • Clean the charging contacts on both earbuds and case. • Ensure the charging case itself has power.

8. SPECIFICATIONS

Feature	Specification
Model Name	M100
Connectivity Technology	Wireless (Bluetooth 5.4)
Ear Placement	Open Ear
Form Factor	On Ear / Clip On
Included Components	Wireless Charging Case
Material	Plastic
Color	Black
Product Dimensions	4 x 4 x 1.8 inches
Item Weight	3.04 ounces
Batteries	1 Lithium Ion battery (included)
UPC	770029329702
Manufacturer	MICOOL

Feature	Specification
Date First Available	March 13, 2025

9. SAFETY INFORMATION

- Do not expose the headphones or charging case to extreme temperatures, humidity, or liquids.
- Avoid dropping or subjecting the device to strong impacts.
- Do not attempt to disassemble or repair the device yourself. Contact qualified service personnel.
- Listen at moderate volume levels to prevent hearing damage.
- Be aware of your surroundings when using open-ear headphones, especially in traffic or hazardous environments.

10. WARRANTY AND SUPPORT

Micool products are designed and manufactured to the highest quality standards. For information regarding warranty coverage, technical support, or service inquiries, please refer to the warranty card included with your product or visit the official Micool website. You may also contact the seller directly for assistance.

© 2025 Micool. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0F1D95VK6>

More documents and user manuals: <https://manuals.plus/>