Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

realme 14T

realme 14T 5G Smartphone User Manual

Model: realme 14T

1. Introduction

This manual provides essential information for setting up, operating, maintaining, and troubleshooting your realme 14T 5G Smartphone. Please read this manual carefully to ensure proper use and to maximize the device's performance and longevity.



Image: realme 14T 5G Smartphone, showcasing its sleek design and camera module.

2. Setup

2.1 Package Contents

Verify that all items are present in your realme 14T 5G package:

- realme 14T 5G Smartphone
- USB Cable
- Phone Case
- Screen Protector (pre-applied or included)
- Quick Start Guide (this document)

2.2 Inserting SIM Card

Locate the SIM card tray on the side of your device. Use the provided SIM ejector tool to open the tray. Insert your Nano-SIM card(s) and/or microSD card (if applicable) into the designated slots, ensuring correct orientation. Gently push the tray back into the device until it clicks into place.

2.3 Initial Power On and Configuration

Press and hold the Power button until the realme logo appears. Follow the on-screen instructions to select your language, connect to a Wi-Fi network, sign in to your Google account, and set up security features like facial recognition or a fingerprint. Your device comes with a pre-applied screen protector and a protective case for immediate use.

2.4 Charging the Device

Connect the USB cable to the charging port on your realme 14T 5G and plug the other end into a compatible 45W SUPERVOOC charger (charger not included in some regions, please check package contents). The device supports fast charging, allowing for quick power replenishment.

3. Operating Instructions

3.1 Display and Navigation

The realme 14T 5G features a 6.67-inch 120Hz AMOLED Esports Display, offering a smooth and vibrant visual experience with a 92.65% screen-to-body ratio. Navigate the interface using touch gestures: swipe, tap, pinch, and zoom. The high refresh rate ensures fluid scrolling and responsive gaming.



Image: The realme 14T 5G's 6.67-inch AMOLED display, highlighting its 120Hz refresh rate and immersive visual quality.

3.2 Performance and Connectivity

Powered by the MediaTek Dimensity 6300 5G chipset (6nm process), the realme 14T 5G delivers robust performance for multitasking, gaming, and 5G connectivity. This chipset ensures an optimal, responsive, and energy-efficient user

experience.




Image: Diagram illustrating the MediaTek Dimensity 6300 5G chipset and its performance capabilities.

3.3 Camera Features

Capture high-quality photos and videos with the 50MP rear camera and 16MP front camera. The device supports 4K video recording at 120 frames per second. Explore various camera modes and settings for creative photography.

3.4 Battery Management

The realme 14T 5G is equipped with a large 5260mAh battery, providing extended usage for gaming, movies, and music. With 45W SUPERVOOC charging, you can quickly recharge your device, ensuring you have power throughout the day.




Image: Visual representation of the 5260mAh battery and 45W fast charging capability.

3.5 Water Resistance

The device boasts IP69, IP68, and IP66 water resistance ratings, making it resistant to hot water, immersion, and splashes. This ensures durability in various environments, providing peace of mind during accidental spills or use in light rain.



Image: The realme 14T 5G demonstrating its high-level water resistance, including IP66 for splashes, IP68 for immersion, and IP69 for hot water.

3.6 AI Features (NEXT Ai)

Experience enhanced functionality with NEXT Ai, which includes features like AI Eraser for removing unwanted objects, Deblur AI for sharpening images, Clear Face AI for improved portraits, and Reflection Removal AI for clearer photos through glass.



Image: Examples of AI features such as AI Eraser, Deblur AI, Clear Face AI, and Reflection Removal AI in action.

4. Maintenance

4.1 Cleaning Your Device

To clean your realme 14T 5G, use a soft, lint-free cloth. Avoid abrasive materials, solvents, or aerosol sprays. For stubborn smudges, slightly dampen the cloth with water. Ensure all ports are dry before charging.

4.2 Software Updates

Regularly check for and install software updates to ensure your device has the latest features, security patches, and performance improvements. You can usually find this option in your device's Settings menu under "System" or "About Phone."

4.3 Battery Care

To prolong battery life:
- Avoid extreme temperatures.
- Do not let the battery drain completely regularly.
- Use the original or certified charging accessories.
- Optimize battery settings in your device to manage power consumption.

4.4 Water Resistance Precautions

While your device is water-resistant, it is not waterproof. Avoid intentional submersion, exposure to high-pressure water, or use in saunas/steam rooms. Water resistance may decrease over time with normal wear and tear. Ensure all ports are closed and dry before exposure to liquids.

5. Troubleshooting

Common Issues and Solutions:
- **Device not turning on:** Ensure the battery is charged. Press and hold the Power button for at least 10 seconds.
- **Charging problems:** Check the USB cable and charger for damage. Try a different power outlet. Ensure the charging port is clean.
- **Connectivity issues (Wi-Fi/5G):** Restart your device. Toggle Wi-Fi/Mobile Data off and on. Check router settings for Wi-Fi.
- **Apps crashing/freezing:** Close and reopen the app. Clear the app's cache and data in Settings. Update the app.
- **Slow performance:** Close unused apps. Clear cache. Restart the device regularly.

If you encounter persistent issues, consider performing a factory reset (backup your data first) or contact realme customer support for assistance.

6. Specifications

Feature	Detail
Brand	realme
Model	14T
CPU Model	MediaTek Dimensity 6300
CPU Speed	2.4 GHz
Internal Storage	256 GB
Display Size	6.67 Inches
Display Resolution	2400 x 1080
Refresh Rate	120 Hz
Cellular Technology	5G
Connectivity Technology	Wi-Fi
Color	Black

Feature	Detail
Processor Type	MediaTek Dimensity 6300
Processor Speed	2.4 GHz
Data Storage Capacity	256 GB
Number of SIM Card Slots	Dual SIM
Form Factor	Bar
Biometric Identification	Facial Recognition
SIM Card Format	Nano
Water Resistance Level	Waterproof (IP69, IP68, IP66)
Headphone Jack	No 3.5mm Jack
Front Camera Resolution	16 MP
Rear Camera Resolution	50 MP
Number of Rear Cameras	2
Number of Front Cameras	1
Item Dimensions	16.3 x 7.6 x 0.8 cm
Video Capture Resolution	4K
Frame Rate	120 fps
Display Pixel Density	1556.5 Pixels per Inch (PPI)
Country of Origin	China
Specific Product Uses	Gaming, Outdoor Activities, Intensive Use

7. Warranty and Support

realme stands by the quality of its products. Your realme 14T 5G Smartphone comes with a **one-year warranty** from the date of purchase, covering manufacturing defects.



One-Year Warranty

realme adheres to strict quality standards. We are committed to providing high-quality goods and services for a worry-free purchase experience.



Customer Support

Quick response within 24 hours

Free returns and exchanges within 30 days

1-year after-sales support

For any questions or support needs, please do not hesitate to contact realme customer service. We aim to respond within 224 hours.

© 2026 realme. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0F1DBF5CR

More documents and user manuals: **https://manuals.plus/**