

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Ninja](#) /

› [Ninja Outdoor Side Table and Grill Stand Instruction Manual - Model XSKUNSTANDTBL](#)

## Ninja XSKUNSTANDTBL

# Ninja Outdoor Side Table and Grill Stand Instruction Manual

Model: XSKUNSTANDTBL

Brand: Ninja

## INTRODUCTION

Thank you for choosing the Ninja Outdoor Side Table and Grill Stand. This manual provides essential information for the safe and efficient use of your new product. Please read all instructions carefully before assembly and operation.

### Key Features:

- **Adjustable Height:** Customize the stand to your preferred cooking height.
- **Integrated Side Table:** Provides convenient extra space for food preparation and utensils.
- **Weather Resistant:** Durable construction designed for outdoor use.
- **Compatibility:** Specifically designed for Ninja Woodfire Collection OG700, OG751, OG850, OG901, and OO101 Series grills and ovens.
- **Portable Design:** Easy to fold and transport for camping, tailgating, or backyard use.

## SETUP AND ASSEMBLY

Follow these steps to assemble your Ninja Outdoor Side Table and Grill Stand. A screwdriver and hex key are included for assembly.

### Included Components:

- 1 Ninja Woodfire Universal Adjustable Stand
- 1 Side Table
- 4 Stand Legs
- 14 Hex Screws
- 1 Hex Key

## Assembly Steps:

### 1. Step 1: Attach the Table Legs

Securely attach the four stand legs to the main frame using the provided hex screws. Ensure all connections are tight for stability.



*Image: The adjustable stand with a Ninja Woodfire grill, demonstrating its sturdy and functional design.*

### 2. Step 2: Adjust Leg Height

The legs feature multiple adjustment points. Loosen the knob, press the latch at the bottom, and pull out the table leg to your desired height. Lock the latch securely once adjusted.

Your browser does not support the video tag.

*Video: Demonstrates the assembly process, including attaching legs and adjusting height.*

### 3. Step 3: Install Side Table and Hooks

Attach the side table to the main unit. The stand also includes integrated hooks for hanging cooking utensils or a garbage bag for convenience.



*Image: The attachable side table provides additional space for food preparation.*

### 4. Step 4: Secure Grill/Oven

Place your compatible Ninja Woodfire grill or oven securely onto the stand. The stand is designed to keep your appliance firmly in place during use.



## NINJA WOODFIRE ACCESSORIES

Ninja Woodfire™ Accessories were made to do one thing and one thing only—to take your outdoor cooking to the next level.

*Image: Multiple Ninja Woodfire grills on their stands, showcasing the complete outdoor cooking setup.*

## OPERATION

The Ninja Outdoor Side Table and Grill Stand is designed for ease of use and versatility in your outdoor cooking setup.

- **Placement:** Position the stand on a stable, level surface away from flammable materials.
- **Grill Stability:** The stand's design ensures your Ninja Woodfire grill or oven remains stable during operation.
- **Heat Ventilation:** The main surface of the stand features a vented design to prevent excessive heat transfer to the table surface, protecting both the stand and your appliance.
- **Accessory Hooks:** Utilize the integrated hooks to keep your cooking tools, such as spatulas and tongs, within easy reach.
- **Side Tables:** Extend the side tables for additional workspace, perfect for holding ingredients, plates, or other cooking essentials.

Your browser does not support the video tag.

*Video: Highlights the adjustable height and stability of the stand, suitable for various outdoor cooking appliances.*

## MAINTENANCE

Proper maintenance will ensure the longevity and continued performance of your grill stand.

- **Cleaning:** Wipe down all surfaces with a damp cloth and mild soap after each use. The plastic top is easy to clean. Avoid abrasive cleaners that may damage the finish.
- **Storage:** The stand is designed to be portable and foldable. For long-term storage or during inclement weather, fold the stand and store it in a dry, protected area.
- **Weather Resistance:** While weather-resistant, prolonged exposure to extreme conditions may affect its lifespan. Consider using a protective cover when not in use.



Image: A Ninja grill protected by a weather-resistant cover, illustrating proper storage.

## TROUBLESHOOTING

If you encounter any issues with your Ninja Outdoor Side Table and Grill Stand, refer to the following common solutions:

- **Instability:** Ensure all leg adjustment latches are securely locked and screws are tightened. Verify the stand is on a flat, stable surface.
- **Difficulty Folding/Unfolding:** Check for any obstructions or debris in the folding mechanisms. Ensure all latches are disengaged before folding.
- **Missing Parts:** Refer to the "Included Components" list. If any parts are missing, contact Ninja customer support.

## SPECIFICATIONS

Feature	Detail
Model Number	XSKUNSTANDTBL
Brand	Ninja
Material	Metal (frame), Plastic (top, side tables)
Color	Black
Product Dimensions (L x W x H)	15.24 x 7.48 x 23.27 inches (folded)
Item Weight	3.48 pounds
Special Feature	Heavy Duty, Adjustable Height, Foldable, Wheels
Assembly Required	Yes
Compatibility	Ninja Woodfire Collection OG700, OG751, OG850, OG901, OO101 Series

## WARRANTY AND SUPPORT

---

For warranty information, product registration, or technical support, please visit the official Ninja website or contact their customer service department. Keep your purchase receipt for warranty claims.

**Online Support:** [www.ninjakitchen.com](http://www.ninjakitchen.com)