

NEXTIME 3328WI

NEXTIME Twitter Cuckoo Wall Clock with Pendulum User Manual

Model: 3328WI

1. INTRODUCTION

This manual provides instructions for the setup, operation, and maintenance of your NEXTIME Twitter Cuckoo Wall Clock with Pendulum. This clock combines a classic cuckoo clock design with modern features, offering a unique timekeeping experience.

Key features include an hourly chirping bird, a gently swinging pendulum, and silent clock movement (no ticking sound). The clock also offers options to disable the chirping sound during nighttime hours or permanently.





Image 1: Front view of the NEXTIME Twitter Cuckoo Wall Clock in White, showing the clock face, birdhouse, and pendulum.

2. WHAT'S IN THE BOX

- NEXTIME Twitter Cuckoo Wall Clock unit
- Pendulum
- Instruction Manual (this document)

Note: 3 AA batteries are required for operation and are not included.

3. SETUP INSTRUCTIONS

1. Install Batteries:

Locate the battery compartment on the back of the clock. Insert 3 AA batteries, ensuring correct polarity (+/-). Close the battery compartment cover securely.





Image 2: Rear view of the clock, highlighting the battery compartment and control switches.

2. Attach Pendulum:

Carefully attach the pendulum to the hook located at the bottom of the clock unit. Ensure it swings freely.

3. Set Time:

Use the time-setting knob or wheel (usually located on the back or side of the clock mechanism) to set the correct time. Rotate the hands clockwise until the desired time is displayed. The cuckoo mechanism will synchronize automatically after the first full hour cycle.

4. Mounting the Clock:

The clock is designed for wall mounting. Use a suitable wall anchor and screw (not included) to securely hang the clock from the keyhole slot on its back. Ensure the clock is level for optimal pendulum operation.

4. OPERATING INSTRUCTIONS

4.1 Hourly Chime (Cuckoo Sound)

The NEXTIME Twitter Cuckoo Wall Clock features an hourly chirping sound, where a bird emerges from its house to announce the hour. This mechanism is designed to operate silently between 10:00 PM and 7:00 AM to prevent disturbance during sleep.



Image 3: Close-up view of the cuckoo bird in its birdhouse, ready to chime.

4.2 Disabling the Chime

The clock offers options to manage the hourly chime:

- **Nighttime Silence:** The chime is automatically disabled between 10:00 PM and 7:00 AM. No manual adjustment is needed for this feature.
- **Permanent Silence:** To permanently disable the chirping sound, locate the ON/OFF switch on the back of the clock (refer to Image 2). Slide the switch to the "OFF" position.

4.3 Silent Motion

The clock features a silent movement mechanism, meaning there is no audible ticking sound during its operation, only the hourly chime (if enabled).

5. MAINTENANCE

- **Cleaning:** Wipe the clock surface with a soft, dry cloth. Avoid using abrasive cleaners or solvents, as these may damage the finish.
- **Battery Replacement:** Replace all 3 AA batteries when the clock hands slow down or the cuckoo mechanism stops functioning correctly. Always replace all batteries at the same time with new ones.
- **Placement:** Avoid placing the clock in direct sunlight or near extreme temperature changes, which can affect its accuracy and material integrity.

6. TROUBLESHOOTING

Problem	Possible Cause	Solution
Clock not running or hands stopped.	Dead or incorrectly installed batteries.	Replace all 3 AA batteries with new ones, ensuring correct polarity.
Cuckoo chime not working.	<ul style="list-style-type: none">• Batteries low.• Chime switch is OFF.• Time is between 10 PM and 7 AM (nighttime silence).	<ul style="list-style-type: none">• Replace batteries.• Ensure chime switch on the back is set to ON.• Wait until after 7 AM for the chime to resume.
Pendulum not swinging.	Pendulum not properly attached or obstructed.	Ensure the pendulum is securely attached and has clearance to swing freely. Check if the clock is level.
Incorrect time display.	Time not set correctly or batteries low.	Reset the time using the setting knob. Replace batteries if necessary.

7. SPECIFICATIONS

Brand: NEXTIME
Model Number: 3328WI
Display Type: Analog
Style: Modern Cuckoo
Special Feature: Hourly Chime (with nighttime silence), Silent Motion
Product Dimensions: 8.46"W x 11.6"H (Clock body, excluding pendulum)
Power Source: Battery Powered (3 AA batteries required, not included)
Material: Plastic
Mounting Type: Wall Mount
Item Weight: Approximately 0.705 ounces (excluding batteries)










Image 4: Diagram showing the dimensions of the NEXTIME Twitter Cuckoo Wall Clock.

8. WARRANTY AND SUPPORT

This NEXTIME product comes with a limited warranty. For specific warranty details, claims, or technical support, please refer to the manufacturer's official website or contact your retailer.

You can find more information about NEXTIME products by visiting the [NEXTIME Store on Amazon](#).



	<p>NeXtime PWAR3534 Digital Wall Clock User Manual and Setup Guide</p> <p>Comprehensive guide for the NeXtime PWAR3534 Digital Wall Clock, covering power supply, operation, time setting, 12/24hr format, and wall mounting instructions.</p>
	<p>NeXtime PWAR0001 Wall Clock User Manual and Instructions</p> <p>Comprehensive user manual for the NeXtime PWAR0001 wall clock, covering setup, operation, care, troubleshooting, and warranty information. Includes multilingual instructions.</p>
	<p>NeXtime PWAR0001 Clock User Manual: Operation, Care, and Warranty</p> <p>Get detailed instructions for your NeXtime PWAR0001 clock. This manual covers battery installation, time setting, maintenance, troubleshooting, special features like glow-in-the-dark, and warranty information.</p>
	<p>Nextime Clock: How to Set Time and Time Zone</p> <p>A concise guide to setting the time and date on your Nextime clock, including instructions for battery installation, time zone selection, and mode adjustments.</p>
	<p>NEXTIME Lumi Floor Lamp Stand PWARLP4002 Assembly Manual</p> <p>Step-by-step assembly instructions for the NEXTIME Lumi Floor Lamp Stand (Model PWARLP4002), including safety notices and warranty information.</p>
	<p>NeXtime 2024 Clock Collection: Timeless Elegance and Modern Design</p> <p>Explore the NeXtime 2024 Clock Collection, featuring a diverse range of stylish and functional timepieces. From retro digital clocks and minimalist Vasco designs to unique cuckoo and glass art clocks, find the perfect statement piece for your home.</p>