Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- > STRICH /
- > STRICH Piano Keyboard Stand and Piano Bench User Manual

STRICH SKT-02S

STRICH Piano Keyboard Stand and Piano Bench User Manual

Model: SKT-02S

1. Introduction

This manual provides comprehensive instructions for the assembly, operation, and maintenance of your STRICH Piano Keyboard Stand (Model SKT-02S) and accompanying Piano Bench. Please read this manual thoroughly before use to ensure proper setup and safe operation. Keep this manual for future reference.



Image 1.1: The STRICH Piano Keyboard Stand and Piano Bench set.

This image displays the complete STRICH Piano Keyboard Stand and Piano Bench package, showcasing both components in their assembled form.

2. SAFETY INFORMATION

- Ensure all components are securely fastened before placing any instrument on the stand or sitting on the bench.
- Do not exceed the maximum weight capacity of 250 lbs (113 kg) for the keyboard stand.
- Keep hands and fingers clear of moving parts during adjustment to prevent pinching.
- Place the stand and bench on a stable, level surface to prevent tipping.
- Regularly inspect the stand and bench for any signs of wear, damage, or loose components.

3. PACKAGE CONTENTS

Please verify that all the following items are included in your package:

- STRICH SKT-02S Piano Keyboard Stand frame
- STRICH Piano Bench components (seat, backrest, legs)
- 4 x Adjustable Keyboard Clamps
- 2 x Safety Straps
- · Set of Adjustable Leveling Feet
- · Set of Lockable Caster Wheels
- Assembly Hardware (screws, washers, tools if applicable)
- User Manual (this document)

4. SETUP INSTRUCTIONS

4.1. Keyboard Stand Assembly (SKT-02S)

- 1. Unpack all components of the keyboard stand.
- 2. Extend the main frame of the stand to its desired width. Use the pull-type knobs to secure the width adjustment.
- 3. Attach either the adjustable leveling feet or the lockable caster wheels to the base of the stand, depending on your preference for mobility or stationary use. Ensure they are tightened securely.
- 4. Adjust the height of the stand using the pull-type knobs on the vertical supports. Ensure both sides are set to the same height for stability.
- 5. Install the 4 adjustable keyboard clamps onto the top support bars of the stand. These clamps will help secure your keyboard.
- 6. Attach the 2 safety straps to the stand and prepare them for securing your keyboard.



Image 4.1: Keyboard stand demonstrating adjustable width and height.

This image shows the STRICH SKT-02S keyboard stand with adjustable width (22.1-35 inches) and height (23.2-33.4 inches), illustrating its adaptability for various keyboard sizes.



Image 4.2: Keyboard stand foot pad options.

A close-up image illustrating the two types of foot pads for the keyboard stand: lockable caster wheels for mobility and adjustable leveling feet for stability on uneven surfaces.

4.2. Piano Bench Assembly

- 1. Unpack all piano bench components.
- 2. Attach the bench legs to the seat frame using the provided hardware. Ensure all screws are tightened firmly.
- 3. Insert the backrest support into the designated slot on the bench seat. Secure it with the knob adjustment.
- 4. Adjust the height of the bench and the position of the backrest to your preferred settings.



Image 4.3: Piano bench dimensions.

This diagram shows the dimensions of the STRICH Piano Bench, including seat width (14.6 inches), seat depth (11.8 inches), and overall height range (18.1-21.3 inches).

5. OPERATING INSTRUCTIONS

5.1. Adjusting the Keyboard Stand

- **Height Adjustment:** To adjust the stand's height, loosen the pull-type knobs on the vertical supports. Raise or lower the top section to the desired height, then firmly tighten the knobs to lock it in place.
- Width Adjustment: To adjust the stand's width, loosen the pull-type knobs on the horizontal support bar. Slide the two halves of the stand closer or further apart to match your keyboard's width, then firmly

tighten the knobs.

- Securing the Keyboard: Place your keyboard on the stand. Adjust the 4 keyboard clamps to firmly grip the sides of your instrument. Use the 2 safety straps to further secure the keyboard to the stand, ensuring it cannot accidentally slide off.
- **Using Caster Wheels:** If you have installed the caster wheels, unlock them to move the stand. Lock the wheels when the stand is in its desired position to prevent unintended movement.




Image 5.1: Pull-type knob for stand adjustment.

This detailed image demonstrates the pull-type knob mechanism used to quickly adjust the height and length of the keyboard stand.

- Bench Height Adjustment: The piano bench offers four precise height levels, ranging from 18 to 21 inches. To adjust, lift the seat and reposition it to the desired height, ensuring it clicks securely into place.
- **Backrest Adjustment:** The backrest can be adjusted for both height and distance from the seat. Loosen the side knobs, position the backrest for optimal support, and then tighten the knobs firmly.



Image 5.2: Piano bench adjustable height feature.

This image illustrates the adjustable height feature of the STRICH Piano Bench, showing the minimum (18.1 inches) and maximum (21.2 inches) height settings.



Image 5.3: Piano bench backrest adjustment.

This image demonstrates the height adjustment of the piano bench's backrest, showing the range of vertical adjustment (1.7-4.1 inches) and horizontal adjustment (14.5-17.5 inches).

6. MAINTENANCE

- Cleaning: Wipe down the stand and bench with a soft, damp cloth. Avoid abrasive cleaners or solvents that could damage the finish.
- **Inspection:** Periodically check all bolts, screws, and adjustment knobs to ensure they are tight. Retighten if necessary.
- Storage: When not in use for extended periods, store the stand and bench in a dry, cool place away

7. TROUBLESHOOTING

- **Stand Instability:** Ensure all adjustment knobs are fully tightened. Verify that the stand is placed on a flat, level surface. If using leveling feet, adjust them to compensate for uneven floors.
- **Difficulty Adjusting Height/Width:** Loosen the pull-type knobs completely before attempting to adjust. Ensure no debris is obstructing the sliding mechanisms.
- **Keyboard Sliding:** Confirm that the 4 adjustable keyboard clamps are properly positioned and tightened against your instrument. Ensure the 2 safety straps are securely fastened.
- Bench Wobbling: Check that all leg attachment screws are tight. Ensure the bench is on a level surface.

8. SPECIFICATIONS

8.1. STRICH SKT-02S Keyboard Stand

- Material: Precision-engineered iron metal with thickened coating
- Tube Diameter: 1.4 inches
- Maximum Weight Capacity: 250 lbs (113 kg)
- Adjustable Width Range: 21.7 35 inches (55 89 cm)
- Adjustable Height Range: 23.6 36.6 inches (60 93 cm) (including wheels/foot pads)
- Compatibility: Suitable for 54, 61, and 88-key electric pianos or keyboards



Image 8.1: Keyboard stand weight capacity.

This image highlights the robust construction of the STRICH SKT-02S keyboard stand, emphasizing its 250 lb weight capacity.

8.2. STRICH Piano Bench

- Adjustable Height Range: 18 21 inches (46 54 cm) with four precise levels
- Backrest: Adjustable for support and relaxation
- Seat Dimensions: Approximately 14.6 inches (37 cm) width, 11.8 inches (30 cm) depth
- Padding: High-quality padding for comfort
- Feet: Non-slip rubber mats



Image 8.2: Piano bench detailed features.

A detailed view of the STRICH Piano Bench, highlighting its high-quality padding, knob adjustment for the backrest, and non-slip rubber mats on the feet.

9. WARRANTY AND SUPPORT

STRICH products are manufactured to high-quality standards. For warranty information, technical support, or assistance with parts, please refer to the contact information provided at the point of purchase or visit the official STRICH website. Please retain your proof of purchase for warranty claims.

Related Documents - SKT-02S



STRICH SMT-10 Guitar Rack Installation Guide - Assemble Your Multi-Guitar Stand

Step-by-step installation guide for the STRICH SMT-10 Guitar Rack. Learn how to assemble this wooden multi-guitar stand for electric and acoustic guitars, including parts list and important notes.



STRICH SMT-20 Guitar Rack Installation Guide

Step-by-step instructions for assembling the STRICH SMT-20 Guitar Rack, including parts list and important notes for proper installation.



STRICH Keyboard Stand Installation Guide

A concise installation guide for the STRICH Keyboard Stand, detailing parts included and step-by-step assembly instructions.



STRICH SDP-120 Multi-function 88 Keys Electronic Keyboard User Manual

This user manual provides comprehensive instructions for operating the STRICH SDP-120 multifunction 88 keys electronic keyboard. It covers Bluetooth connection, troubleshooting, function introduction, demo songs, rhythms, chords, recording, effect changes, dynamic control, split function, drum function, MP3 function, and detailed button descriptions.



STRICH SPS-30 MAX User Manual: Guitar Pedal Power Supply

User manual for the STRICH SPS-30 MAX guitar pedal power supply. Provides instructions on operation, connection, safety, and accessories for this isolated pedalboard power solution.



STRICH BT-N2C Wireless Music Pedal User Manual

User manual for the STRICH BT-N2C Wireless Music Pedal, detailing its functions, specifications, charging, maintenance, and connectivity.