

# Roomba 105 Combo Robot Vacuum Instruction Manual

Model: Y311260

## INTRODUCTION

---

The Roomba 105 Combo is designed to simplify your daily cleaning routine. This robot vacuum and mop offers powerful suction, intelligent navigation, and convenient app control to keep your floors spotless with minimal effort.

It features a 4-stage cleaning system, including powerful suction, multi-surface brushes, edge-cleaning brush, and a microfiber mop pad for comprehensive cleaning.



Image: The Roomba 105 Combo robot vacuum and mop, shown with its accompanying smartphone application.

## SETUP

### 1. Unboxing and Placement

Carefully remove all components from the packaging. Place the Home Base charging station against a wall in an open, uncluttered area, ensuring at least 0.5 meters (1.5 feet) of clear space on either side and 1.2 meters (4 feet) in front.

### 2. Initial Charge

Place your Roomba 105 Combo onto the Home Base. The robot will automatically begin charging. For optimal battery life, ensure the robot is fully charged before its first cleaning cycle. A full charge typically takes a few hours.

3  
WAYS

## 好みに合わせてコントロール



Image: The Roomba 105 Combo robot vacuum returning to its charging station.

### 3. Connecting to the iRobot Home App

Download the iRobot Home App from your device's app store. Follow the in-app instructions to connect your Roomba 105 Combo to your home Wi-Fi network (2.4 GHz required). The app allows for advanced features such as:

- Creating and customizing cleaning schedules.
- Viewing cleaning history and maps generated by ClearView™ LiDAR navigation.
- Adjusting cleaning preferences (suction power, water level for mopping).
- Setting Keep Out Zones to restrict access to certain areas.
- Receiving maintenance alerts.



Image: A screenshot of the iRobot Home app displaying options for setting cleaning schedules.

## OPERATING THE ROOMBA 105 COMBO

### Cleaning Modes

The Roomba 105 Combo offers versatile cleaning options:

- **Vacuum Only:** For dry debris and general floor cleaning.
- **Mop Only:** For wet cleaning hard floors.
- **Vacuum & Mop Simultaneously:** For a comprehensive clean in one pass.

You can select your preferred cleaning method via the iRobot Home App.




Image: A visual representation of the Roomba 105 Combo's ability to vacuum, mop, or perform both functions simultaneously.

### Smart Scrub Feature



For tougher messes, activate the Smart Scrub feature. This mode provides a more powerful scrubbing action, offering up to 2 times the cleaning power compared to standard mopping, effectively tackling stains like coffee spills.



スマートスクラブで拭き取り力が2倍に\*



\*IEC規格に基づき、コーヒーの汚れに対してスマートスクラブを使用時。標準の水拭きモードとの比較。

Image: The Roomba 105 Combo demonstrating its Smart Scrub feature on a hard floor, indicated by water trails.

### Carpet Detection

The robot is equipped with automatic carpet detection. When mopping, it will intelligently avoid carpets and rugs to prevent them from getting wet, ensuring safe and effective cleaning on hard floors.



## ClearView™ LiDAR

お部屋のマップをすばやく作成。




Image: The Roomba 105 Combo robot vacuum detecting and avoiding a carpet while in mopping mode.

### Customizing Cleaning

Through the iRobot Home App, you can customize various cleaning settings:

- **Suction Power:** Choose from multiple levels of suction to suit different floor types and debris.
- **Water Level:** Adjust the amount of water dispensed onto the mop pad for optimal mopping results.
- **Targeted Cleaning:** Direct the robot to clean specific rooms or areas, or perform spot cleaning for concentrated messes.

### Control Methods

You can control your Roomba 105 Combo using three convenient methods:

- **iRobot Home App:** Full control over all features and settings.
- **Voice Assistant:** Integrate with compatible voice assistants like Alexa, Siri, or Google Assistant for hands-free commands.
- **Robot Button:** Press the CLEAN button on the robot for a quick start/stop of a cleaning cycle.



最大70倍強力になったパワーリフト吸引\*  
でゴミやホコリを一掃



\*フル充電でスポット清掃時、国内累計出荷台数トップの  
Roomba® 600シリーズとの比較。(2025年2月時点)

Image: Visual representation of the three control methods for the Roomba 105 Combo: voice commands, the iRobot Home app, and the physical button on the robot.

## MAINTENANCE

### Dustbin and Filter

Regularly empty the dustbin after each cleaning cycle. The filter should also be cleaned periodically by tapping it against a trash can to remove debris. Replace the filter every few months or as indicated by the app for optimal performance.

### Brushes

The Roomba 105 Combo features multi-surface rubber brushes that are designed to minimize hair tangles, making them easier to clean. Periodically remove the brushes and clear any accumulated hair or debris. The edge-cleaning brush should also be checked and cleaned.



## 手間いらずでゴミを一掃



掃除機がけ、  
水拭き掃除、  
その両方



最大70倍パワー  
アップした吸引力\*

\* Roomba® 600シリーズとの比較



素早くスマートに  
マッピング



水拭き掃除中に  
カーペットを  
検知して回避



スマート充電&再開



4段階の吸引力と  
3段階の水拭き  
掃除用水分量

Image: An underside view of the Roomba 105 Combo, highlighting its main brushes and microfiber mop pad.

### Mop Pad

The microfiber mop pad is washable and reusable. After each mopping session, remove the pad and wash it thoroughly with water. Allow it to air dry completely before reattaching to prevent odors and maintain cleaning effectiveness.

### Sensors and Charging Contacts

Wipe the robot's sensors and charging contacts with a clean, dry cloth regularly to ensure proper navigation and charging.

## TROUBLESHOOTING

### Common Issues and Solutions

- **Robot not charging:** Ensure the Home Base is plugged in and the robot's charging contacts are clean



and properly aligned with the base.

- **Robot getting stuck:** Clear obstacles from the cleaning path. The ClearView™ LiDAR navigation helps the robot avoid obstacles, but some small items or loose cords may still cause issues.
- **Poor cleaning performance:** Check the dustbin, brushes, and filter for clogs or excessive debris. Ensure the mop pad is clean and wet for mopping.
- **App connectivity issues:** Verify your Wi-Fi network is 2.4 GHz and stable. Restart the robot and your router if necessary.
- **Error messages:** Refer to the iRobot Home App for specific error codes and troubleshooting steps.

For persistent issues, consult the iRobot Home App's help section or visit the iRobot support website.

## SPECIFICATIONS

Feature	Detail
Manufacturer	iRobot
Model Number	Y311260
Package Dimensions	45 x 37 x 17 cm
Color	White
Item Weight	Approx. 4.9 kg
Special Features	Vacuum & Mop simultaneously, Dirt Detect Sensor, Smart Mapping, Edge Cleaning, LiDAR Navigation
Power Source	Battery Powered
Lithium Battery Pack	Battery built-in
ASIN	B0F1FDVCBK

## WARRANTY AND SUPPORT

For products sold and shipped by Amazon.co.jp, manufacturer support is available. For products sold by other sellers, please contact the respective seller for support and warranty information.

iRobot is committed to customer privacy and employs high-level data encryption technology to ensure the privacy and security of your data.

# すっきり清潔な スマートホーム

お持ちの音声アシスタント\*と  
連携させると、音声で家中の  
掃除を指示できます。



\*Alexa, Siri, Googleアシスタント対応デバイスと連携。Alexaおよびすべての関連ロゴはAmazon.comまたはその関連会社の商標です。GoogleおよびGoogle Homeは、Google LLCの登録商標です。Siriは米国および他の国々で登録されたApple Inc.の登録商標です。

Image: A graphic emphasizing iRobot's reliable customer service and data privacy commitment.



## OFFICIAL PRODUCT VIDEO





Your browser does not support the video tag.

Video: An official product video demonstrating the Roomba 105 Combo's features and cleaning capabilities. This video highlights its powerful suction, intelligent navigation, and mopping function.

© 2025 iRobot Corporation. All rights reserved. Roomba is a registered trademark of iRobot Corporation.

## Related Documents - Y311260

	<a href="#">Instrukcja obsługi robota iRobot Roomba 105 Vac Combo ze stacją dokującą Auto Empty</a> Instrukcja obsługi robota sprzątającego iRobot Roomba 105 Vac Combo z funkcją odkurzania i mopowania oraz stacją dokującą Auto Empty. Dowiedz się o konfiguracji, obsłudze, konserwacji i rozwiązywaniu problemów.
	<a href="#">Roomba 105 Vac Combo Robot + AutoEmpty Dock Owner's Guide</a> This guide provides instructions for setting up, operating, and maintaining the iRobot Roomba 105 Vac Combo robot with AutoEmpty dock. Learn about charging, cleaning patterns, troubleshooting, and care for your robot and dock.

 <p>Roomba® 105 AutoEmpty™ Dock iRobot</p>	<p><a href="#">iRobot Roomba 105 Combo Robot Vacuum with AutoEmpty Dock User Manual</a></p> <p>Comprehensive user manual for the iRobot Roomba 105 Combo robot vacuum cleaner, detailing setup, operation, maintenance, and troubleshooting for the AutoEmpty Dock. Includes part identification and care instructions.</p>
 <p>Roomba® Combo 10 Max iRobot</p>	<p><a href="#">Roomba Combo 10 Max Robot Vacuum &amp; Mop User Manual</a></p> <p>Comprehensive user guide for the iRobot Roomba Combo 10 Max robot vacuum and mop with AutoWash™ base, covering setup, operation, maintenance, troubleshooting, and safety information.</p>
 <p>Roomba® Plus 405 AutoWash™ Dock iRobot</p>	<p><a href="#">iRobot Roomba Combo 405+ AutoWash Dock User Manual</a></p> <p>Comprehensive user manual for the iRobot Roomba Combo 405+ with AutoWash Dock, covering setup, operation, cleaning, maintenance, and troubleshooting.</p>
 <p>Roomba® 105 AutoEmpty™ Dock iRobot</p>	<p><a href="#">Roomba® 105 Robot Aspirateur et Laveur Combo avec AutoEmpty™ Dock   iRobot</a></p> <p>Découvrez le Roomba® 105, un robot aspirateur et laveur intelligent d'iRobot. Doté de la navigation LIDAR, 7000 Pa d'aspiration, SmartScrub, et la base AutoEmpty™ pour un entretien simplifié. Contrôle via application et commandes vocales.</p>