



[Manuals.plus](#) /

> [FIXR](#) /

> FIXR PG01, PG50, PG50 Plus Replacement Hose User Manual

FIXR PG01, PG50, PG50 Plus

FIXR PG01, PG50, PG50 Plus Replacement Hose User Manual

INTRODUCTION

This manual provides instructions for the proper installation, operation, and maintenance of your FIXR PG01, PG50, or PG50 Plus Replacement Hose. Please read this manual thoroughly before use to ensure safe and efficient operation.

SAFETY INFORMATION

Always ensure the pet grooming vacuum kit is unplugged before installing or removing the hose. Keep the hose away from sharp objects and extreme heat sources. Do not use the hose if it is damaged or kinked, as this may affect performance or cause injury.

PACKAGE CONTENTS

- 1 x FIXR PG01, PG50, or PG50 Plus Replacement Hose

Note: The pet grooming vacuum kit and other accessories are sold separately.

SETUP

1. **Unpack the Hose:** Carefully remove the replacement hose from its packaging. Inspect it for any signs of damage.
2. **Prepare the Grooming Kit:** Ensure your FIXR PG01, PG50, or PG50 Plus pet grooming vacuum kit is turned off and unplugged from the power source.
3. **Remove Old Hose (if applicable):** If replacing an existing hose, gently twist and pull to detach it from the vacuum unit and any attachments.
4. **Attach New Hose to Vacuum Unit:** Align the connector end of the new replacement hose with the intake port on your FIXR grooming vacuum unit. Push firmly and twist clockwise until it is securely locked in place.
5. **Attach Accessories:** Connect your desired grooming tools (e.g., brush, nozzle) to the other end of the hose by

pushing and twisting until secure.



Image: The FIXR replacement hose securely attached to the main vacuum unit of a pet grooming kit. This image illustrates the connection point for the hose to the vacuum.

OPERATING INSTRUCTIONS

Once the hose is securely attached and all accessories are in place, you can begin using your pet grooming vacuum kit. Ensure the hose is not kinked or obstructed during operation to maintain optimal suction.

- **Power On:** Plug in the grooming vacuum kit and turn on the power switch.
- **Grooming:** Use the attached grooming tools as per the instructions for your specific FIXR grooming kit model.
- **Monitor Hose:** Periodically check the hose for any blockages or kinks that might reduce suction or cause damage.
- **Power Off:** After use, turn off the grooming vacuum kit and unplug it from the power source.

MAINTENANCE

- **Cleaning:** After each use, detach the hose and gently shake out any trapped pet hair or debris. If necessary, wipe the exterior of the hose with a damp cloth. Do not immerse the hose in water.
- **Storage:** Store the hose in a clean, dry place, away from direct sunlight and extreme temperatures. Avoid kinking or bending the hose sharply during storage to prevent damage.
- **Inspection:** Regularly inspect the hose for cracks, tears, or blockages. Replace the hose if any significant damage is observed.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Reduced Suction	Hose is kinked or blocked.	Straighten the hose. Detach and check for blockages, then clear them.
Hose Detaches Easily	Hose not securely attached.	Ensure the hose is firmly pushed and twisted into place on both the vacuum unit and accessories.
Visible Damage to Hose	Wear and tear or accidental damage.	Discontinue use and replace the hose with a new FIXR replacement hose.

SPECIFICATIONS

Model Compatibility: FIXR PG01, PG50, PG50 Plus Pet Grooming Vacuum Kits

Material: Silicone

Color: White

Length: Approximately 117 inches (297 cm)

Item Weight: 12.7 ounces (360 grams)

Manufacturer: FIXR

CUSTOMER SUPPORT

For further assistance, questions, or to report issues, please contact FIXR customer support. Refer to your original product packaging or the FIXR website for contact details.

Website: [Visit the FIXR Store on Amazon](#)

