

TOKIT 1.5 L Mini Rice Cooker with Vacuum Sealer

TOKIT 1.5L Mini Rice Cooker and Vacuum Sealer Instruction Manual

1. INTRODUCTION

Thank you for choosing the TOKIT 1.5L Mini Rice Cooker and Vacuum Sealer. This versatile appliance is designed to simplify your cooking and food preservation needs. Please read this manual thoroughly before use to ensure safe and efficient operation. Keep this manual for future reference.

2. SAFETY INSTRUCTIONS

- Always ensure the appliance is unplugged before cleaning or when not in use.
- Do not immerse the main unit of either appliance in water or other liquids.
- Keep out of reach of children.
- Do not operate if the power cord or plug is damaged. Contact customer support for assistance.
- Use only accessories recommended by the manufacturer.
- Avoid touching hot surfaces. Use handles or oven mitts.
- Ensure proper ventilation during operation.

3. PACKAGE CONTENTS

Verify that all items are present in your package:

- TOKIT 1.5L Mini Rice Cooker
- TOKIT Vacuum Sealer
- Inner Cooking Pot (for rice cooker)
- Rice Measuring Cup
- Rice Serving Spatula
- Power Cords (for both appliances)

- Instruction Manual (this document)

4. PRODUCT OVERVIEW

4.1 TOKIT 1.5L Mini Rice Cooker




The TOKIT Mini Rice Cooker shown with its inner pot, rice measuring cup, and serving spatula, illustrating the included accessories for convenient use.

The TOKIT Mini Rice Cooker features a compact design with a touch-button display. It includes a removable non-stick inner pot for easy cleaning. The appliance offers multiple cooking functions and a keep-warm feature.

4.2 TOKIT Vacuum Sealer

4 Modes Simple Operation Meet Your Various Needs



The TOKIT Vacuum Sealer in operation, sealing fresh meat and surrounded by various vegetables, showcasing its food preservation capabilities.

The TOKIT Vacuum Sealer is designed for efficient food preservation, featuring one-touch operation and multiple sealing modes for various food types. Its compact and portable design makes it suitable for any kitchen or travel.

5. SETUP

5.1 Initial Setup (Rice Cooker)

1. Unpack all components and remove any packaging materials.
2. Wash the inner cooking pot, measuring cup, and spatula with warm, soapy water. Rinse thoroughly and dry.
3. Wipe the exterior of the rice cooker with a damp cloth.
4. Place the rice cooker on a stable, flat, heat-resistant surface.
5. Ensure the power cord is securely plugged into the appliance and a suitable power outlet.

5.2 Initial Setup (Vacuum Sealer)

1. Unpack the vacuum sealer and remove any protective films.
2. Wipe the exterior with a damp cloth.
3. Place the vacuum sealer on a stable, flat surface.
4. Plug the power cord into a suitable power outlet.

6. OPERATING THE RICE COOKER

6.1 Basic Rice Cooking

1. Using the provided measuring cup, measure the desired amount of rice.
2. Rinse the rice thoroughly under cold water until the water runs clear.

3. Place the rinsed rice into the inner cooking pot.
4. Add water according to the markings inside the inner pot. For example, for 2 cups of rice, fill water up to the '2' mark.
5. Insert the inner pot into the rice cooker.
6. Close the lid securely.
7. Press the 'Select' button to choose your desired cooking function (e.g., White Rice, Quick Cook, Brown Rice). The display will show the estimated cooking time.
8. Press the 'Start' button to begin cooking. The display will show a countdown.
9. Once cooking is complete, the rice cooker will automatically switch to 'Keep Warm' mode.
10. Allow the rice to rest for 5-10 minutes in 'Keep Warm' mode before serving for best results.
11. Use the provided spatula to fluff and serve the rice.



The TOKIT Mini Rice Cooker with a prepared meal, demonstrating its capacity to serve individual portions directly from the cooking pot.

6.2 Using Other Cooking Functions



A close-up of the TOKIT Mini Rice Cooker's control panel, displaying various cooking modes such as White Rice, Quick Cook, Brown Rice, Congee, Soup, Hot Pot, Steam, and Warm.

The TOKIT Rice Cooker offers 8 versatile cooking functions:

- **White Rice:** Standard cooking for white rice.
- **Quick Cook:** Faster cooking cycle for white rice.
- **Brown Rice:** Optimized for cooking brown rice.
- **Congee:** For preparing porridge or congee.
- **Stew Soup:** Ideal for stews and soups.
- **Hot Pot:** Use for hot pot dishes.
- **Steaming:** For steaming vegetables or other foods (requires a steaming basket, not included).
- **Keep Warm:** Automatically activates after cooking to maintain food temperature.

To select a function, press the 'Select' button repeatedly until the desired function is highlighted on the display. Then press 'Start'.

7. OPERATING THE VACUUM SEALER

7.1 Sealing Food

1. Place the food inside a vacuum sealer bag, ensuring the open end is clean and dry.
2. Open the lid of the vacuum sealer.
3. Place the open end of the bag into the vacuum channel.
4. Close the lid firmly until it clicks into place.
5. Select the appropriate mode (Dry or Moist) based on your food type.
6. Press the 'Vacuum & Seal' button. The machine will automatically remove air and then seal the bag.
7. Once the process is complete, the indicator light will turn off. Open the lid and remove the sealed bag.

Why Choose TOKIT Sealer?

⌚ Save Time 💰 Save Money

		
	TOKIT	Other Brands
Vacuum Sealing Time	15-25S	over30S
Sustained Performance	Sustained Sealing 50 times	No more than 30 times
Safe Design	Overheat Protection & Cooling System	Overheatingn Causing Machine Damage

An illustration of the TOKIT Vacuum Sealer's four operation modes: Dry, Moist, Manual, and Seal, explaining their functions for different food types.

7.2 External Vacuum System

External Vacuum System

Designed to work with any vacuum-friendly container





Vacuum Jars



Wine Plugs



Storage Bags

The TOKIT Vacuum Sealer demonstrating its external vacuum system, compatible with vacuum jars, wine stoppers, and storage bags for versatile preservation.

The vacuum sealer can also be used with external accessories like vacuum canisters, jars, and wine stoppers (sold separately).

1. Connect one end of the accessory hose (not included) to the external vacuum port on the sealer.
2. Connect the other end to the port on your vacuum container or wine stopper.

3. Press the 'External Vacuum' button (if available) or 'Vacuum & Seal' button. The machine will remove air from the container.
4. Once complete, disconnect the hose.



A visual representation of the TOKIT Vacuum Sealer's powerful 65Kpa suction, illustrating its efficiency in quickly and tightly sealing food.

8. MAINTENANCE AND CLEANING

8.1 Rice Cooker Cleaning

1. Always unplug the rice cooker and allow it to cool completely before cleaning.
2. Remove the inner cooking pot and wash it with warm, soapy water. It is non-stick and can be easily cleaned.
3. Wipe the interior of the main unit with a damp cloth. Do not use abrasive cleaners.
4. Clean the lid and steam vent regularly to prevent blockages.
5. Ensure all parts are completely dry before reassembling or storing.

8.2 Vacuum Sealer Cleaning

1. Unplug the vacuum sealer before cleaning.
2. Wipe down the sealing strip and vacuum channel with a damp cloth to remove any food residue.
3. Clean the exterior with a soft, damp cloth.
4. Ensure all surfaces are dry before storing.

9. TROUBLESHOOTING

9.1 Rice Cooker Issues

Problem	Possible Cause	Solution
Rice is too hard/dry	Insufficient water; lid not sealed properly	Add more water next time; ensure lid is closed tightly.
Rice is too soft/mushy	Too much water	Reduce water amount next time; follow water level markings.
Cooker does not turn on	Not plugged in; power outage	Check power connection; verify power supply.

9.2 Vacuum Sealer Issues

Problem	Possible Cause	Solution
Bag not sealing properly	Bag not positioned correctly; sealing strip dirty; bag is wet	Reposition bag; clean sealing strip; ensure bag opening is dry.
No vacuum created	Lid not closed; vacuum channel blocked	Ensure lid is firmly closed; clear any obstructions from vacuum channel.

10. SPECIFICATIONS

Feature	Detail
Product Name	TOKIT 1.5L Mini Rice Cooker with Vacuum Sealer
Model Number	B0F1FL2542
Rice Cooker Capacity	1.5 Liters
Rice Cooker Functions	White Rice, Quick Cook, Brown Rice, Congee, Stew Soup, Hot Pot, Steaming, Keep Warm
Vacuum Sealer Modes	Dry, Moist, Pulse, Seal, External Vacuum
Vacuum Sealer Suction	65Kpa
Date First Available	March 14, 2025

11. WARRANTY AND SUPPORT

TOKIT products come with a standard manufacturer's warranty. For specific warranty details, please refer to the warranty card included in your product packaging or visit the official TOKIT website. If you encounter any issues or require technical assistance, please contact TOKIT customer support through the following channels:

- **Email:** support@tokit.com (example)
- **Phone:** 1-800-XXX-XXXX (example)

- **Website:** [TOKIT Official Store on Amazon](#)

Please have your model number (B0F1FL2542) and purchase date ready when contacting support.