

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Ciays](#) /
- › [Ciays 43-Inch Rectangular Propane Fire Pit User Manual](#)

Ciays CIFPT52B-43-US

Ciays 43-Inch Rectangular Propane Fire Pit User Manual

Model: CIFPT52B-43-US

Brand: Ciays

INTRODUCTION

This manual provides essential information for the safe operation, assembly, maintenance, and troubleshooting of your Ciays 43-Inch Rectangular Propane Fire Pit. Please read this manual thoroughly before assembly or operation to ensure proper use and to prevent personal injury or property damage.



Image: The Ciays 43-inch rectangular propane fire pit with flames, showcasing its design and functionality.

IMPORTANT SAFETY INFORMATION

WARNING: For outdoor use only. Improper installation, adjustment, alteration, service, or maintenance can cause injury or property damage. Read the installation, operating, and maintenance instructions thoroughly before installing or servicing this equipment.

- Always maintain proper clearance from combustible materials.
- Do not store or use gasoline or other flammable vapors and liquids in the vicinity of this or any other appliance.
- A propane cylinder not connected for use shall not be stored in the vicinity of this or any other appliance.
- Ensure adequate ventilation when operating.
- Keep children and pets away from the fire pit during operation.
- Do not use the fire pit in windy conditions.
- This appliance is CSA-certified for safety and reliability.

KEY FEATURES

- **Powerful 60,000 BTU Heating:** Efficient warmth for outdoor use, featuring a durable 304 stainless steel H-burner for consistent heating.
- **Extra 3-Inch Table Edge:** Provides ample space for drinks, snacks, and other items, enhancing functionality.

- **Stylish and Practical Design:** Includes decorative rocks and a premium texture that blends with patio decor.
- **2-in-1 Fire Pit Table:** Easily transforms into a standard table with the included protective cover, offering versatility.
- **Infinite Flame Adjustment & Adjustable Feet:** Stepless adjustment knob for precise flame control and adjustable feet for stability on uneven surfaces.



Image: Visual representation of the fire pit's key features, including its 60,000 BTU output, storage mesh bag, and CSA certification.

SPECIFICATIONS

Attribute	Value
Brand	Ciays
Model Number	CIFPT52B-43-US
Product Dimensions	43"D x 25"W x 25"H

Material	Alloy Steel
Finish Type	Lacquered
Shape	Rectangular
Item Weight	52 Pounds
Fuel Type	Liquefied Petroleum Gas
Color	Black
BTU Output	60,000 BTU
Certification	CSA Certified



Image: The fire pit with key dimensions highlighted, showing its overall size.

PACKAGE CONTENTS

Please verify that all parts are present before beginning assembly.

- Ciays 43-Inch Rectangular Propane Fire Pit Table
- Protective Cover
- Decorative Lava Rocks
- 304 Stainless Steel H-Burner (pre-installed)
- Instruction Manual

Removable Lid with Hook



Includes Lava Rocks



Adjustable Feet

Image: Details of the fire pit's components, including the removable lid, lava rocks, and adjustable feet.

SETUP INSTRUCTIONS

1. **Unpacking:** Carefully remove all components from the packaging. Retain packaging for future storage or transport if needed.

2. **Placement:** Position the fire pit on a hard, level, non-combustible surface. Ensure there is adequate clearance from combustible materials (e.g., walls, furniture, trees).
3. **Adjust Feet:** Use the adjustable feet at the base of the fire pit to ensure it is stable and level on uneven patios or lawns.
4. **Propane Tank Connection:**
 - Open the access door on the side of the fire pit.
 - Place a standard 20 lb propane tank (not included) inside the designated compartment.
 - Connect the regulator hose from the fire pit to the propane tank valve. Hand-tighten securely.
 - Check all connections for leaks using a soapy water solution before first use.
5. **Lava Rock Placement:** Carefully distribute the decorative lava rocks evenly over the burner assembly. Do not block the igniter or burner ports.



Image: The fire pit in an outdoor setting, demonstrating its use for gatherings and providing warmth.

OPERATING INSTRUCTIONS

1. **Before Lighting:** Ensure the control knob is in the "OFF" position. Open the valve on the propane tank slowly.
2. **Lighting the Fire Pit:**
 - Push and turn the control knob counter-clockwise to the "LOW" position.
 - Press and hold the igniter button for 5-10 seconds until the burner ignites.
 - If ignition does not occur within 15 seconds, turn the control knob to "OFF", wait 5 minutes, and repeat the lighting procedure.
3. **Adjusting Flame:** Once lit, rotate the control knob between "LOW" and "HIGH" to adjust the flame height to your desired level.
4. **Shutting Down:**
 - Turn the control knob clockwise to the "OFF" position.
 - Close the valve on the propane tank.
 - Allow the fire pit to cool completely before covering or moving.



Image: The stepless adjustment switch, allowing users to precisely control the flame height.

MAINTENANCE

- **Cleaning:** Regularly wipe down the exterior surfaces with a soft, damp cloth. Do not use abrasive cleaners.
- **Burner Maintenance:** Keep the burner and lava rocks free from debris. Use a soft brush to clean the burner ports if necessary.
- **Protective Cover:** Use the included protective cover when the fire pit is not in use to shield it from weather elements and dust. This also allows it to function as a regular table.
- **Storage:** When storing the fire pit for extended periods, disconnect the propane tank and store it in a well-ventilated area outdoors. Cover the fire pit and store it in a cool, dry place.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Burner will not light	No gas flow Igniter not sparking Low propane tank pressure	Check propane tank valve is open. Ensure hose is securely connected. Check igniter electrode for proper gap. Replace or refill propane tank.
Low flame or irregular flame	Low propane tank pressure Burner ports clogged Excess flow safety device activated	Replace or refill propane tank. Clean burner ports. Turn off fire pit and propane tank, wait 5 minutes, then restart slowly.
Flame goes out during use	Low propane tank pressure Strong winds	Replace or refill propane tank. Relocate fire pit to a sheltered area.

WARRANTY AND SUPPORT

For warranty information or technical support, please contact Ciays customer service. Refer to your purchase documentation for specific warranty terms and contact details.

You can also visit the official Ciays store for more information: [Ciays Store](#)

© 2024 Ciays. All rights reserved.
For assistance, please contact customer support.

Related Documents - CIFPT52B-43-US

 <p>NUU GARDEN INSTRUCTION MANUAL 43\" Gas Fire Pit Table With Cover And Wind Guard AF225C-G</p>	<p>NUU GARDEN 43\" Gas Fire Pit Table AF225C-G: Assembly, Operation & Maintenance Manual Comprehensive instruction manual for the NUU GARDEN 43\" Gas Fire Pit Table (Model AF225C-G). Includes assembly steps, safety warnings, operation guide, maintenance tips, and troubleshooting for your outdoor fire pit.</p>
---	--

<p>Fire Pit Table User Manual CIFPT10B Rev01</p>  	<p>Fire Pit Table CIFPT10B User Manual</p> <p>User manual for the CIFPT10B Fire Pit Table, providing safety information, assembly instructions, operation guidelines, maintenance tips, and troubleshooting for this propane-powered outdoor appliance.</p>
<p>Fire Pit Table User Manual CIFPT11B Rev01</p>  	<p>CIFPT11B Fire Pit Table User Manual: Assembly, Operation, and Safety Guide</p> <p>Comprehensive user manual for the CIFPT11B Fire Pit Table. Includes safety information, assembly instructions, operation guidelines, maintenance tips, and troubleshooting for your outdoor gas appliance.</p>
<p>Fire Pit Table User Manual CIFPT3 Rev02.1 A</p>  	<p>Ciays CIFPT3 Fire Pit Table User Manual</p> <p>User manual for the Ciays CIFPT3 Fire Pit Table, covering safety information, assembly instructions, gas cylinder installation, operation, maintenance, and troubleshooting.</p>
<p>TOSHIBA</p>  <p>43UH55 US8 43UH55 US8 43UH55 US8 43UH50S16S US8 43UH50S16S US8 49S5 US8</p> <p>OPERATING INSTRUCTIONS</p>	<p>Toshiba TV Operating Instructions: Model Guide</p> <p>Comprehensive operating instructions and user guide for Toshiba TVs, covering setup, features, connectivity, troubleshooting, and more.</p>
<p>TOSHIBA</p>  <p>32UH LA2B Series 32UH LA3B Series 24UH31 WA2B Series 24UH31 WA3B Series</p> <p>QUICK START GUIDE KURZANLEITUNG GUIDE DE MISE EN MARCHÉ RAPIDE GUIDA RAPIDA ALL'AVVIO PŘÍRUČKA PRO RYCHLÝ START PŘÍRUČKA PRE RYCHLÝ START</p> <p>Please visit www.toshiba.eu to download the full user manual.</p>	<p>Toshiba Television Quick Start Guide: Setup and Basic Operation</p> <p>Get started quickly with your new Toshiba TV. This guide covers initial setup, connections, remote control, and accessing the full user start manual for models like the LA2B, LA3B, WA2B, and WA3B series.</p>

