

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [MOTPK](#) /

› [MOTPK L Shaped Gaming Desk 43 Inch User Manual - Assembly, Features, and Care](#)

MOTPK L Shaped Gaming Desk 43 Inch

MOTPK L Shaped Gaming Desk 43 Inch User Manual

Model: L Shaped Gaming Desk 43 Inch | Brand: MOTPK

INTRODUCTION

Thank you for choosing the MOTPK L Shaped Gaming Desk. This manual provides detailed instructions for assembly, operation, maintenance, and troubleshooting to ensure optimal use and longevity of your desk. Please read this manual thoroughly before beginning assembly or use.

SAFETY INFORMATION

- Ensure all parts are present and undamaged before assembly. Do not use if any parts are missing or broken.
- Assemble the desk on a soft, clean surface to prevent scratches.
- Tighten all screws and bolts securely, but do not overtighten.
- Keep small parts away from children during assembly.
- Do not stand or sit on the desk.
- Distribute weight evenly across the desk surface.
- Ensure the power outlet is connected to a grounded electrical source. Do not overload the power strip.

PACKAGE CONTENTS

Before assembly, please verify that all components listed below are included in your package. If any parts are missing or damaged, contact customer support.

- Desk Panels (Main, Side, Shelf)
- Metal Frame Components
- 4 Fabric Drawers
- LED Light Strip with Controller
- Recessed Power Outlet (3 AC, 2 USB)
- Grid Pegboard and Headphone Hook
- Adjustable Foot Pads

- Assembly Hardware (screws, bolts, tools)



Image: The MOTPK L Shaped Gaming Desk, showcasing its overall design and integrated features like the LED light, power outlet, and storage drawers. This image represents the complete product package.

ASSEMBLY INSTRUCTIONS

Follow these steps carefully. It is recommended to have two people for assembly. Refer to the included diagram for part identification.

- 1. Step 1: Prepare the Area.** Clear a spacious, flat area for assembly. Lay out all parts and hardware, ensuring they match the package contents list.
- 2. Step 2: Assemble the Main Desk Frame.** Connect the main desk legs and support bars using the provided screws. Do not fully tighten screws until all components are aligned.
- 3. Step 3: Attach Main Desk Panel.** Secure the main desk panel to the assembled frame.
- 4. Step 4: Assemble the Side Desk Frame.** Connect the side desk legs and support bars. Decide whether to configure the L-shape to the left or right side of the main desk.
- 5. Step 5: Attach Side Desk Panel.** Secure the side desk panel to its frame.

6. **Step 6: Connect Main and Side Desks.** Join the main and side desk sections using the designated connectors. Ensure proper alignment for the desired L-shape configuration.
7. **Step 7: Install Storage Unit.** Assemble the frame for the storage unit and insert the fabric drawers. Attach the storage unit to the desk frame.
8. **Step 8: Install Top Shelf and Pegboard.** Mount the top shelf and grid pegboard onto the designated frame sections.
9. **Step 9: Install LED Light Strip.** Adhere the LED light strip to the underside of the top shelf or desired location. Connect the controller.
10. **Step 10: Install Power Outlet.** Recess the power outlet into the pre-drilled slot on the desk surface. Secure it with screws.
11. **Step 11: Attach Headphone Hook.** Secure the headphone hook to the side of the desk.
12. **Step 12: Final Tightening and Adjustment.** Once all parts are in place and aligned, fully tighten all screws. Attach the adjustable foot pads to the bottom of the desk legs and adjust for stability.



Image: A detailed diagram illustrating the dimensions of the MOTPK L Shaped Gaming Desk and its various components, including the top shelf, drawers, and main desk sections. This image is useful for understanding the structure during assembly.

FEATURES OVERVIEW

Reversible L-Shape Design

The L-shaped configuration of this desk is reversible, allowing you to position the longer or shorter section to either the left or right side to best fit your room layout and personal preference. This flexibility maximizes space utilization.

4 Fabric Storage Drawers

Keeping your desktop neat and tidy



Image: This visual demonstrates the reversible nature of the MOTPK L Shaped Gaming Desk, showing how the side section can be configured on either the left or right to adapt to different room layouts.

Integrated Power Outlet

The desk includes a built-in power strip with 3 standard AC outlets (125V/12A) and 2 USB charging ports (5V/2A). This feature provides convenient access to power for your electronic devices, reducing cable clutter.

Recessed power Strip



 **3 AC Outlets**
125V/12A

 **2 USB Ports**
5V/2A

Image: A close-up view of the recessed power strip integrated into the desk surface, highlighting the three AC outlets and two USB charging ports for convenient device power.

LED Light Strip

Enhance your gaming or work environment with the included LED light strip. It offers 10 static colors, 10 dynamic modes, and 6 brightness levels, all controllable via a memory function and switching controls. This allows for customizable ambiance and reduced eye strain.

Responsive Mobile Design

Customize your setup with flexible installation options



Image: This image displays the LED light strip installed on the desk's top shelf, illustrating its various color options and dynamic modes, which can be adjusted to create different lighting effects.

Ample Storage Solutions

The desk is equipped with four fabric drawers, a grid pegboard, an open shelf, and a headphone hook. These features provide extensive storage for gaming accessories, office supplies, and personal items, helping to keep your workspace organized and clutter-free.



Image: A detailed view of the four fabric storage drawers, demonstrating their capacity and smooth sliding mechanism, designed for organizing various items.

Adjustable Foot Pads

The desk features adjustable foot pads on each leg. These pads allow you to level the desk on uneven floors, ensuring stability and preventing wobbling.



Image: A close-up shot of the adjustable foot pads located at the base of the desk legs, illustrating their design for leveling the desk on uneven surfaces.

OPERATING INSTRUCTIONS

Using the LED Light Strip

- **Power On/Off:** Press the power button on the LED controller to turn the lights on or off.
- **Change Color:** Use the color selection buttons on the controller to cycle through 10 static color options.
- **Change Mode:** Select from 10 dynamic modes (e.g., flash, fade, strobe) using the mode button.
- **Adjust Brightness:** Use the brightness up/down buttons to select from 6 brightness levels. The memory function will recall your last setting.

Using the Power Outlets

- **Connect to Wall Outlet:** Plug the desk's power cord into a standard, grounded 120V AC wall outlet.
- **AC Devices:** Insert your device's power plug into one of the three AC outlets.
- **USB Devices:** Connect your USB charging cable to one of the two USB ports to charge compatible devices.
- **Overload Protection:** The power strip includes surge protection. If it trips, unplug devices, wait a moment, and then reset the power strip if applicable.

MAINTENANCE AND CARE

- **Cleaning:** Wipe the desk surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners that may

damage the finish.

- **Dusting:** Regularly dust the desk and LED strip to maintain appearance and functionality.
- **Hardware Check:** Periodically check all screws and bolts to ensure they remain tight. Retighten if necessary.
- **Avoid Excessive Weight:** Do not place excessively heavy items on the desk or shelves to prevent structural damage.
- **Liquid Spills:** Clean up any liquid spills immediately to prevent damage to the desk material or electrical components.

TROUBLESHOOTING

Issue	Possible Cause	Solution
Desk is wobbly/unstable.	Uneven floor; loose screws.	Adjust the foot pads until the desk is level. Tighten all assembly screws.
LED light strip not working.	Loose connection; power issue; faulty strip.	Check that the LED strip is securely connected to the controller and power source. Ensure the power outlet is functional. If issues persist, contact support.
Power outlets not providing power.	Desk power cord unplugged; wall outlet issue; tripped surge protector.	Ensure the desk's power cord is fully plugged into a working wall outlet. Test the wall outlet with another device. Check if the power strip's surge protector button needs to be reset.
Drawers do not slide smoothly.	Improper installation; obstruction.	Ensure the fabric drawers are correctly inserted and not overloaded. Check for any obstructions in the drawer slides.

SPECIFICATIONS


Feature	Detail
Brand	MOTPK
Model	L Shaped Gaming Desk 43 Inch
Product Dimensions (D x W x H)	43.31" x 31.5" x 30"
Color	Carbon Fiber Pink
Style	Modern
Base Material	Alloy Steel
Top Material Type	Engineered Wood
Finish Type	Powder Coated
Special Feature	Reversible
Item Weight	41.6 Pounds
Assembly Required	Yes

Feature	Detail
UPC	850071099546

WARRANTY AND SUPPORT

MOTPK products are designed for quality and durability. For specific warranty information, please refer to the documentation included with your purchase or visit the official MOTPK website. If you encounter any issues or require assistance, please contact MOTPK customer support. You can also visit the [MOTPK Store on Amazon](#) for more information.


Related Documents - L Shaped Gaming Desk 43 Inch

	<p>MOTPK L-Shaped Gaming Desk User Manual Comprehensive user manual for the MOTPK L-Shaped Gaming Desk, detailing pre-installation, assembly instructions, parts list, customer service information, and troubleshooting.</p>
	<p>MOTPK Gaming Desk User Manual and Assembly Guide Comprehensive user manual and assembly guide for the MOTPK Gaming Desk, featuring step-by-step instructions, parts list, troubleshooting, and customer service information.</p>
	<p>Unikito L-Shaped Desk Assembly Guide Comprehensive guide for assembling the Unikito L-Shaped Desk with USB charging port and power outlet. Includes parts list, assembly steps, and tips for efficient installation.</p>
	<p>Wrought Studio L-Shaped Desk User Manual User manual for the Wrought Studio L-Shaped Desk, providing assembly instructions, safety guidelines, parts list, and customer service details for this reversible computer and gaming desk.</p>



[Inbox Zero L-Shaped Desk User Manual and Assembly Guide](#)

Comprehensive user manual and assembly guide for the Inbox Zero L-Shaped Desk, featuring detailed instructions, parts list, safety precautions, and troubleshooting tips for home office setup.



[Wrought Studio EHCM1441 L-Shaped Computer Desk Assembly Instructions](#)

Comprehensive assembly instructions for the Wrought Studio EHCM1441 L-shaped computer desk. This guide provides a detailed parts list, hardware inventory, and step-by-step instructions to help you assemble your new home office desk with drawers, LED lights, power outlet, and monitor stand.