



[Manuals.plus](#) /

› [LOUVIXA](#) /

› LOUVIXA 6-Drawer Dresser with LED Lights and Charging Station - Instruction Manual

LOUVIXA 17-XTSLCG

LOUVIXA 6-Drawer Dresser with LED Lights and Charging Station - Instruction Manual

INTRODUCTION

This manual provides detailed instructions for the assembly, operation, and maintenance of your LOUVIXA 6-Drawer Dresser. Designed for versatility, this dresser features six spacious drawers, integrated LED lighting, and a convenient charging station. Please read these instructions carefully before beginning assembly or use to ensure safe and proper operation.



Image: Front view of the LOUVIXA 6-Drawer Dresser.

Large Storage Space

You can efficiently store your clothes, toys, ornaments and other items with 6 large drawers



Image: Overview of the dresser's large storage capacity.

SAFETY INFORMATION

To prevent injury and ensure stability, it is crucial to follow all safety guidelines. This dresser is equipped with an anti-tipping design. Proper installation of the anti-tipping device is mandatory to secure the unit to a wall, especially in households with children or pets.

Anti-tipping Design

For your safety, be sure to install anti-tipping devices correctly





Image: Illustration of the anti-tipping design, demonstrating the importance of securing the dresser to the wall to prevent accidents.

- Always install the provided anti-tipping device.
- Do not allow children to climb on drawers or the dresser.
- Ensure the dresser is placed on a flat, stable surface.
- Distribute weight evenly within drawers to maintain balance.
- Keep liquids away from the charging station to prevent electrical hazards.

PACKAGE CONTENTS

Before assembly, verify that all components are present and undamaged. Refer to the included parts list in your packaging. If any parts are missing or damaged, please contact customer support.

- Dresser panels and hardware
- Six (6) drawer units
- LED light strip and remote control
- Charging station unit (2 AC outlets, 1 USB, 1 Type-C)

- Metal handles and legs
- Anti-tipping device
- Assembly instructions

SETUP AND ASSEMBLY

Assembly of the LOUVIXA 6-Drawer Dresser is designed to be straightforward with labeled components and detailed instructions. It is recommended to have at least two people for assembly.

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a clean, soft surface to prevent scratches.
2. **Identify Parts:** Match each component with the labeled diagrams in the separate assembly guide.
3. **Assemble Frame:** Follow the step-by-step instructions to construct the main frame of the dresser.
4. **Install Drawers:** Assemble the six drawers and install them into the dresser frame. Ensure smooth operation of the drawer slides.
5. **Attach Legs and Handles:** Secure the five sturdy metal legs and the stylish metal handles to the drawers.
6. **Install LED Lights:** Adhere the LED light strip to the designated area on the dresser. Connect it to the power source as instructed.
7. **Integrate Charging Station:** Install the charging station into its dedicated slot. Ensure all connections are secure.
8. **Secure Anti-Tipping Device:** This is a critical step. Attach the anti-tipping device to the back of the dresser and secure it firmly to a wall stud using appropriate hardware.

For detailed visual guidance, refer to the separate assembly manual included in your package.

OPERATING INSTRUCTIONS

LED Lighting System

The integrated RGB LED lighting system can be controlled via the included remote control to create various atmospheres.

LED 6 Drawer Dresser



Image: The dresser with its LED lights active, alongside the remote control for adjusting settings.

- **Power On/Off:** Press the **Power** button on the remote to turn the lights on or off.
- **Color Selection:** Use the color buttons to select a static color. The remote offers 20+ color options.
- **Brightness Adjustment:** Use the **Brightness Up/Down** buttons to increase or decrease light intensity.
- **Speed Adjustment:** For dynamic modes, use the **Speed Up/Down** buttons to control the transition speed.
- **Rhythm Modes:** Select from various **Rhythm** modes for dynamic light patterns.
- **Timing Function:** Utilize the **Timing** button to set a timer for the lights to automatically turn off.

Built-in Charging Station

The dresser includes a built-in charging station for convenient power access.



Built-in Charging Station



125V/12A
2 AC Outlets



5V /2A
1 USB Port



5V /2A
1 Type-C Port

Image: The charging station with its two AC outlets, USB port, and Type-C port in use.

- **AC Outlets:** Two (2) 125V/12A AC outlets are provided for standard electrical devices.
- **USB Port:** One (1) 5V/2A USB port is available for charging compatible devices.
- **Type-C Port:** One (1) 5V/2A Type-C port is available for charging compatible devices.
- **Usage:** Simply plug your devices into the appropriate ports. Ensure the dresser is connected to a power source for the charging station to function.

MAINTENANCE

Proper care will extend the life and appearance of your LOUVIXA dresser.

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners that may damage the engineered wood finish.
- **Spills:** Immediately wipe up any spills to prevent moisture damage.
- **Drawer Slides:** Periodically check drawer slides for smooth operation. If needed, a silicone-based lubricant can be applied sparingly.

- **Hardware:** Occasionally check and tighten all screws and fasteners to ensure stability.
- **LED Lights:** The LED strip is designed for long-term use. If issues arise, refer to the troubleshooting section.

TROUBLESHOOTING

Problem	Possible Cause	Solution
LED lights not turning on.	<ul style="list-style-type: none"> ◦ Power cable disconnected. ◦ Remote control battery depleted. ◦ LED strip connection loose. 	<ul style="list-style-type: none"> ◦ Ensure power cable is securely plugged into an outlet and the dresser. ◦ Replace remote control battery. ◦ Check the connection between the LED strip and its power adapter.
Charging station not working.	<ul style="list-style-type: none"> ◦ Dresser not plugged into wall outlet. ◦ Device cable faulty. ◦ Overload protection activated. 	<ul style="list-style-type: none"> ◦ Verify the dresser's main power cord is connected to a live wall outlet. ◦ Try a different charging cable for your device. ◦ Unplug all devices, wait a few minutes, then plug them back in one by one.
Drawers are stiff or not closing properly.	<ul style="list-style-type: none"> ◦ Drawer slides misaligned. ◦ Obstruction in the drawer path. ◦ Overloaded drawer. 	<ul style="list-style-type: none"> ◦ Ensure drawers are correctly seated on their slides. ◦ Check for items blocking the drawer's movement. ◦ Reduce the weight or volume of items in the drawer.

SPECIFICATIONS



Product Size

Image: Detailed dimensions of the dresser and its drawers.

Feature	Detail
Brand	LOUVIXA
Model Number	17-XTSLCG
Material	Engineered Wood
Overall Dimensions (L x W x H)	119.89 cm x 34.8 cm x 99.82 cm (47.2" x 13.7" x 39.3")
Drawer Dimensions (L x W x H)	52.07 cm x 28.45 cm x 11.94 cm (20.5" x 11.2" x 4.7")
Number of Drawers	6
Weight	36.42 kg (80.29 lbs)

Feature	Detail
Special Features	LED Lighting, Built-in Charging Station (2 AC, 1 USB, 1 Type-C), Anti-tipping Design

WARRANTY AND SUPPORT

For information regarding product warranty, please refer to the documentation provided at the time of purchase or contact your retailer. LOUVIXA is committed to customer satisfaction. If you have any questions, require assistance with assembly, or encounter any issues with your dresser, please contact LOUVIXA customer support through the retailer's platform or the official brand website.

Please have your model number (**17-XTSLCG**) and purchase details ready when contacting support.