



Manuals.plus /

› UREVO /

› UREVO Smart Treadmill User Manual

UREVO URTM036

UREVO Smart Treadmill User Manual

MODEL: URTM036

1. Introduction and Overview

The UREVO Smart Treadmill is designed to provide a versatile and efficient workout experience for your home or office. Featuring both running and walking modes, an adjustable auto-incline, and smart connectivity via the UREVO App, this treadmill offers a comprehensive solution for various fitness levels and goals. Its compact design and user-friendly features make it an ideal choice for maximizing your workout space and routine.




Figure 1: UREVO Smart Treadmill in a home setting, showcasing its compact design and integrated app features.

2. Safety Information


Prioritize your safety by adhering to the following guidelines:

- Always read the entire user manual before operating the treadmill.
- Ensure the safety key is properly attached to both the treadmill and your clothing before starting any workout.
- Keep children and pets away from the treadmill during operation.
- Wear appropriate athletic footwear.
- Do not step on the belt until it has started moving at a slow speed.
- If you feel dizzy, nauseous, or experience any pain, stop your workout immediately.
- Regularly inspect the treadmill for any signs of wear or damage.

AI-POWERED WELLNESS APP



Personalized Plans for Your Workout, Health and Goals.



The **UREVO APP** contains an ever-growing library of training, both on and off your devices. Wherever you are, you'll always have the full UREVO APP experience along with massage relaxation, weight management, and live workouts.

Simply download the UREVO APP onto your mobile device!



Figure 2: Ergonomic handrails provide stability and support during workouts, enhancing user safety.

3. Setup

The UREVO Smart Treadmill requires minimal assembly, arriving largely pre-assembled for your convenience.

3.1 Unpacking and Placement

- Carefully remove the treadmill from its packaging.

- Place the treadmill on a flat, stable surface with adequate clearance around it.

3.2 Folding and Unfolding

The treadmill features a convenient folding design for easy storage.

- To unfold: Gently lift the handle until it locks into the upright position. Ensure all locking mechanisms are secure before use.
- To fold: Follow the instructions in the user manual to release the handle and carefully lower it to the flat position.

Your browser does not support the video tag.

Video 1: Demonstrates the folding and unfolding process of the UREVO Smart 3-in-1 Folding Treadmill for convenient storage.



Figure 3: Comparison of the UREVO treadmill in its folded state, highlighting its space-saving design.

4. Operating Instructions

The UREVO Smart Treadmill offers various modes and controls for a customized workout.

4.1 Power On/Off

- Connect the power cord to a grounded outlet.
- Flip the main power switch located at the front of the treadmill.
- Attach the safety key to the designated slot on the console.

4.2 Basic Operation (Speed & Incline)

- Use the remote control or console buttons to start/pause the treadmill.
- Adjust speed: The walking speed ranges from 0.6-4.0 mph, and running speed from 0.6-7.6 mph. Use the '+' and '-' buttons to adjust.
- Adjust incline: The treadmill features a 9% adjustable auto-incline. Use the incline buttons on the remote or app to change the gradient.



Figure 4: The treadmill's display shows current speed, incline, and available HIIT training programs.

4.3 UREVO App Connectivity

Connect your treadmill to the UREVO App for enhanced features:

- Download the UREVO App from your device's app store.
- Pair your device via Bluetooth.
- Access virtual city experiences, challenge modes, and track your workout data.



Figure 5: The UREVO App provides real-time workout data, scenic routes, and interactive challenges.

Your browser does not support the video tag.

Video 2: Overview of the UREVO Smart Treadmill's features, including its auto-incline and app integration.

5. Maintenance

Regular maintenance ensures the longevity and optimal performance of your treadmill.

5.1 Cleaning

- Wipe down the treadmill with a damp cloth after each use.
- Avoid using abrasive cleaners or solvents.

5.2 Belt Lubrication

The running belt requires periodic lubrication to reduce friction and wear. Refer to the detailed instructions in the included User Manual (PDF) for proper lubrication procedures and frequency.

5.3 Belt Adjustment

If the running belt becomes misaligned or slips, it may need adjustment. Consult the detailed instructions in the included User Manual (PDF) for proper belt centering and tensioning procedures.

6. Troubleshooting

If you encounter issues with your treadmill, try the following basic troubleshooting steps:

- **No Power:** Ensure the power cord is securely plugged into a working outlet and the main power switch is on. Check the safety key is correctly inserted.
- **Belt Not Moving:** Verify the safety key is in place and the treadmill is not in pause mode.
- **Unusual Noises:** Check for any loose parts or foreign objects under the belt. Refer to the lubrication section if the noise is a squeak or grinding sound.

For more detailed troubleshooting steps and solutions, please refer to the comprehensive guide in the User Manual (PDF) provided with your product.

7. Specifications

Feature	Specification
Brand	UREVO
Model Number	URTM036
Product Dimensions (LxWxH)	54.72"D x 25.37"W x 6.67"H
Item Weight	39 Kilograms
Material	Alloy Steel (Frame: Aluminum)
Maximum Speed	7.6 Miles per Hour
Minimum Speed	0.6 Miles per Hour
Maximum Incline Percentage	9.0%
Maximum Horsepower	2.5 Horsepower
Maximum Weight Recommendation	265 Pounds
Number of Programs	6
Display Type	LED
Connectivity Technology	Power Cord (App via Bluetooth)

8. Warranty and Support

8.1 Warranty Information

The UREVO Smart Treadmill comes with a 1-year warranty from the date of purchase, covering manufacturing defects. Please retain your proof of purchase for warranty claims.

8.2 Returns Policy

This product is eligible for 30-day easy returns. Refer to your retailer's return policy for full details.

8.3 Customer Support

For any questions, technical assistance, or warranty claims, please contact UREVO Customer Support. Contact information can be found on the product packaging or the official UREVO website.