

AEG TO63IQ0BIB

AEG TO63IQ0BIB 60cm Induction Hob User Manual

Model: TO63IQ0BIB

1. INTRODUCTION

This manual provides essential information for the safe and efficient use of your new AEG TO63IQ0BIB 60cm Induction Hob. Please read these instructions carefully before installation and use, and keep them for future reference. This induction hob features three cooking zones, including a flexible bridge function, PowerBoost, a pause function, and the Hob2Hood system for automatic ventilation control.



This image displays the top view of the AEG TO63IQ0BIB induction hob. It features a sleek black frameless glass ceramic surface. On the left, two rectangular cooking zones are visible, designed for the FlexiPowder bridge function. On the right, a larger, circular cooking zone is present. Below the cooking zones, the touch control panel is visible, showing power level indicators, a timer display, and various function icons including PowerBoost and Pause.

2. SAFETY INFORMATION

Always prioritize safety when operating electrical appliances. Failure to follow these instructions may result in electric shock, fire, or injury.

- **Electrical Connection:** Ensure the hob is correctly installed by a qualified electrician in accordance with local regulations. The power supply must match the specifications of the appliance.
- **Hot Surfaces:** Although induction hobs heat cookware directly, the hob surface can become hot from residual heat. Avoid touching hot surfaces.
- **Suitable Cookware:** Use only ferromagnetic cookware suitable for induction cooking. Non-induction cookware will not heat.
- **Children and Pets:** Keep children and pets away from the appliance during operation and when it is cooling down.
- **Cleaning:** Disconnect the appliance from the power supply before cleaning. Do not use abrasive cleaners or steam cleaners.
- **Ventilation:** Ensure adequate ventilation around the appliance as specified in the installation instructions.

3. SETUP AND INSTALLATION

The AEG TO63IQ0BIB induction hob is designed for flush-mounted installation. Professional installation is highly recommended to ensure proper electrical connection and fit.

3.1 Unpacking

Carefully remove the hob from its packaging. Inspect for any damage during transit. Retain packaging materials for potential future transport or service.

3.2 Placement

The hob must be installed into a countertop opening that meets the specified dimensions. Ensure sufficient clearance for ventilation beneath the appliance.

3.3 Electrical Connection

This appliance requires a dedicated electrical circuit. The electrical connection must be performed by a qualified technician, adhering to all local electrical codes and regulations. Refer to the wiring diagram provided with the appliance for specific connection details.

4. OPERATING INSTRUCTIONS

Familiarize yourself with the touch control panel for efficient operation of your induction hob.

4.1 Power On/Off

- To turn on: Touch the main power symbol.
- To turn off: Touch and hold the main power symbol until the display turns off.

4.2 Selecting a Cooking Zone and Adjusting Power

- Place suitable cookware on the desired cooking zone.
- Touch the control for the specific cooking zone.
- Use the independent slider control (0-14) to set the desired power level. Slide your finger along the scale or touch the specific point.

4.3 Bridge Function (FlexiPowder)

The bridge function allows two cooking zones to be combined into a larger single zone, ideal for griddles or large pots.

- Activate the two adjacent zones you wish to bridge.
- Touch the bridge function symbol (often indicated by two linked rectangles).
- Adjust the power level for the combined zone using its dedicated slider.

4.4 PowerBoost Function

The PowerBoost feature provides a rapid burst of heat for quick boiling or searing.

- Select a cooking zone and set a power level.

- Touch the PowerBoost symbol (often 'P' or a similar icon). The zone will operate at maximum power for a limited time.

4.5 Pause Function

The pause function temporarily reduces all active cooking zones to a low keep-warm setting, allowing you to briefly step away without turning off the hob.

- Touch the pause symbol (often two vertical bars). All active zones will switch to a low power setting.
- Touch the pause symbol again to resume cooking at the previous power settings.

4.6 Timer Function

The individual timer allows you to set a cooking duration for each zone.

- Select the desired cooking zone.
- Touch the timer symbol.
- Use the +/- controls or slider to set the desired cooking time.
- The zone will automatically switch off when the timer expires.

4.7 Hob2Hood System

The Hob2Hood feature automatically controls a compatible cooker hood based on the hob's cooking activity.

- Ensure your cooker hood is Hob2Hood compatible and correctly paired with the hob.
- When cooking starts, the hob will send signals to the hood to adjust the extraction rate automatically.
- Manual override is possible on the cooker hood if desired.

5. MAINTENANCE AND CLEANING

Regular cleaning and maintenance will prolong the life and appearance of your induction hob.

- **Daily Cleaning:** After each use, allow the hob to cool. Wipe the glass ceramic surface with a damp cloth and a small amount of mild detergent. Dry thoroughly with a clean cloth.
- **Stubborn Stains:** For burnt-on food or stubborn stains, use a specialized ceramic hob scraper or cleaner. Follow the product instructions carefully.
- **Avoid Abrasives:** Do not use abrasive sponges, scouring pads, or harsh chemical cleaners, as these can scratch or damage the hob surface.
- **Control Panel:** Wipe the control panel gently with a damp cloth. Ensure it is dry before operating the hob.

6. TROUBLESHOOTING

If you encounter issues with your hob, refer to the following common problems and solutions before contacting service.

Problem	Possible Cause	Solution
Hob does not turn on.	No power supply; control panel locked.	Check circuit breaker. Ensure the child lock is not active.

Problem	Possible Cause	Solution
Cooking zone not heating.	Incorrect cookware; cookware not centered; zone not activated.	Use induction-compatible cookware. Center the pot. Activate the zone and set power.
Display shows 'E' or error code.	Internal fault; overheating.	Turn off the hob, wait a few minutes, then restart. If the error persists, contact service.
Unusual noises during operation.	Normal induction hum; fan noise.	Light humming or buzzing is normal for induction technology. The cooling fan may also produce noise.

7. SPECIFICATIONS

Detailed technical specifications for the AEG TO63IQ0BIB Induction Hob.

Feature	Specification
Brand	AEG
Model Number	TO63IQ0BIB
Product Dimensions (D x W x H)	20.08" x 22.83" x 1.93" (51cm x 58cm x 4.9cm)
Item Weight	26.7 pounds (12.1 kg)
Heating Elements	3 Induction Zones (2 x 21 cm, 1 x 28 cm)
Control Type	Touch and Slider
Power Source	Electric (Induction)
Heater Surface Material	Glass Ceramic
Material	Tempered Glass
Special Features	FlexiPowder (Bridge Function), Hob2Hood System, PowerBoost, Pause Function, Individual Timer, Safety Lock

8. WARRANTY AND SUPPORT


Your AEG TO63IQ0BIB Induction Hob comes with a manufacturer's warranty. Please refer to the warranty card included with your appliance for specific terms and conditions, including coverage duration and what to do in case of a claim.

For technical assistance, spare parts, or service requests, please contact AEG customer support. Have your model number (TO63IQ0BIB) and serial number ready when contacting support.

You can find contact information for AEG customer service on the official AEG website or in the documentation provided with your product.



Related Documents - TO63IQ0BIB

	AEG IKE64471FB Induction Hob User Manual Comprehensive user manual for the AEG IKE64471FB induction hob, covering safety instructions, product description, daily use, flexible induction cooking area, hints and tips, care and cleaning, troubleshooting, installation, technical data, and energy efficiency.
	AEG IKB64301XB Induction Hob User Manual Comprehensive user manual for the AEG IKB64301XB induction hob, covering safety instructions, installation, daily use, care, cleaning, troubleshooting, technical data, and energy efficiency.
	AEG IKB64401FB Induction Hob User Manual Comprehensive user manual for the AEG IKB64401FB induction hob, covering safety instructions, installation, daily use, care, troubleshooting, and technical specifications.
	Manuali i Përdorimit AEG IKB32300CB - Udhëzime Sigurie dhe Përdorimi Ky manual përdorimi ofron udhëzime thelbësore për instalimin, përdorimin e sigurt dhe mirëmbajtjen e hobit tuaj me induksion AEG IKB32300CB. Mësoni rreth funksioneve, sigurisë dhe zgjidhjes së problemeve.
	AEG IKB32300CB Ugradna ploča - Uputstvo za upotrebu Detaljno uputstvo za upotrebu AEG ugradne ploče modela IKB32300CB, sa sigurnosnim uputstvima, savetima za instalaciju, korišćenje i održavanje.
	Udhëzues Përdorimi AEG IAE64843FB Vatër Gatimi Ky udhëzues përdorimi ofron udhëzime të hollësishme për instalimin, përdorimin e sigurt dhe mirëmbajtjen e hobit me induksion AEG IAE64843FB.



TO63IQ0BIB

CA Manual d'usuari | Placa 2 2
PT Manual de instruções | Placa 25 25
ES Manual de instrucciones | Placa de cocción 48 48



[\[pdf\]](#) User Manual

Title ca ES manualINDUCCION AEG TO63IQ0BIB 3F ZONA 28CM 60CM 7200Wmanualcomercialprieto

WebRoot Store Shops ComercialPrieto 6814 BAD8 A2CE E92C 9535 0A6E 2802 ABCB DOCS manual |||

aeg.com/register CA Manual d usuari Placa 2 PT Manual de instru es Placa 25 ES

Manual de instrucciones Placa de cocci n 48 **TO63IQ0BIB** aeg.com register

Benvinguts a AEG Gr cies per triar el nostre electrodom stic. Consells d s, cat legs,

instruccions per a la resoluci ...

lang:es **score:32** filesize: 790.26 K page_count: 72 document date: 2024-10-11


TO63IQ0BIB



Combina dos zonas para mayor superficie de cocción
La placa de Inducción Serie 6000 Flex permite usar convenientemente grandes recipientes. Al pulsar el botón Bridge, las zonas de cocción se unen para formar una sola zona de cocción más grande. La zona unida comparte el mismo ajuste de temperatura y tiempo.

Placa de Inducción de la Serie 6000 Flex de 60 cm con 3 zonas (28 cm x 2 x 22 cm). Sistema flexible, con controles deslizantes intuitivos (28 cm x 2 cm). Potencia máxima: 7200W (2200W/2200W/2800W). Placa de Inducción de Inducción. El puente de Inducción permite usar recipientes grandes o largos. La zona unida comparte el mismo ajuste de temperatura y tiempo.


Funciones y características




Combina 2 zonas de cocción con Bridge
La función Bridge permite usar convenientemente grandes recipientes. Al pulsar el botón Bridge, las zonas de cocción se unen para formar una sola zona de cocción más grande. La zona unida comparte el mismo ajuste de temperatura y tiempo.



Notificación: La zona unida comparte el mismo ajuste de temperatura y tiempo
La función Bridge permite usar convenientemente grandes recipientes. Al pulsar el botón Bridge, las zonas de cocción se unen para formar una sola zona de cocción más grande. La zona unida comparte el mismo ajuste de temperatura y tiempo.



Mesa pisa y mayor control gracias a la pantalla táctil
La función Mesa pisa permite usar convenientemente grandes recipientes. Al pulsar el botón Bridge, las zonas de cocción se unen para formar una sola zona de cocción más grande. La zona unida comparte el mismo ajuste de temperatura y tiempo.



Calor más rápido con PowerBoost
La función PowerBoost permite usar convenientemente grandes recipientes. Al pulsar el botón Bridge, las zonas de cocción se unen para formar una sola zona de cocción más grande. La zona unida comparte el mismo ajuste de temperatura y tiempo.



Temporizador de la placa. Hecho para la precisión
El temporizador de la placa permite usar convenientemente grandes recipientes. Al pulsar el botón Bridge, las zonas de cocción se unen para formar una sola zona de cocción más grande. La zona unida comparte el mismo ajuste de temperatura y tiempo.



Notificación: La zona unida comparte el mismo ajuste de temperatura y tiempo
La función Bridge permite usar convenientemente grandes recipientes. Al pulsar el botón Bridge, las zonas de cocción se unen para formar una sola zona de cocción más grande. La zona unida comparte el mismo ajuste de temperatura y tiempo.

TO63IQ0BIB



Combina dos zonas de cocción
La placa de Inducción Serie 6000 Bridge permite usar convenientemente grandes recipientes. Al pulsar el botón Bridge, las zonas de cocción se unen para formar una sola zona de cocción más grande. La zona unida comparte el mismo ajuste de temperatura y tiempo.

Product Benefits & Features



Combina 2 zonas de cocción con Bridge
La función Bridge permite usar convenientemente grandes recipientes. Al pulsar el botón Bridge, las zonas de cocción se unen para formar una sola zona de cocción más grande. La zona unida comparte el mismo ajuste de temperatura y tiempo.



Notificación: La zona unida comparte el mismo ajuste de temperatura y tiempo
La función Bridge permite usar convenientemente grandes recipientes. Al pulsar el botón Bridge, las zonas de cocción se unen para formar una sola zona de cocción más grande. La zona unida comparte el mismo ajuste de temperatura y tiempo.



Less steps and more control with Direct Touch Controls
La función Direct Touch permite usar convenientemente grandes recipientes. Al pulsar el botón Bridge, las zonas de cocción se unen para formar una sola zona de cocción más grande. La zona unida comparte el mismo ajuste de temperatura y tiempo.



Quicken heat for extra speed with PowerBoost
La función PowerBoost permite usar convenientemente grandes recipientes. Al pulsar el botón Bridge, las zonas de cocción se unen para formar una sola zona de cocción más grande. La zona unida comparte el mismo ajuste de temperatura y tiempo.



Big screen. Built for precision
La función Big screen permite usar convenientemente grandes recipientes. Al pulsar el botón Bridge, las zonas de cocción se unen para formar una sola zona de cocción más grande. La zona unida comparte el mismo ajuste de temperatura y tiempo.



Notificación: La zona unida comparte el mismo ajuste de temperatura y tiempo
La función Bridge permite usar convenientemente grandes recipientes. Al pulsar el botón Bridge, las zonas de cocción se unen para formar una sola zona de cocción más grande. La zona unida comparte el mismo ajuste de temperatura y tiempo.

[\[pdf\]](#) Datasheet

Datasheet leafletINDUCCION AEG TO63IQ0BIB 3F ZONA 28CM 60CM 7200Wleafletcomercialprieto

WebRoot Store Shops ComercialPrieto 6814 BAD8 A2CE E92C 9535 0A6E 2802 ABCB DOCS leaflet |||

Placa de inducci n Serie 6000 Flex de 60 cm **TO63IQ0BIB** Combina dos zonas para

mayor superficie de cocci n La placa de inducci n 6000 Bridge permite usar c

modamente grandes utensilios. El bot n Bridge une dos zonas de cocci n para que

puedas usar recipientes grandes o largos. La zona unida co...

lang:es **score:24** filesize: 395.07 K page_count: 2 document date: 2025-03-28

[\[pdf\]](#) Datasheet

Datasheet 6000 Bridge Induction Full Hob TO63IQ0BIBmediamedia adeo media 4788349 |||

6000 Bridge Induction Full Hob **TO63IQ0BIB** Combine two zones to cook more The

6000 Bridge Induction Hob can easily cope when you re cooking with bigger pans.

The Bridge button links two cooking zones together to fit any large or long pan. The

bridged zone will share the same temperature and time set...

lang:en **score:17** filesize: 332.08 K page_count: 2 document date: 2025-05-28

HORNOS, PLACAS Y CAMPANAS DE AEG

1. COMPAÑIA ORGANIZADORA

2. GRATUIDAD

3. LEGITIMACIÓN PARA PARTICIPAR

4. MECÁNICA DE PARTICIPACIÓN

lang:es score:15 filesize: 356.85 K page_count: 9 document date: 2025-02-06



[pdf]

150€ 1 mar 2025 — La sociedad Electrolux España S A U con CIF A28125706 en adelante AEG el fin de incrementar las ventas su marca así como para implementar 1718 2 cemevisa files promocion webs |||

LLVATE HASTA 150 DE REEMBOLSO en hornos, lavavajillas, placas y frigoríficos

integrados Escanea para ... acin 949598349 TI64IG00IB 949598393 TI63IF0BFB

949598346 TO64IM0BIB 949598389 TO63IQ0FFB 949598390 **TO63IQ0BIB**

949598388 TO63IQ00FB 949598550 TO63IV0FFB 949598552 TO63IV00FB

949598549 TO63IV00IB 94949...

lang:es score:15 filesize: 452.08 K page_count: 11 document date: 2025-02-28