

NDHWHE RC-10NMF, RC-10LMI, RC-10JMC

NDHWHE Replacement Inner Bowl User Manual

For Toshiba Rice Cooker Models: RC-10NMF, RC-10LMI, RC-10JMC

1. INTRODUCTION

This manual provides instructions for the proper use and maintenance of your NDHWHE replacement inner bowl, designed for specific Toshiba rice cooker models. Please read this manual thoroughly before first use to ensure optimal performance and longevity of the product.

2. COMPATIBILITY

This replacement inner bowl is specifically designed to be compatible with the following Toshiba rice cooker models:

- Toshiba RC-10NMF
- Toshiba RC-10LMI
- Toshiba RC-10JMC

Ensure your rice cooker model matches one of the listed models for proper fit and function.

3. KEY FEATURES

- Durable Construction:** Engineered for long-lasting use.
- Non-Stick Surface:** Facilitates easy food release and cleaning.
- Optimal Heat Distribution:** Designed for even cooking results.
- Integrated Measurement Markings:** For precise rice and water ratios.



Image 1: The replacement inner bowl showing internal measurement markings for rice and water levels.

4. SETUP

1. **Unpacking:** Carefully remove the inner bowl from its packaging. Inspect for any damage.
2. **Initial Cleaning:** Before first use, wash the inner bowl thoroughly with warm, soapy water. Rinse completely and dry with a soft cloth.
3. **Placement:** Ensure the inner bowl is correctly seated within your compatible Toshiba rice cooker. It should fit snugly without wobbling.

5. OPERATING INSTRUCTIONS

This inner bowl functions as a direct replacement for your original rice cooker pot. Refer to your Toshiba rice cooker's original instruction manual for specific cooking procedures, recipes, and safety guidelines.

- **Rice Measurement:** Use the provided measurement markings inside the bowl to add the desired amount of rice.
- **Water Measurement:** Add water according to the markings or your recipe, ensuring the water level corresponds to the rice quantity.
- **Cooking:** Place the inner bowl into the rice cooker, close the lid, and select the appropriate cooking function on your rice cooker.

6. MAINTENANCE AND CLEANING

- **After Each Use:** Allow the inner bowl to cool before cleaning.

- **Washing:** Wash the inner bowl with warm, soapy water and a soft sponge or cloth. Avoid abrasive cleaners, scouring pads, or metal utensils, as these can damage the non-stick coating.
- **Stubborn Residue:** If food sticks, soak the bowl in warm water for a few minutes to loosen the residue before washing.
- **Drying:** Dry thoroughly before storing or reusing.
- **Storage:** Store in a dry place.

7. TROUBLESHOOTING

As this product is a replacement inner bowl, most operational issues will relate to the rice cooker unit itself. Refer to your Toshiba rice cooker's original manual for troubleshooting common cooking problems.







- **Food Sticking:** Ensure you are using appropriate cooking oil or butter if necessary, and avoid scratching the non-stick surface with metal utensils.
- **Improper Fit:** Double-check that the inner bowl is correctly seated and that your rice cooker model is listed as compatible.

8. SPECIFICATIONS

Attribute	Detail
Brand	NDHWHE
Compatible Models	Toshiba RC-10NMF, RC-10LMI, RC-10JMC
Material	Non-stick coated metal
Color	One Color (Black)
Item Weight	50 Grams (approx. 1.76 ounces)
Package Dimensions	1.18 x 0.79 x 0.39 inches

9. WARRANTY AND SUPPORT

For warranty information or product support, please refer to the seller's policies or contact the manufacturer directly. Keep your purchase receipt as proof of purchase.

	<p>Toshiba Electric Rice Cooker/Warmer Instruction Manual for RC-10NMF, RC-18NMF, RC-10NMF1, RC-18NMF1</p> <p>Comprehensive instruction manual for Toshiba Electric Rice Cooker/Warmer models RC-10NMF, RC-18NMF, RC-10NMF1, and RC-18NMF1. Covers safety precautions, part names, preparation, cooking instructions, clock adjustment, preset timer, keeping warm, maintenance, and specifications.</p>
	<p>Toshiba Electric Rice Cooker/Warmer: Comprehensive Instruction Manual for Models RC-10NAF Series</p> <p>This comprehensive instruction manual provides detailed guidance on operating and maintaining your Toshiba Electric Rice Cooker/Warmer, including safety precautions, cooking instructions for rice and other dishes, cleaning tips, and troubleshooting for models RC-10NAF, RC-18NAF, and their variants.</p>
	<p>Toshiba Rice Cooker/Warmer Instruction Manual - Models RC-10NMF, RC-18NMF, RC-10NMF1, RC-18NMF1</p> <p>Comprehensive instruction manual for Toshiba Electric Rice Cooker/Warmer models RC-10NMF, RC-18NMF, RC-10NMF1, and RC-18NMF1. Includes safety guidelines, part identification, preparation steps, cooking instructions for various modes, clock adjustment, timer settings, warming functions, maintenance procedures, and technical specifications.</p>
	<p>Toshiba Rice Cooker User Manual: RC-10IP1PV, RC-10IX1PV, RC-18IP1PV, RC-18IX1PV</p> <p>Comprehensive user manual for Toshiba induction rice cookers, models RC-10IP1PV, RC-10IX1PV, RC-18IP1PV, and RC-18IX1PV. Includes safety precautions, parts identification, operation instructions, cooking modes, cleaning, maintenance, troubleshooting, and technical specifications.</p>
	<p>Toshiba Rice Cooker User Manual - RC-10JFM, RC-18JFM, RC-18JFM2, RC-10JH1TVN</p> <p>Comprehensive user manual for Toshiba rice cookers, including product introduction, safety precautions, operating instructions, cleaning guide, technical specifications, troubleshooting, and warranty information for models RC-10JFM, RC-18JFM, RC-18JFM2, and RC-10JH1TVN.</p>
	<p>Toshiba Rice Cooker Operation Manual</p> <p>This manual provides detailed instructions for operating and maintaining your Toshiba rice cooker, including safety precautions, part identification, cooking steps, special functions, and troubleshooting.</p>