Scstartx QD-208

Scstartx QD-208 Car Battery Jump Starter User Manual

Model: QD-208 | Brand: Scstartx

Introduction

The Scstartx QD-208 is a portable car battery jump starter designed to provide reliable power for starting vehicles with dead 12V batteries. It features a 2000A peak current, making it suitable for a wide range of vehicles, including cars, trucks, motorcycles, boats, and more, with up to 7.0L gas and 4.0L diesel engines. This device also functions as a portable power bank and includes an LED flashlight for emergencies.

This manual provides essential information for the safe and effective use of your Scstartx QD-208 jump starter. Please read it thoroughly before operation.



Image: The Scstartx QD-208 jump starter with its smart jumper clamps, illustrating its use for various vehicles like a Jeep and a motorcycle.

Safety Information

Always observe the following safety precautions to prevent injury or damage to the device and vehicle:

- Ensure the jump starter is charged above 50% before attempting to jump start a vehicle.
- Do not connect the positive (+) and negative (-) clamps together.
- Do not immerse the device in water or expose it to excessive moisture.
- Do not disassemble the unit. Refer servicing to qualified personnel.
- Keep out of reach of children.
- Operate in a well-ventilated area.
- The device incorporates a smart chip with 10 integrated safety protection technologies, including reverse connection, over-discharge, over-current, short circuit, reverse charge, over-temperature, low voltage, reverse polarity, over-charge, and low-temperature protection. These features are designed to ensure safe operation and prevent sparking.



Image: Visual representation of the 10 safety protection features integrated into the Scstartx QD-208 jump starter.

What's in the Box

Verify that all items are present upon unpacking:

- 1 x Scstartx QD-208 Jump Starter
- 1 x Smart Jumper Cable with Clamps
- 1 x USB-C Charging Cable
- 1 x EVA Storage Bag
- 1 x User Manual (this document)



Image: All components included in the Scstartx QD-208 jump starter package, neatly arranged.

Product Overview

Familiarize yourself with the main components of the Scstartx QD-208 jump starter:

- **Main Unit:** Portable power pack with integrated battery.
- **Smart Jumper Cables:** Red (+) and Black (-) clamps with a smart protection module.
- **Power Button:** To turn the device on/off and activate functions.
- **LED Display:** Shows battery percentage and status.
- **USB Output Ports:** For charging external devices.
- **USB-C Input Port:** For charging the jump starter.
- **LED Flashlight:** Integrated light with multiple modes.



Image: The Scstartx QD-208 jump starter unit with its smart clamps, highlighting its compact design and readiness for use with cars and motorcycles.

Setup

Charging the Jump Starter

Before first use, fully charge the Scstartx QD-208. It is recommended to keep the device charged above 50% for optimal performance, especially before jump-starting a vehicle.

1. Connect the provided USB-C charging cable to the USB-C input port on the jump starter.
2. Connect the other end of the USB-C cable to a suitable USB wall adapter (not included) or a powered USB port.
3. The LED display will show the charging progress. The device is fully charged when the display shows 100%.

Operating Instructions

Jump Starting a Vehicle

Ensure the jump starter is charged above 50% before proceeding.

1. **Connect Clamps:** Plug the smart jumper cable into the jump starter's port. Ensure a secure connection.
2. **Attach to Battery:** Connect the red (+) clamp to the positive terminal of the vehicle's battery. Connect the black (-) clamp to the negative terminal of the vehicle's battery.
3. **Check Indicator:** The smart jumper cable's indicator light will show the connection status. A solid green light indicates a correct and safe connection. If an error light appears, refer to the troubleshooting section.
4. **Start Vehicle:** Once the green light is solid, start your vehicle's engine.
5. **Remove Clamps:** After the vehicle starts, immediately remove the smart jumper clamps from the vehicle battery, then disconnect the jumper cable from the jump starter.



Image: The Scstartx QD-208 jump starter connected to a car battery, ready to initiate a jump start.

Using the LED Flashlight

The built-in LED flashlight has three modes: Flashlight, Strobe, and SOS.

1. **Turn On/Off:** Long press the LED button for 2 seconds to turn the flashlight on or off.
2. **Change Modes:** With the flashlight on, short press the LED button to cycle through Flashlight, Strobe, and SOS modes.



Image: The Scstartx QD-208 jump starter's LED flashlight in use, demonstrating its various lighting modes (flashlight, strobe, SOS).

Using as a Portable Power Bank

The Scstartx QD-208 can charge various USB-powered devices.

1. Connect your device's USB charging cable to one of the USB output ports on the jump starter.
2. The jump starter will automatically begin charging your device.
3. Monitor your device's charging status.



Image: The Scstartx QD-208 jump starter functioning as a power bank, simultaneously charging a smartphone, tablet, smartwatch, and wireless earbuds.

Maintenance

Charging Recommendations

- For optimal battery health, if the jump starter is not used for a long period, it is recommended to charge it every 2-3 months.
- Avoid completely draining the battery frequently.

Storage

- Store the jump starter in a cool, dry place, away from direct sunlight and extreme temperatures.
- Use the provided EVA storage bag to protect the device and accessories.

Troubleshooting

If you encounter issues with your Scstartx QD-208, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Vehicle does not start	Jump starter battery too low Incorrect clamp connection Vehicle battery severely damaged	Ensure jump starter is above 50% charge Verify correct positive (+) and negative (-) connections Consult a professional mechanic
Smart jumper cable indicator shows error	Reverse polarity Short circuit Over-temperature	Disconnect and re-connect clamps correctly Check for any metal contact between clamps Allow device to cool down before re-attempting
Jump starter not charging	Faulty USB-C cable or adapter Charging port issue	Try a different USB-C cable and adapter Contact customer support if issue persists

Problem	Possible Cause	Solution
Flashlight not working	Battery too low Button malfunction	Charge the jump starter Contact customer support

If the problem persists after attempting these solutions, please contact Scstartx customer support.

Specifications

Feature	Detail
Brand	Scstartx
Model	QD-208
Peak Output Current	2000 Amps
Battery Type	Lithium Polymer
Battery Capacity	16000 mAh
Vehicle Compatibility	12V vehicles (up to 7.0L Gas, 4.0L Diesel)
Product Dimensions	1.69"D x 3.22"W x 6.53"H
Item Weight	600 Grams (1.32 pounds)
Operating Temperature	-20°C to 60°C (-4°F to 140°F)
Flashlight Lumens	400 Lumens
Safety Protections	10 integrated safety features (Reverse Connection, Over-Discharge, Over-Current, Short Circuit, Reverse Charge, Over-Temperature, Low Voltage, Reverse Polarity, Over-Charge, Low Temperature)



Image: The Scstartx QD-208 jump starter shown in a snowy landscape, highlighting its ability to operate in extreme cold temperatures down to -4°F.



Image: The Scstartx QD-208 jump starter shown in a desert landscape, highlighting its ability to operate in extreme hot temperatures up to 122°F.

Warranty and Support

Scstartx provides comprehensive support for its products:

- **Warranty:** 12 Months Warranty and 180 Days Hassle-free Warranty.
- **Return Policy:** 30-day Unconditional Return Guarantee.
- **Technical Support:** Lifetime Technical Support.
- **Customer Service:** 24 Hours, 7x24 Customer Support.

For any questions or assistance, please contact Scstartx customer service.



Image: Overview of Scstartx customer support offerings, including 24/7 support, return policy, warranty, and lifetime technical assistance.

© 2025 Scstartx. All rights reserved.