



Manuals.plus /

› Naturehike /

› Naturehike Compact King Size Air Mattress User Manual

Naturehike Morning View

Naturehike Compact King Size Air Mattress User Manual

Model: Morning View (CJ-C25) | Brand: Naturehike

1. INTRODUCTION

This manual provides instructions for the proper setup, operation, and maintenance of your Naturehike Compact King Size Air Mattress. Please read this manual thoroughly before using the product to ensure safe and efficient operation.

COMPACT KING SIZE AIR MATTRESS

Comfortable sleep for the whole family



Image 1.1: The Naturehike Compact King Size Air Mattress, designed for comfortable sleep for multiple users.

2. SAFETY INFORMATION

- **Temperature:** Suggested use temperature is above 50°F (10°C).
- **Initial Inflation:** After receiving, inflate the mattress and leave it for 8-12 hours before first use.
- **Charging:** Do not use the air pump while it is charging.
- **Pump Storage:** The air pump should be stored in a dry environment.
- **Pump Overheating:** It is recommended to turn off the power to cool down the air pump for 10 minutes after 5 minutes of continuous operation to avoid overheating and potential internal damage.
- **Over-inflation:** Please do not over-inflate the mattress.
- **Material Safety:** The skin-friendly flocked PVC fabric is formaldehyde-free, soothing, and breathable, suitable for use by children and pets.



Image 2.1: The mattress features skin-friendly flocked PVC fabric, ensuring comfort and safety for all users.

3. PACKAGE CONTENTS

Verify that all items are present in the package:

- Naturehike Luxury Air Mattress with Built-in USB Pump
- User Guide
- Carry Bag

4. SETUP

4.1 Charging the Built-in Pump

The built-in pump is rechargeable via a USB-C cable (included). A full charge typically allows for 3-5 inflation/deflation cycles. Ensure the pump is fully charged before initial use.

4.2 Inflation

To inflate the mattress:

1. Unfold the mattress and lay it flat on a clean, level surface.
2. Locate the built-in pump on the side of the mattress.
3. Open the pump cover.
4. Press the inflation button (usually marked with a '+' or 'inflate' symbol). The mattress will begin to inflate automatically.
5. Inflation typically takes approximately 3 minutes. The pump will stop automatically or can be manually stopped once the desired firmness is reached.
6. Close the pump cover securely to prevent air leakage.



Image 4.1: The built-in pump allows for quick inflation and deflation with a single touch. Auxiliary nozzles are included for other inflatables.

4.3 Setup Video

Video 4.1: Official Naturehike video demonstrating the inflation process of the air mattress.

5. OPERATING INSTRUCTIONS

5.1 Deflation

To deflate the mattress:

1. Open the pump cover.
2. Press the deflation button (usually marked with a '-' or 'deflate' symbol). The mattress will begin to deflate automatically.
3. Ensure all air is expelled for compact storage.
4. Close the pump cover securely.

5.2 Using the Pump for Other Inflatables

The built-in pump is extractable and can be used to inflate other compatible inflatable products. Remove the pump from its housing and attach the appropriate nozzle (included) to inflate items such as air pillows or sleeping pads.

6. MAINTENANCE

6.1 Cleaning

Wipe the mattress surface with a damp cloth and mild soap if necessary. Ensure the mattress is completely dry before storing.

6.2 Storage

For compact storage, follow these steps:

1. Ensure the mattress is fully deflated.
2. Lay the mattress flat.
3. Fold the left 1/4 portion inward.
4. Fold the right 1/3 portion inward.

5. Fold the mattress in half lengthwise.
6. Fold the mattress towards the head end.
7. Place the folded mattress into the provided carry bag.



Image 6.1: Step-by-step guide for folding and storing the air mattress, reducing its size significantly for portability.

7. TROUBLESHOOTING

- **Air Leakage:** If you experience any problems with air leakage, please contact Naturehike customer support for assistance.
- **Pump Not Working:** Ensure the pump is fully charged. If the pump stops during operation, allow it to cool down for 10 minutes before resuming use.

8. SPECIFICATIONS

Feature	Detail
Size (Unfolded)	78.7"L x 71"W x 10"Th (200cm x 180cm x 25cm)
Storage Size	16.5" x 13.4" x 6.7" (42cm x 34cm x 17cm)
Item Weight	11.46 lbs (5.2 kg)
Weight Limit	992 lbs (450 kg)
Material	Flocked PVC fabric
Pump Type	Built-in USB Rechargeable Electric Pump
Inflation Time	Approx. 3 minutes

FOUR RIGOROUS TESTS, QUALITY GUARANTEED



Image 8.1: The internal honeycomb load-bearing system provides balanced and stable support.

Formaldehyde 0 exceeds the standard

Children / pets lie at ease

Skin-friendly flocking fabric, soothing and breathable from the inside to the outside, build a secure sleep environment



Image 8.2: The mattress undergoes rigorous testing, including 5000 roller rolling tests and a 450kg 24-hour pressure test.

9. WARRANTY AND SUPPORT

The Naturehike Compact King Size Air Mattress is covered by a **2-year warranty**.

For any product issues, including problems with the air pump or air leakage, please contact Naturehike customer support. We are committed to providing a satisfactory solution.

Contact information can typically be found on the Naturehike official website or through your purchase platform.