

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Nathan James](#) /

› [Nathan James Mischa Boho Pendant Light \(Model 12010\) Instruction Manual](#)

## Nathan James 12010

# Nathan James Mischa Boho Pendant Light (Model 12010)

Instruction Manual

## INTRODUCTION

This manual provides detailed instructions for the safe installation, operation, and maintenance of your Nathan James Mischa Boho Pendant Light. This large rattan pendant light features an oversized handwoven cone-shaped shade made from natural rattan, complemented by vintaged brass accents. It includes a dual bulb socket cluster, is adjustable to different heights, and is compatible with sloped ceilings. Please read this manual thoroughly before beginning installation or use.

## IMPORTANT SAFETY INFORMATION

- Always disconnect power at the circuit breaker before installation, cleaning, or maintenance.
- Installation should be performed by a qualified electrician if you are unsure or uncomfortable with electrical wiring.
- Ensure all electrical connections are secure and properly insulated to prevent electrical shock.
- Do not exceed the maximum wattage specified for the light bulbs (60W per bulb, 120W total).
- This product is designed for indoor use only. Do not expose to moisture or outdoor elements.
- Handle the rattan shade with care to avoid damage.

## PACKAGE CONTENTS

Verify that all components are present and undamaged before beginning assembly.

- Pendant Light Fixture (Rattan/Brass)
- Mounting Hardware
- Instruction Manual
- *Note: Light bulbs are not included. The fixture requires two ST19 vintage Edison or A19 bulbs with a standard E26 base. Maximum 60W per bulb.*



Image: Components of the Mischa Pendant Light, including the rattan shade and brass fixture.

## TOOLS REQUIRED FOR ASSEMBLY

---

- Phillips-head screwdriver
- Wire strippers (if needed for electrical connections)
- Electrical tape (if needed for insulation)
- Ladder (for safe ceiling installation)

## SETUP AND INSTALLATION

---

Follow these steps carefully to install your pendant light. If you are unsure about any step, consult a qualified electrician.

1. **Turn Off Power:** Locate the circuit breaker controlling the power to the installation area and turn it off. Verify power is off using a voltage tester.
2. **Prepare Mounting Surface:** Attach the circular mounting bracket to the ceiling junction box using the screws

provided. Ensure the bracket is securely fastened and can support the weight of the fixture.

3. **Adjust Height (Optional):** The pendant light's height is adjustable. Determine your desired hanging length and adjust the suspension rod accordingly. The fixture is also compatible with sloped ceilings.
4. **Wire Connections:** Connect the fixture's wires to the corresponding household wires. Typically, black (live) to black, white (neutral) to white, and bare copper or green (ground) to ground. Use wire nuts to secure connections and wrap with electrical tape for added insulation.
5. **Attach Canopy:** Carefully push the fixture's canopy up to the ceiling, covering the junction box and wiring. Secure it to the mounting bracket with the provided screws.
6. **Install Bulbs:** Screw in two ST19 vintage Edison or A19 bulbs (not included) into the E26 base sockets. Do not exceed 60W per bulb.
7. **Attach Rattan Shade:** Carefully attach the rattan shade to the fixture according to the specific instructions provided with the hardware.
8. **Restore Power:** Once installation is complete and all components are secure, restore power at the circuit breaker.



Image: The Mischa Pendant Light installed, demonstrating its aesthetic.

## OPERATING INSTRUCTIONS

---

The Nathan James Mischa Pendant Light operates via a standard wall switch (not included). Ensure the light bulbs are correctly installed and the power supply is active.

- **Turning On/Off:** Use the wall switch connected to the fixture to turn the light on or off.
- **Dimming (if applicable):** If the fixture is connected to a compatible dimmer switch and you are using dimmable bulbs, you can adjust the light intensity by operating the dimmer switch.

## CARE AND MAINTENANCE

---

- **Cleaning:** Always disconnect power before cleaning. Wipe the rattan shade with a soft, dry cloth. For the metal components, use a slightly damp cloth and mild soap if necessary, then dry thoroughly. Avoid abrasive cleaners, solvents, or harsh chemicals, as these can damage the finish.
- **Bulb Replacement:** Ensure power is off and bulbs have cooled completely before attempting to replace them. Unscrew old bulbs and screw in new E26 base bulbs (max 60W).
- **Inspection:** Periodically inspect all electrical connections and mounting hardware to ensure they remain secure.

## TROUBLESHOOTING

---

Problem	Possible Cause	Solution
Light does not turn on.	No power to the fixture; loose wiring; faulty bulb.	Check the circuit breaker. Ensure all wire connections are secure. Replace the light bulb.
Light flickers.	Loose bulb; incompatible dimmer switch/bulb; loose wiring.	Tighten the bulb. Ensure dimmer and bulbs are compatible. Check wiring connections.
Fixture is unstable or wobbles.	Mounting hardware not securely fastened.	Ensure the mounting bracket and canopy are securely attached to the ceiling junction box.

## SPECIFICATIONS

---

**Brand:** Nathan James

**Model Name:** Mischa Pendant

**Model Number:** 12010

**Color:** Rattan/Brass

**Material:** Cane, Metal

**Style:** Bohemian

**Light Fixture Form:** Pendant

**Room Type:** Bedroom, Dining Room, Entryway, Kitchen, Living Room

**Product Dimensions:** 14" L x 14" W x 53" H

**Indoor/Outdoor Usage:** Indoor

**Power Source:** Corded Electric

**Special Features:** 2-bulb socket cluster, Adjustable height, Sloped ceiling compatible, Oversized natural rattan shade, Vintaged brass-colored metal

**Light Source Type:** Incandescent (compatible with LED)

**Number of Light Sources:** 2

**Voltage:** 120 Volts

**Wattage:** 60 watts (per bulb, max 120W total)

**Bulb Base:** E26

**Item Weight:** 4 Pounds

**Assembly Required:** Yes

**UPC:** 842196018946

— 4.7" —





Image: Dimensional diagram of the Mischa Pendant Light.

## • Shade/Light

- ✓ Oversized natural rattan shade
- ✓ 2-bulb socket cluster
- ✓ Bohemian style
- ✓ Max. Wattage:  
120W (60W per bulb)

## • Details

- ✓ Vintaged brass-colored metal
- ✓ Can be installed at different heights
- ✓ Can be installed on sloped ceilings



Lifetime  
Manufacturer  
Warranty

Image: Key features of the Mischa Pendant Light.

## WARRANTY AND SUPPORT

**Warranty:** The Nathan James Mischa Pendant Light comes with a lifetime manufacturer warranty. For any quality issues, please contact Nathan James customer support for a replacement.

**Customer Support:** For assistance with assembly, missing parts, or any other inquiries, please visit the official Nathan James website or contact their customer service directly. Refer to your purchase documentation for specific contact details.

*This product is not recommended for commercial use.*

