

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [SWOFY](#) /

› [SWOFY M2 Wearable MP3 Player User Manual](#)

SWOFY M2

SWOFY M2 Wearable MP3 Player User Manual

Model: M2

INTRODUCTION

The SWOFY M2 is a versatile 2-in-1 wearable and neckable MP3 player designed for active lifestyles. It combines a high-fidelity music player with a fitness tracker, offering a seamless audio experience and activity monitoring. Featuring a 1.91-inch curved touch screen, Bluetooth 5.3 connectivity, and 32GB of internal storage, the M2 is ideal for sports, running, gym workouts, and daily commutes. Its ergonomic and lightweight design ensures comfort and convenience.



Image: The SWOFY M2 MP3 Player shown both as a wrist-worn device and attached to a lanyard for neck wear, highlighting its dual functionality.

WHAT'S IN THE BOX

Upon opening your SWOFY M2 package, please ensure all the following components are present:

- 1 x 32GB MP3 Player (SWOFY M2)
- 1 x Wired Earbud
- 1 x Magnetic Snap Charging Cable
- 1 x User manual

Dimensions and package contents




Image: A visual representation of the SWOFY M2 MP3 Player and its included accessories: the player itself, a magnetic charging cable, wired earbuds, and the user manual.

PRODUCT FEATURES

2-in-1 Wearable & Neckable Design

The SWOFY M2 offers flexible wearing options. It can be worn on your wrist like a smartwatch or attached to the included lanyard for hands-free neck wear. This adaptability makes it suitable for various activities, from intense workouts to casual listening.

Multiple Function MP3 player



One click to shortcut interface



Image: An illustration of the SWOFY M2's multi-functionality, displaying icons for Music, Recorder, Bluetooth, Pedometer, E-book, Calendar, Alarm Clock, Stopwatch, and Watch Face.

High-Fidelity Audio with Bluetooth 5.3

Experience pristine, lossless audio quality. The M2 supports multiple audio formats including MP3, FLAC, AAC, WAV, APE, and WMA. Equipped with Bluetooth 5.3, it ensures stable and seamless connection to your headphones, earbuds, or external speakers, complemented by automatic noise reduction for an optimal listening experience.

Stable Duplex Bluetooth

you can use it to connect Bluetooth
Headphones, home speakers and car system



Image: The SWOFY M2 MP3 Player screen showing Bluetooth connection status, indicating compatibility with headphones, speakers, and car systems, but not with laptops or phones for data transfer.

Integrated Fitness Tracker (Pedometer)

Beyond music, the M2 functions as a pedometer, tracking your steps and activity data. It stores 7 days of step data and provides 24-hour step data, encouraging an active lifestyle.

Pedometer



Image: A person running with the SWOFY M2 MP3 Player on their wrist, with an enlarged view of the screen showing pedometer data including steps, distance, and calories burned.

Voice Recorder & E-book Functionality

Capture important notes or lectures with the built-in voice recorder, featuring 10-level noise reduction for clear audio. The device also supports e-book reading, making it a versatile companion for both productivity and leisure.

Long Battery Life & Quick Charging

The 200mAh battery provides up to 10 hours of playback and an impressive 16 days of standby time. Smart power-saving features like "Raise-to-Wake" optimize battery usage. Charging is convenient via the magnetic snap charging cable.

Long battery life and high capacity



Image: The back of the Swofy M2 MP3 Player connected to its magnetic charging cable, illustrating the charging process and highlighting its long battery life with 18 days standby, 7 days daily use, and 2.5 hours magnetic charging time.

Vivid Full-Color Touch Display & Customization

Navigate effortlessly on the bright, responsive 1.91-inch LCD touchscreen. Personalize your device with dynamic analog/digital faces and wallpapers to match your style and mood.

Reasons to choose the SWOFY MP3 Player

1.91"

Ultra HD Dazzling Screen



34g



34g Ultra-thin Watch

Image: The SWOFY M2 MP3 Player highlighting its 1.91-inch Ultra HD Dazzling Screen and its lightweight design at 34 grams.

SETUP GUIDE

1. Initial Charging

Before first use, fully charge your SWOFY M2. Connect the magnetic snap charging cable to the charging points on the back of the device and plug the USB end into a standard USB power adapter (not included) or a computer's USB port. The screen will indicate charging status. A full charge typically takes about 2.5 hours.

2. Powering On/Off

- **To Power On:** Press and hold the power button (usually located on the side) until the screen lights up.
- **To Power Off:** Press and hold the power button, then select "Power Off" on the screen.

3. Connecting to Bluetooth Devices

1. Ensure your Bluetooth headphones or speaker are in pairing mode.
2. On your SWOFY M2, navigate to the "Bluetooth" icon on the main screen.
3. Tap to open Bluetooth settings.
4. The device will scan for available Bluetooth devices. Select your device from the list to pair.
5. Once paired, the device will automatically connect when in range and Bluetooth is enabled.

OPERATING INSTRUCTIONS

Navigation

The SWOFY M2 features a full-color touch display for intuitive navigation. Swipe left/right or up/down to browse through applications and settings. Tap an icon to open an application.

It's both an MP3 and a Fitness Tracker (Pedometer)

Not just a stylish Fitness Tracker, this is a high - performance MP3 player famous for its HiFi sound! Enjoy crystal - clear music!

Note : Free case & lanyard! Two ways to wear!



Image: The SWOFY M2's quick access interface, showing numbered points for Backlight adjustment, Volume adjustment, Screen style, Raise your wrist to turn on the screen, Flashlight, Speaker switch, Folder, and Bluetooth switch.

Music Playback

1. Transfer music files (MP3, FLAC, AAC, WAV, APE, WMA) to the device's internal 32GB storage via a computer.
2. Tap the "Music" icon on the home screen.
3. Browse your music library by artist, album, or song.
4. Tap a song to begin playback. Use on-screen controls for play/pause, skip, and volume adjustment.

Voice Recording

1. Tap the "Recorder" icon.
2. Press the record button to start recording.
3. Press the stop button to end and save the recording.
4. Recordings are saved in the device's memory and can be accessed via the "Folder" or "Recorder" application.

Fitness Tracking (Pedometer)

1. Tap the "Pedometer" icon to view your activity data.
2. The device automatically tracks your steps throughout the day.
3. Review daily and weekly step counts, distance, and estimated calories burned.

Other Functions

- **E-book:** Access and read text files.
- **Alarm Clock:** Set multiple alarms for reminders.
- **Calendar:** View dates and manage schedules.
- **Stopwatch:** Use for timing activities.
- **Watch Face:** Customize the display with various analog and digital watch faces.

MAINTENANCE

- **Cleaning:** Wipe the device and screen with a soft, dry, lint-free cloth. Avoid using harsh chemicals or abrasive materials.
- **Battery Care:**
 - Charge the device regularly, avoiding complete discharge for extended periods.
 - Do not expose the device to extreme temperatures (hot or cold), as this can degrade battery performance.
- **Storage:** When not in use for extended periods, store the device in a cool, dry place away from direct sunlight. Ensure it has a partial charge (around 50%) before storing.
- **Water Resistance:** The device is not waterproof. Avoid exposure to water, rain, or excessive moisture.

TROUBLESHOOTING

If you encounter issues with your SWOFY M2, please refer to the following common problems and solutions:

Problem	Possible Cause / Solution
Device does not turn on.	Battery may be depleted. Connect to charger and allow it to charge for at least 15 minutes before attempting to power on again.

Problem	Possible Cause / Solution
Cannot connect to Bluetooth headphones/speaker.	<ul style="list-style-type: none"> • Ensure Bluetooth is enabled on both the MP3 player and the receiving device. • Make sure the receiving device is in pairing mode. • Move the devices closer to each other to ensure they are within range. • Turn off and on Bluetooth on both devices, then try pairing again. • Note: The device connects to headphones/speakers, not typically to phones or computers for data transfer via Bluetooth.
Music playback is choppy or cuts out.	<ul style="list-style-type: none"> • Ensure the Bluetooth connection is stable and within range. • Check if there are obstacles or interference between the player and the audio device. • Verify the audio file is not corrupted.
Fitness tracker (pedometer) is inaccurate.	<ul style="list-style-type: none"> • Ensure the device is worn correctly on your wrist or neck. • Movement patterns can affect accuracy; consistent arm swing is recommended for wrist wear. • Environmental factors or very subtle movements might not be registered.
Device is not charging.	<ul style="list-style-type: none"> • Check if the magnetic charging cable is properly aligned and connected to the device. • Ensure the USB power source (adapter or computer port) is functional. • Try a different USB port or power adapter.

SPECIFICATIONS

Brand	SWOFY
Model Number	M2
Memory Storage Capacity	32 GB
Connectivity Technology	Bluetooth 5.3
Screen Size	1.91 Inches
Display Technology	LCD
Supported Audio Standards	MP3, WMA, APE, FLAC, WAV, AAC




Special Features	Built-In Speaker, Equalizer, Touch Screen, Video Playback, Voice Recorder, Fitness Tracker (Pedometer)
Compatible Devices	Bluetooth Headphones, Bluetooth Speakers
Battery	1 A battery required (included), 200mAh
Item Weight	5.3 ounces (approx. 150g)
Package Dimensions	5.83 x 5.83 x 0.75 inches
Country of Origin	China

WARRANTY AND SUPPORT

For detailed warranty information and customer support, please refer to the official SWOFY website or contact the seller directly. The included user manual also contains specific warranty terms and contact details. Please retain your proof of purchase for warranty claims.

No official seller videos were found in the provided product data for embedding in this manual.

Related Documents - M2

	<p>SWOFY M2 MP3 Player User Manual</p> <p>Comprehensive user manual for the SWOFY M2 MP3 Player, detailing its features, functions, and specifications. Learn how to operate music playback, Bluetooth pairing, FM radio, recordings, e-book reading, and device settings.</p>
	<p>SWOFY D50 MP3 Player User Manual</p> <p>User manual for the SWOFY D50 MP3 Player. This guide provides detailed instructions on features such as music playback, Bluetooth connectivity, FM radio, recording, e-book reading, and device settings. Learn to maximize your portable digital music experience.</p>
	<p>SWOFY M4 Music Player User Manual - Features, Specifications & Operation</p> <p>Comprehensive user manual for the SWOFY M4 Music Player. Learn about its features, specifications, music playback, movie support, FM radio, Bluetooth connectivity, and more.</p>

<div><div>SWOFY</div><div>User Manual</div><div>MP3 Player</div><div><small>If any request is received, please feel free to email us: sales@swofy.com</small></div></div>	<div><div>SWOFY M4 Music Player User Manual</div><div>User manual for the SWOFY M4 Music Player, detailing its features, functions, specifications, and operation for music playback, video, e-books, FM radio, and Bluetooth connectivity.</div></div>
<div><div>SWOFY</div><div>USER MANUAL</div><div>MP3 PLAYER</div><div><small>Please be sure to read the instructions carefully before using the product, and please do not use the product if you are not familiar with the instructions.</small></div></div>	<div><div>SWOFY D50 MP3 Player User Manual</div><div>User manual for the SWOFY D50 MP3 Player, covering button functions, charging, music playback, Bluetooth pairing, E-book reading, FM radio, settings, and specifications.</div></div>
<div><div>SWOFY</div><div>USER MANUAL</div><div>DIGITAL PLAYER</div><div><small>Please be sure to read the instructions carefully before using the product, and please do not use the product if you are not familiar with the instructions.</small></div></div>	<div><div>SWOFY M503Pro Digital Player User Manual</div><div>Comprehensive user manual for the SWOFY M503Pro digital player, covering setup, features, settings, specifications, and warnings. Learn how to use your device effectively.</div></div>