



[Manuals.plus](#) /

› [Gamtimer](#) /

› Gamtimer Gaming Chair User Manual

Gamtimer G-08

Gamtimer Gaming Chair User Manual

Model: G-08

Brand: Gamtimer

1. INTRODUCTION

Thank you for choosing the Gamtimer Gaming Chair. This manual provides essential information for the assembly, operation, maintenance, and troubleshooting of your new chair. Please read this manual thoroughly before assembly and use to ensure proper function and safety. This chair is designed to provide ergonomic support and comfort for extended periods of gaming, working, or studying.



Image 1.1: Gamtimer Gaming Chair in upright and reclined positions, showcasing its versatility.

2. IMPORTANT SAFETY INFORMATION

Please observe the following safety guidelines to prevent injury or damage to the chair:

- **Weight Capacity:** Do not exceed the maximum weight capacity of 400 lbs (approximately 181 kg). Exceeding this limit can cause damage to the chair and potential injury.
- **Assembly:** Ensure the chair is properly assembled according to the instructions to avoid any risk of tipping or instability. All screws and bolts must be securely tightened.
- **Stability:** Do not stand on the chair. Avoid leaning excessively to one side or rocking vigorously, especially when reclined, to prevent tipping.
- **Children and Pets:** Keep children and pets away from the chair during assembly. Do not allow children to play on or around the chair unsupervised.
- **Moving Parts:** Be cautious of moving parts, such as the recline mechanism and armrests, to avoid pinching.

fingers or other body parts.

- **Placement:** Place the chair on a flat, stable surface. Avoid placing it near heat sources or in direct sunlight for prolonged periods, which can damage the material.

3. PACKAGE CONTENTS

Before beginning assembly, please verify that all parts are present and undamaged. If any parts are missing or damaged, please contact customer support immediately.

DIMENSION (IN)

GAMTIMER

HEIGHT	
RECOMMENDED	47-83in
MAX LOAD	85in

WEIGHT	
RECOMMENDED	88-265lbs
MAX LOAD	300lbs

Image 3.1: Exploded view of the Gamtimer Gaming Chair components, including the backrest, seat, armrests, base, wheels, and gas lift.

Typical components include:

- Backrest
- Seat Cushion

- Armrests (pre-attached or separate)
- Star Base
- Casters (Wheels)
- Gas Lift Cylinder
- Gas Lift Cover
- Mechanism Plate
- Lumbar Support Pillow
- Headrest Pillow
- Hardware (screws, washers, Allen key)
- Footrest (if applicable)

4. SETUP AND ASSEMBLY

Follow these steps carefully to assemble your Gamtimer Gaming Chair. It is recommended to have a second person assist with some steps for easier assembly.

1. **Attach Casters to Base:** Insert the five casters into the holes at the end of each leg of the star base. Push firmly until they click into place.
2. **Install Gas Lift:** Place the gas lift cylinder into the center hole of the star base. Cover it with the gas lift cover.
3. **Attach Mechanism Plate to Seat:** Align the mechanism plate with the pre-drilled holes on the underside of the seat cushion. Ensure the front of the mechanism (usually indicated by an arrow or "FRONT") faces the front of the seat. Secure with screws using the provided Allen key.
4. **Attach Armrests to Seat:** If armrests are not pre-attached, align them with the holes on the sides of the seat cushion. Secure them with screws.
5. **Attach Backrest to Seat:** Align the backrest with the mounting brackets on the seat cushion (or armrests, depending on design). Secure with screws.
6. **Connect Seat to Gas Lift:** Carefully place the assembled seat and backrest onto the gas lift cylinder, ensuring the center hole of the mechanism plate aligns with the top of the gas lift. Press down firmly to secure.
7. **Attach Pillows:** Attach the lumbar support pillow and headrest pillow using their straps, positioning them for optimal comfort.



5. OPERATING INSTRUCTIONS

Your Gamtimer Gaming Chair offers several adjustable features to customize your seating experience:

- **Height Adjustment:** To adjust the chair height, pull the lever located on the right side of the seat (when seated) upwards. To raise the chair, lift the lever while taking your weight off the seat. To lower the chair, lift the lever while remaining seated. Release the lever to lock the height.
- **Backrest Recline:** The backrest can recline from 90° (upright) to 155° (relaxed). Pull the recline lever (typically on the right side, below the seat) upwards and lean back to your desired angle. Release the lever to lock the backrest in place.
- **Retractable Footrest:** To use the footrest, pull it out from underneath the seat. Extend it fully and rest your feet. To retract, push it back in until it is fully concealed.
- **360° Swivel:** The chair can freely rotate 360 degrees, allowing for easy movement and access to your surroundings without needing to move the entire chair.
- **Lumbar and Headrest Pillows:** The included lumbar support and headrest pillows are adjustable. Slide them up or down along their straps to find the most comfortable position for your neck and lower back.

ERGONOMIC BACKREST

relieves long working hours and pressure on lumbar and cervical vertebrae. Reduce fatigue



Image 5.1: Illustration of the chair's adjustable features, including recline angles, height adjustment, 360-degree swivel, and the concealed pull-out footrest.



Image 5.2: Diagram highlighting the ergonomic design of the backrest, providing support for the neck, shoulders, back, and lumbar region to relieve pressure.

6. MAINTENANCE AND CARE

Proper care will extend the life and appearance of your Gamtimer Gaming Chair:

- **Cleaning:** For general cleaning, wipe the PU leather with a soft, damp cloth. For stubborn stains, use a mild soap solution and wipe dry immediately. Avoid harsh chemicals, abrasive cleaners, or solvents, as these can damage the material.
- **Hardware Check:** Periodically check all screws and bolts to ensure they are tight. Re-tighten if necessary to maintain stability and prevent squeaking.
- **Caster Care:** Keep the casters clean by removing any hair or debris that may accumulate around them. This ensures smooth rolling.
- **Avoid Direct Sunlight:** Prolonged exposure to direct sunlight can cause the PU leather to fade or crack.

- **Weight Distribution:** Avoid concentrating weight on one specific area for extended periods to prevent premature wear.

7. TROUBLESHOOTING

If you encounter any issues with your chair, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Chair is wobbly or unstable.	Loose screws or improper assembly.	Check all screws and bolts and tighten them securely. Ensure all parts are correctly assembled according to the manual.
Chair makes squeaking noises.	Loose connections or friction between parts.	Tighten all screws. Apply a small amount of silicone lubricant to moving parts or joints if the noise persists.
Gas lift not adjusting height.	Lever not fully engaged or gas lift malfunction.	Ensure the height adjustment lever is fully pulled. If the issue persists, the gas lift may need replacement. Contact customer support.
Backrest not reclining or locking.	Recline lever not fully engaged or mechanism obstruction.	Ensure the recline lever is fully pulled and released. Check for any obstructions in the recline mechanism.
Casters not rolling smoothly.	Debris caught in casters or damaged casters.	Remove any hair, dust, or debris from the caster wheels. If damaged, casters may need replacement.

If the problem persists after trying these solutions, please contact Gamtimer customer support for further assistance.

8. PRODUCT SPECIFICATIONS

Feature	Detail
Brand	Gamtimer
Model Name	CHAIR (G-08)
Color	Black
Product Dimensions	23"D x 21"W x 51"H
Maximum Weight Recommendation	400 Pounds
Back Style	Wing Back

Feature	Detail
Special Feature	Ergonomic backrest, Retractable footrest, Linked armrests
Reclining Position Count	3 (90° to 155°)
Fill Material	Foam (4D Thickened Sponge)
Included Components	Lumbar and headrest pillows
Item Weight	42 pounds
Manufacturer	Gamtimer




Image 8.1: Detailed dimensions of the Gamtimer Gaming Chair.

9. WARRANTY AND CUSTOMER SUPPORT

Gamtimer is committed to providing high-quality products and excellent customer service.

- **Warranty:** This chair includes a 1-year repair warranty from the date of purchase. This warranty covers manufacturing defects and material flaws under normal use.
- **Return Policy:** A 30-day return policy is available from the date of purchase. Please refer to your retailer's specific return guidelines.
- **Replacement Parts:** Our in-house factory ensures that replacement parts are identical to the originals, providing seamless maintenance and longevity for your chair.
- **Customer Service:** For any questions, concerns, or warranty claims, our professional after-sales team is available for 7x24 hours service. Please contact us through the retailer's platform or the official Gamtimer website for assistance.

We are dedicated to ensuring your satisfaction with your Gamtimer Gaming Chair.