

[manuals.plus](#) /› [innioasis](#) /› [Innioasis Y1 MP3 Player with Bluetooth - User Manual](#)**innioasis Y1**

Innioasis Y1 MP3 Player with Bluetooth - User Manual

Model: Y1

1. INTRODUCTION

This manual provides detailed instructions for the setup, operation, and maintenance of your Innioasis Y1 MP3 Player. Please read this manual thoroughly to ensure proper usage and to maximize your device's capabilities. The Innioasis Y1 is a portable digital music player designed for high-fidelity audio playback, video viewing, and audiobook listening, featuring Bluetooth connectivity and a classic click wheel interface.

2. PRODUCT OVERVIEW

2.1 Device Components

Familiarize yourself with the main components and controls of your Innioasis Y1 MP3 Player.

Powerful Management for Categories and Playlist



Figure 1: Front view of the Innioasis Y1 MP3 Player, highlighting the display screen and the circular click wheel for navigation and control.




Figure 2: Side view of the Innioasis Y1 MP3 Player, illustrating the headphone jack, USB-C charging port, and integrated speaker grille.

3. SETUP

3.1 Charging the Device

Before first use, fully charge your Innioasis Y1 MP3 Player. Connect the provided USB-C cable to the device's charging port and the other end to a compatible USB power adapter or a computer's USB port. The battery indicator on the screen will show charging status.

3.2 Transferring Files

To transfer music, videos, or audiobooks to your device:

1. Connect the Innioasis Y1 to your computer using the USB-C cable.
2. The device will appear as a removable disk drive on your computer.
3. Drag and drop your desired files into the appropriate folders (e.g., 'Music', 'Videos', 'Audiobook') on the device.
4. Safely eject the device from your computer before disconnecting the cable.

4. OPERATING INSTRUCTIONS

4.1 Basic Navigation

The Innioasis Y1 features a classic click wheel for intuitive navigation. Use the outer ring to scroll through menus and lists, and the center button to select items. Dedicated buttons are available for play/pause, skip forward/backward, and menu access.



Figure 3: Illustration of the classic click wheel control on the Innioasis Y1, demonstrating touch and rotate functionality for navigation.

4.2 Playing Music

Navigate to the 'Music' menu. You can browse by 'All songs', 'Playlists', 'Artists', 'Albums', 'Genres', or 'Folders'. Select a song to begin playback. The device supports various audio formats including MP3, WAV, FLAC, APE, OGG, M4A, AAC, WMA, MP2, and AMR.




Figure 4: The Innioasis Y1 displaying music playback with album art and a list of supported music formats.

4.3 Bluetooth Connectivity

To connect to Bluetooth headphones or speakers:

1. Go to the 'Bluetooth' menu from the home screen.
2. Turn Bluetooth 'On'.
3. The device will scan for available Bluetooth devices.
4. Select your desired device from the list to pair.

Bluetooth *

Fast Pairing, Stable Connection



Bluetooth
Earphone



Bluetooth
Speaker



Car Bluetooth
Speaker



Figure 5: The Innioasis Y1 displaying its Bluetooth menu, showing available devices for fast pairing and stable connection.

4.4 Video Playback

The Innioasis Y1 supports 720p video playback. Transfer video files to the 'Videos' folder. Navigate to the 'Videos' menu and select a file to play. For optimal viewing, ensure videos are in compatible formats.




Figure 6: The Innioasis Y1 displaying a video, illustrating its capability for 720p video playback.

4.5 Audiobook Functionality

The device supports audiobooks. Place audiobook files into the 'Audiobook' folder on the device. While an audiobook is playing, you can long-press to create a bookmark. Bookmarks are listed under the 'Audio Books' menu for easy access.



Figure 7: The Innioasis Y1 displaying a list of audiobooks, demonstrating its audiobook support and bookmark management features.

4.6 FM Radio

Access the 'FM radio' option from the home screen to listen to local radio stations. Ensure headphones are

connected as they often act as the antenna.

5. FEATURES

- **Storage Capacity:** 128 GB internal memory.
- **HiFi Sound:** Supports equalizer settings for personalized audio experience.
- **Long Battery Life:** Up to 35 hours of music playback with wired headphones (50% volume) and 4 hours of video support (50% brightness, max built-in speaker).
- **Classic Click Wheel Control:** Intuitive and responsive navigation.
- **Video Support:** Enjoy 720p video playback.
- **Audiobook Support:** Includes bookmark management.
- **Connectivity:** Bluetooth for wireless audio, USB-C for charging and data transfer.
- **Integrated Speaker:** Allows audio playback without headphones.



Figure 8: The Innioasis Y1 highlighting its HiFi Sound capabilities and equalizer support.



Figure 9: The Innioasis Y1 illustrating its long battery life, providing 35 hours for music and 4 hours for video playback.

6. MAINTENANCE

6.1 Screen Care

The device's screen cover is made of a soft plastic material. To prevent scratches, it is highly recommended to apply a screen protector immediately after purchase. Avoid placing the device in direct contact with sharp objects or abrasive materials.

6.2 General Cleaning

Use a soft, dry, lint-free cloth to clean the device. Do not use liquid cleaners or aerosols, as they may damage the device.

6.3 Battery Care

To prolong battery life, avoid fully discharging the device frequently. Charge the device regularly, even if not in use for extended periods. Store the device in a cool, dry place.

7. TROUBLESHOOTING

7.1 Device Not Powering On

Ensure the device is fully charged. Connect it to a power source and allow it to charge for at least 30 minutes before attempting to power it on again.

7.2 Files Not Appearing on Device

Verify that files have been transferred to the correct folders (Music, Videos, Audiobook). Ensure the file formats are supported by the device. If issues persist, try re-transferring the files or restarting the device.

7.3 Bluetooth Pairing Issues

Ensure the Bluetooth feature is enabled on both the MP3 player and the target device. Place devices within close proximity during pairing. If pairing fails, try restarting both devices and attempting to pair again.

7.4 Screen Damage or Detachment

Due to the soft plastic screen cover, physical impact or prolonged stress may cause scratches or potential detachment of the screen. Handle the device with care and consider using a protective case.

8. SPECIFICATIONS

Feature	Specification
Product Dimensions	3.86 x 2.4 x 0.35 inches
Item Weight	5.6 ounces (0.16 Kilograms)
Model Name	Y1
Connectivity Technology	Bluetooth
Memory Storage Capacity	128 GB
Color	Black
Screen Size	1.8 Inches
Compatible Devices	Headphone, Earphone, Smartphone
Display Technology	LCD
Supported Standards	MP3, AAC, FLAC, WAV, WMA, OGG, MP4, M4A, AMR
Batteries	1 Nonstandard Battery (included)
Manufacturer	Innioasis

9. WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the documentation included with your purchase or visit the official Innioasis website. Keep your proof of purchase for any warranty claims.

