## Bellemave WL000022DTW-1

# Bellemave Twin Over Twin House Bunk Bed Instruction Manual

Model: WL000022DTW-1

## 1. Important Safety Information

Please read all instructions carefully before assembly and use of this bunk bed. Keep this manual for future reference.

- **WARNING:** The top bunk is not suitable for children under six years of age.
- **WARNING:** Bunk beds should not be used by more than one person on the top bunk at a time.
- **WARNING:** Ensure all guardrails are properly installed and secured before use.
- **WARNING:** Use only mattresses that are 74-75 inches long and 37.5-38.5 inches wide for both top and bottom bunks. The maximum mattress thickness for the top bunk should not exceed 6 inches to ensure proper guardrail height.
- **WARNING:** Do not attach or hang items to any part of the bunk bed that are not designed for use with the bed; for example, but not limited to, hooks, belts, and jump ropes.
- Periodically check and ensure that all connectors are tight.
- Do not allow jumping on the bed.
- Always use the ladder for entering and exiting the top bunk.

## 2. Package Contents

Verify that all components listed below are present and undamaged before beginning assembly. If any parts are missing or damaged, please contact Bellemave customer support.

- Headboard and Footboard panels
- Side rails for both bunks
- Guardrails
- Ladder components
- Bed slats
- House roof frame components

- Hardware pack (screws, bolts, nuts, Allen wrench)
- Assembly Instruction Manual



Image 1: Bellemave Twin Over Twin House Bunk Bed (White)

## 3. Specifications

| Feature | Detail |
|---|---|
| Product Dimensions | 78.61"L x 43.11"W x 70.71"H |
| Size | Twin over Twin |
| Material | Pine Wood and MDF |
| Color | White |
| Item Weight | 132.3 pounds |
| Assembly Required | Yes |
| Compatible Mattress Size | Twin (Mattress not included) |
| Special Features | No Box Spring Needed, Slatted, Space Saving, House Roof Design, Full-Length Guardrail |





Image 2: Detailed dimensions of the Bellemave Twin Over Twin House Bunk Bed.

## 4. Setup and Assembly Instructions

Assembly typically requires two adults. Please follow the detailed step-by-step instructions provided in the separate assembly manual included in your package. Ensure all hardware is securely tightened, but do not overtighten.

### Tools Required (Not Included):

- Phillips Head Screwdriver
- Hammer (optional, for dowels)

### General Assembly Steps:

1. **Unpack and Identify Parts:** Lay out all components and hardware. Compare them with the parts list in your assembly manual.
2. **Assemble Bed Ends:** Attach the headboard and footboard panels to the vertical posts for both the top and bottom bunks.
3. **Attach Side Rails:** Connect the side rails to the assembled bed ends for both bunks.
4. **Install Bed Slats:** Securely attach the wooden slats to the side rails of both bunks. Ensure even spacing for proper mattress support.
5. **Assemble House Roof Frame:** Connect the roof frame components according to the manual.

6. **Attach Guardrails:** Install the full-length guardrails on the top bunk. Verify they are firmly secured.
7. **Attach Ladder:** Securely attach the built-in ladder to the bunk bed frame.



Image 3: Close-up view of the built-in ladder and lower bunk side panel.



Image 4: Detail of the wooden slats providing mattress support and the ladder connection.



Image 5: Close-up of the house-shaped roof frame design.

## 5. Operating Instructions

Once assembled, the Bellemave Twin Over Twin House Bunk Bed is ready for use. Observe the following guidelines for safe operation:

- **Mattress Placement:** Place twin-sized mattresses directly onto the wooden slats. No box spring is required. Ensure the top bunk mattress does not exceed the maximum recommended thickness of 6 inches.
- **Ladder Use:** Always use the built-in ladder to access and exit the top bunk. Do not climb on the side rails or other parts of the bed.
- **Weight Limits:** Adhere to the recommended weight limits for each bunk (refer to the separate assembly manual for specific limits, typically around 175 lbs for the top bunk and 250 lbs for the bottom bunk).
- **Supervision:** Children using the top bunk should be supervised, especially during initial use.

## 6. Maintenance

Regular maintenance will help prolong the life and safety of your bunk bed.

- **Cleaning:** Wipe down the bed frame with a soft, damp cloth. Avoid using harsh chemicals or abrasive cleaners, as these can damage the finish.
- **Hardware Check:** Periodically (e.g., every 3-6 months) inspect all bolts, screws, and connections to ensure they

are tight. Retighten as necessary to prevent wobbling or instability.

- **Slat Inspection:** Check the wooden slats for any signs of damage or cracking. Replace any damaged slats immediately.
- **Avoid Excessive Moisture:** Keep the bed in a dry environment to prevent wood warping or damage.

## 7. Troubleshooting

If you encounter any issues with your bunk bed, refer to the following common solutions:

- **Wobbling or Instability:** This is usually caused by loose hardware. Re-check and tighten all bolts and screws throughout the entire frame.
- **Squeaking Noises:** Squeaking can result from loose connections or friction between wood parts. Ensure all hardware is tight. Applying a small amount of paraffin wax or silicone spray to contact points (where wood meets wood or metal) can help.
- **Damaged Parts:** If any structural part of the bed is damaged, discontinue use immediately and contact customer support for replacement parts. Do not attempt to repair damaged structural components yourself.

## 8. Warranty and Support

For any questions, missing parts, or concerns regarding your Bellemave Twin Over Twin House Bunk Bed, please contact Bellemave customer support. Refer to your purchase documentation for specific warranty details and contact information. Please have your model number (WL000022DTW-1) and purchase date available when contacting support.