Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

VASAGLE LSC092W01

VASAGLE LSC092W01 Storage Unit Instruction Manual

Model: LSC092W01

1. Introduction

Thank you for choosing the VASAGLE LSC092W01 Storage Unit. This versatile sideboard, featuring two sliding doors and adjustable shelves, is designed to enhance your living space, whether in the kitchen, living room, or office. This manual provides essential information for safe assembly, proper usage, and maintenance to ensure the longevity and optimal performance of your product.



Image 1.1: The VASAGLE LSC092W01 Storage Unit, a rustic white and honey brown sideboard with sliding doors, used in a home environment.

2. Safety Instructions

Please read and understand all safety instructions before assembly and use. Failure to follow these instructions may result in injury or damage to the product.

- **Weight Capacity:** Do not exceed the maximum weight capacity of the unit. The top surface can support items, but avoid

placing excessively heavy objects. The overall unit is designed for stability under normal use.

- **Anti-Tip Kit:** Always install the included anti-tip kit to prevent the unit from tipping over, especially in households with children or pets. Securely fasten the unit to a wall stud using appropriate hardware.
- **Stable Placement:** Place the storage unit on a flat, level, and stable surface. Use the adjustable feet to compensate for uneven floors and ensure maximum stability.
- **Assembly:** Assemble the unit strictly according to the instructions provided. Do not modify the product or use parts not supplied by the manufacturer.
- **Children Safety:** Keep small parts and packaging materials away from children during assembly. Do not allow children to climb on or play with the unit.



Image 2.1: Dimensions of the storage unit (80 cm height, 100 cm width, 33 cm depth) and its robust design capable of supporting up to 217 kg.



Image 2.2: Details of the anti-tip kit for wall mounting, the 3 cm thick top panel, and the adjustable feet for leveling the unit.

3. Package Contents

Before beginning assembly, please ensure all parts are present and undamaged. Refer to the included assembly instructions for a detailed list of components. Typically, your package will contain:

- Main structural panels (top, bottom, side panels)

- Sliding doors and associated hardware (tracks, rollers, handles)
- Adjustable shelves and shelf pins
- Metal frame components and adjustable feet
- Anti-tip kit
- Assembly hardware (screws, dowels, cam locks, etc.)
- Assembly tools (e.g., Allen wrench, screwdriver - sometimes included)
- Illustrated instruction manual

If any parts are missing or damaged, please contact customer support for assistance.

4. Assembly and Setup

Assembly of the VASAGLE LSC092W01 Storage Unit is designed to be straightforward with the provided illustrated instructions and numbered parts. It is recommended to have two people for assembly.

1. **Prepare Your Workspace:** Clear a spacious, clean, and soft area to prevent scratching the furniture during assembly.
2. **Identify Parts:** Lay out all components and hardware. Match them with the numbered diagrams in the instruction manual.
3. **Follow Instructions:** Assemble the unit step-by-step as shown in the illustrated manual. Pay close attention to the orientation of each piece.
4. **Secure Connections:** Ensure all screws, cam locks, and other fasteners are tightened securely, but do not overtighten to avoid damaging the material.
5. **Install Adjustable Feet:** Attach the adjustable feet to the bottom of the unit. Once the unit is in its final position, adjust the feet to ensure the unit is level and stable.
6. **Install Anti-Tip Kit:** For safety, always install the anti-tip kit. Follow the specific instructions provided with the kit to secure the unit to a wall stud.



Image 4.1: Detailed view of the anti-tip kit attachment to the wall and the adjustable feet for leveling the unit.

5. Operating and Usage

The VASAGLE LSC092W01 Storage Unit offers flexible storage solutions for various items.

- **Sliding Doors:** The two barn-style sliding doors operate smoothly on their tracks. Gently slide them left or right to access the compartments. Ensure the tracks are kept clear of debris for optimal function.

- **Adjustable Shelves:** The unit features three adjustable shelves within its six compartments. These shelves can be moved to three different height levels or removed entirely to accommodate items of various sizes. To adjust, remove the shelf pins, reposition the shelf to the desired height, and reinsert the pins securely.
- **Top Surface:** The sturdy top surface (33 x 100 cm) provides additional space for decorative items, small appliances, or frequently used objects.



Image 5.1: The interior of the storage unit, demonstrating how various items can be organized on the adjustable shelves.



Image 5.2: Close-up of the shelf adjustment mechanism, indicating 3.2 cm increments for shelf placement.

6. Maintenance

Proper care and maintenance will help preserve the appearance and functionality of your storage unit.

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid using harsh chemicals, abrasive cleaners, or polishes that may damage the finish.

- **Spills:** Clean up spills immediately to prevent staining or damage to the chipboard.
- **Hardware Check:** Periodically check all screws and fasteners to ensure they remain tight. Retighten if necessary.
- **Avoid Direct Sunlight/Heat:** Prolonged exposure to direct sunlight or extreme heat can cause fading or warping.
- **Sliding Door Tracks:** Keep the sliding door tracks free of dust and debris to ensure smooth operation.

7. Troubleshooting

If you encounter any issues with your storage unit, refer to the following common solutions:

- **Unit is Wobbly:**
  - Ensure the unit is on a flat surface.
  - Adjust the leveling feet at the bottom of the unit until it is stable.
  - Check all assembly screws and tighten them if loose.
- **Sliding Doors are Sticking:**
  - Inspect the tracks for any debris or obstructions and clear them.
  - Ensure the doors are properly seated in their tracks.
  - Check if any hardware on the doors or tracks is loose or misaligned.
- **Missing or Damaged Parts:**
  - Review the package contents list and assembly instructions carefully.
  - Contact VASAGLE customer support with your model number and a description of the issue.

8. Specifications

Model Number	LSC092W01
Brand	VASAGLE
Dimensions (L x W x H)	100 x 33 x 80 cm (39.37 x 12.99 x 31.5 inches)
Item Weight	25.6 Kilograms
Color	Rustic White + Honey Brown
Material	Chipboard, Steel
Door Style	Shaker (Sliding Barn Doors)
Mounting Type	Floor Mount (with Anti-Tip Kit)
UPC/GTIN	194343411293

9. Warranty and Support

VASAGLE is committed to providing high-quality products and customer satisfaction. For specific warranty information, please refer to the documentation included with your purchase or visit the official VASAGLE website.
If you have any questions, require assistance with assembly, or need to report missing/damaged parts, please contact VASAGLE customer support. Have your model number (LSC092W01) and purchase details ready for faster service.
You can often find support contact information on the manufacturer's website or through your retailer.

© 2026 VASAGLE. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0F1MV6711

More documents and user manuals: **https://manuals.plus/**