

RAPOO MT560

Rapoo MT560 Wireless Mouse User Manual

Model: MT560 | Brand: RAPOO

INTRODUCTION

This manual provides comprehensive instructions for the setup, operation, and maintenance of your Rapoo MT560 Wireless Mouse. Please read this manual carefully before using the product to ensure optimal performance and longevity. The Rapoo MT560 is an advanced wireless mouse designed for comfort and functionality. It supports multi-mode wireless connectivity, including 2.4 GHz, Bluetooth 4.0, and Bluetooth 5.0, allowing seamless switching between multiple devices. Its high-performance 4000 DPI sensor ensures precise navigation on various surfaces, and the integrated rechargeable battery offers extended use without frequent battery changes.

PRODUCT OVERVIEW



Figure 1: Top view of the Rapoo MT560 Wireless Mouse, showing the scroll wheel and main buttons.



Figure 2: Angled front view of the mouse, highlighting its ergonomic shape.



Figure 3: Side view of the mouse, displaying the two programmable side buttons and horizontal scroll wheel.



Figure 4: Bottom view of the mouse, showing the optical sensor, power switch, and mode selection button.

SETUP

Charging the Mouse

The Rapoo MT560 mouse comes with an integrated rechargeable lithium battery. Before first use, it is recommended to fully charge the mouse.

- Connect the provided USB charging cable to the charging port on the mouse.
- Connect the other end of the USB cable to a powered USB port on your computer or a USB wall adapter.
- The charging indicator light will illuminate. Once fully charged, the light may change color or turn off.
- A full charge can last up to 25 days of typical use.

Connecting the Mouse

The MT560 supports multi-mode wireless connection. You can connect it via 2.4 GHz wireless (USB receiver) or Bluetooth (3.0, 4.0, or 5.0).

2.4 GHz Wireless Connection:

1. Locate the USB receiver, usually stored in a compartment on the bottom of the mouse.

2. Plug the USB receiver into an available USB port on your computer.
3. Turn on the mouse using the power switch on the bottom.
4. Press the mode switch button on the bottom of the mouse until the indicator light for 2.4G mode is active.
5. Your computer should automatically detect and install the necessary drivers. The mouse is ready for use.

Bluetooth Connection:

The mouse supports connecting to up to two Bluetooth devices (BT1 and BT2).

1. Turn on the mouse using the power switch on the bottom.
2. Press the mode switch button on the bottom of the mouse to select either BT1 or BT2 mode. The corresponding indicator light will blink slowly.
3. Press and hold the mode switch button for approximately 3 seconds until the BT1 or BT2 indicator light starts blinking rapidly. This indicates the mouse is in pairing mode.
4. On your computer or device, open Bluetooth settings.
5. Search for new devices and select "Rapoo MT560" from the list.
6. Follow any on-screen prompts to complete the pairing process.
7. Once paired, the indicator light will stop blinking and remain solid for a few seconds before turning off.

Note: The mouse can automatically pair with previously connected Bluetooth devices when in the correct mode.

OPERATING INSTRUCTIONS

DPI Adjustment

The Rapoo MT560 features an adjustable 4000 DPI optical sensor for precise cursor control. You can cycle through different DPI settings to match your preference or task requirements.

- Locate the DPI switch button, typically found near the scroll wheel on the top of the mouse.
- Press the DPI button to cycle through available DPI settings (e.g., 800, 1200, 1600, 2400, 4000 DPI).
- Observe the cursor speed on your screen to determine the desired DPI setting.

Multi-Device Switching

The MT560 allows seamless switching between up to three connected devices (one 2.4 GHz and two Bluetooth devices).

- To switch between connected devices, simply press the mode switch button on the bottom of the mouse.
- Each press will cycle through the 2.4G, BT1, and BT2 modes.
- The corresponding indicator light will briefly illuminate to confirm the selected mode.

Ergonomic Design and Buttons

The mouse is designed for right-handed users, providing comfort during extended use. It features 9 programmable buttons and two scroll wheels.

- **Left/Right Click:** Standard mouse functions.
- **Main Scroll Wheel:** Vertical scrolling.
- **Side Scroll Wheel:** Horizontal scrolling, useful for wide documents or spreadsheets.
- **Side Buttons:** Typically used for forward/back navigation in web browsers or file explorers. These can often be customized via software (if available from Rapoo).
- **DPI Button:** Adjusts cursor sensitivity.
- **Mode Switch Button (bottom):** Switches between 2.4G, BT1, and BT2 modes.

MAINTENANCE

Cleaning the Mouse

Regular cleaning helps maintain the performance and appearance of your mouse.

- Ensure the mouse is turned off before cleaning.
- Use a soft, lint-free cloth slightly dampened with water or a mild, non-abrasive cleaner.
- Gently wipe the surface of the mouse.
- For the optical sensor, use a cotton swab or compressed air to remove any dust or debris.
- Avoid using harsh chemicals, abrasive pads, or excessive moisture.

Battery Care

The integrated rechargeable battery is designed for long life. Follow these tips to maximize battery longevity:

- Avoid fully discharging the battery frequently.
- Store the mouse in a cool, dry place if not used for extended periods.
- Charge the mouse when the battery low indicator (if present) illuminates or when performance degrades.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Mouse not responding	Low battery; Mouse turned off; Incorrect connection mode; USB receiver not connected (2.4G); Bluetooth not paired.	Charge the mouse; Turn on the mouse; Ensure correct mode (2.4G/BT1/BT2) is selected; Re-insert USB receiver; Re-pair Bluetooth device.
Cursor movement is erratic or jumpy	Dirty optical sensor; Unsuitable surface; Interference.	Clean the optical sensor; Use the mouse on a clean, non-reflective surface (e.g., mouse pad); Move mouse closer to receiver/device; Reduce other wireless interference.
Cannot connect via Bluetooth	Mouse not in pairing mode; Bluetooth on device is off; Device already connected to maximum Bluetooth devices.	Ensure mouse is in BT pairing mode (rapid blinking light); Turn on Bluetooth on your device; Disconnect other Bluetooth devices if necessary.
DPI adjustment not working	Button malfunction; Software conflict.	Ensure you are pressing the correct DPI button; Restart your computer; Check for any Rapoo software that might override settings.

SPECIFICATIONS

Model Name	MT560
Brand	RAPOO
Connectivity Technology	2.4 GHz Wireless, Bluetooth 3.0, Bluetooth 4.0, Bluetooth 5.0

Movement Detection Technology	Optical
DPI Sensor	Adjustable up to 4000 DPI
Number of Buttons	9
Hand Orientation	Right
Power Source	Rechargeable Lithium Battery
Battery Life	Up to 25 days (average use) / 1 month (as per specifications)
Compatible Operating Systems	Windows 11, Windows 10, Mac OS 11 Big Sur, Linux, Chrome OS
Compatible Devices	Laptop, Desktop, Smartphone, Tablet
Product Dimensions	10.6 x 7 x 0.1 cm; 82 g
Color	Black
Special Features	Wireless, Lightweight, Rechargeable, Ergonomic Design, Soundless

WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the official RAPOO website or contact their customer service directly. Keep your purchase receipt as proof of purchase for warranty claims.

Online Resources:

- [RAPOO Official Website](#) (for drivers, software, and FAQs)
- [RAPOO Support Page](#)

Note: Warranty terms and conditions may vary by region. Please consult the documentation included with your product or the official website for specific details.

© 2025 RAPOO. All rights reserved. Information in this manual is subject to change without notice.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0F1MW5FM9>

More documents and user manuals: <https://manuals.plus/>