

[Manuals.plus](#) /

› [LEDIARY](#) /

› LEDIARY 20" Caged Ceiling Fan with Light User Manual

LEDIARY B0F1MWP7P5

LEDIARY 20" Caged Ceiling Fan with Light User Manual

Model: B0F1MWP7P5

INTRODUCTION

This manual provides detailed instructions for the installation, operation, and maintenance of your LEDIARY 20" Caged Ceiling Fan with Light. Please read this manual thoroughly before installation and use to ensure safe and efficient operation of the product. Keep this manual for future reference.

SAFETY INFORMATION

Always follow basic safety precautions when installing and operating electrical appliances. Ensure power is disconnected at the circuit breaker before installation or maintenance. Consult a qualified electrician if you are unsure about any part of the installation process. Do not attempt to repair the unit yourself.

WHAT'S IN THE BOX

Verify that all components are present before beginning installation.

- Caged Ceiling Fan Unit
- Remote Control (2 AAA batteries included)
- Instruction Manual (this document)
- Mounting Hardware Kit



6 Speeds Adjustable

Choose the Wind Speed According to Your Need



1-2 Speeds
Comfortable Wind



3-4 Speeds
Natural Wind



5-6 Speeds
Cool Wind

Figure 1: Included components for the LEDIARY 20" Caged Ceiling Fan. Ensure all parts are accounted for before proceeding with installation.

SETUP AND INSTALLATION

This section guides you through the process of installing your ceiling fan. It is recommended to have two people for installation.

1. **Preparation:** Turn off power at the main circuit breaker. Clear the installation area.
2. **Mounting Bracket Installation:** Secure the mounting bracket to the ceiling junction box using appropriate screws. Ensure it is firmly attached to support the fan's weight.
3. **Wiring:** Connect the fan's electrical wires to the household wiring (Live, Neutral, Ground) according to local electrical codes. The fan includes a hook on a wire to temporarily hang the fan during wiring, simplifying the process.
4. **Fan Assembly:** Attach the fan unit to the mounting bracket. Ensure all connections are secure.
5. **Bulb Installation:** Install four E26 base bulbs (not included) into the light sockets. Recommended bulbs: A19 ST19 T45, incandescent bulbs up to 60W, LED bulbs up to 10W.
6. **Final Check:** Verify all connections are tight and the fan is securely mounted. Restore power at the circuit breaker.



Figure 2: Detailed view of the fan's internal components, including the powerful copper motor and modern 7-blade design, which contribute to its quiet and efficient operation.

OPERATING INSTRUCTIONS

Your LEDIARY ceiling fan can be controlled via the included remote control or a dedicated smartphone application.

Remote Control Operation

The remote control allows for convenient adjustment of fan speed, light settings, and other functions.

- **Power On/Off:** Press the power button to turn the fan and light on or off.
- **Fan Speed:** Select from 6 available fan speeds (1-6) to adjust airflow intensity.
- **Light Control:** Independently turn the light on or off.
- **Timer Function:** Set the fan to automatically turn off after 1, 2, 4, or 8 hours.
- **Reversible Mode (F/R):** Switch between summer mode (downward airflow for cooling) and winter mode (upward airflow for heat distribution).



APP & Remote Control

✧ Tips: APP control needs Bluetooth



Speed Control



Timer Setting



Reverse Function



Turn On/Off



Fan On/Off



Figure 3: The fan can be controlled via the included remote or a smartphone app, offering comprehensive control over fan and light functions.

Smartphone App Control

For enhanced control and smart features, download the LEDIARY app from your device's app store. Bluetooth connection

is required for app control.

- **Pairing:** Follow the app's instructions to pair your smartphone with the fan via Bluetooth.
- **Full Functionality:** Access all remote control features, including speed adjustment, timer, light control, and reversible mode.

Fan Speed and Airflow

The fan offers 6 speed settings to suit various comfort levels and room sizes.

- **1-2 Speeds:** Provides a comfortable, gentle breeze, ideal for sleeping or quiet environments.
- **3-4 Speeds:** Offers natural wind circulation, suitable for general daily use.
- **5-6 Speeds:** Delivers a strong, cool wind for maximum air circulation.



Silent Operation Ceiling Fan



6 Fan Speeds



1/2/4/8H Timing



Powerful Motor



Quiet Operation



0dB
Mute



15dB
Library



30dB
Our Ceiling Fan



40-60dB
Chat



60-80dB
Meeting



Figure 4: Choose from 6 wind speeds to match your comfort preference, from a gentle breeze to strong airflow.

Reversible Airflow Function

The reversible motor allows for year-round comfort by optimizing air circulation for different seasons.

- **Summer Mode (Downward Airflow):** Blades rotate counter-clockwise, pushing cool air down to create a cooling effect.
- **Winter Mode (Upward Airflow):** Blades rotate clockwise, drawing air up towards the ceiling to redistribute warm air evenly throughout the room.



20" for Normal Size Room



E26*4 (Not Included)

Recommended Bulbs :



LED Edison
Bulb A19



LED Bulb
ST19



LED Bulb
A19



LED Edison
Bulb ST19



Edison LED
Bulb T14



E26 Medium Base

LED Light Bulb - Max 10W

Figure 5: Utilize the reversible function to optimize air circulation for cooling in summer and warming in winter.

Quiet Operation

The fan is designed with a pure copper DC motor for quiet operation, ensuring minimal disturbance.



Figure 6: The fan operates at approximately 30dB, comparable to a quiet whisper, making it suitable for bedrooms and living areas.

MAINTENANCE

Regular maintenance ensures optimal performance and longevity of your ceiling fan.

- **Cleaning:** Before cleaning, ensure the power is turned off at the circuit breaker. Use a soft, damp cloth to wipe down the fan housing and blades. Do not use abrasive cleaners or solvents.
- **Bulb Replacement:** Ensure power is off before replacing bulbs. Allow bulbs to cool completely. Replace with E26 base bulbs as specified in the Setup section.
- **Tightening Screws:** Periodically check and tighten all screws on the mounting bracket and fan assembly to prevent wobbling or noise.

TROUBLESHOOTING

This section addresses common issues you might encounter with your ceiling fan.

Problem	Possible Cause	Solution
Fan does not operate.	No power supply; loose wiring; remote control battery low.	Check circuit breaker. Verify wiring connections. Replace remote control batteries.
Light does not turn on.	Bulbs not installed or faulty; loose wiring.	Ensure bulbs are correctly installed and functional. Check light wiring connections.
Fan wobbles.	Loose mounting screws; unbalanced blades.	Tighten all mounting screws. Ensure blades are securely attached.
Remote control not working.	Batteries depleted; remote not paired.	Replace batteries. Refer to pairing instructions in the app or manual.

SPECIFICATIONS

Feature	Detail
Brand	LEDIARY
Model	B0F1MWP7P5
Color	Gold-dusted Black
Material	Iron
Product Dimensions	17"L x 13"W x 7"H (approx. 20 inch diameter)
Item Weight	9.48 pounds
Power Source	DC Motor
Installation Type	Flush Mount

Feature	Detail
Control Method	App, Remote Control
Number of Light Sources	4
Bulb Base	E26 (Bulbs not included)
Special Features	Remote Controlled, Energy Efficient, Timer, 6 Wind Speeds, Reversible Mode



Airflow Circulation

Cool in Summer and Warm in Winter




Figure 7: Product dimensions and recommended bulb types for the LEDIARY 20" Caged Ceiling Fan.

WARRANTY AND SUPPORT

For specific warranty information and technical support, please refer to the warranty card included with your product or

contact LEDIARY customer service directly. LEDIARY is committed to providing high-quality products and dedicated customer support.

You can often find contact information on the official LEDIARY website or through the retailer where the product was purchased.

