

LEDIARY LEDIARY 23 Inch Caged Ceiling Fan (B0F1MX2GGZ)

LEDIARY 23" Caged Ceiling Fan with Light User Manual

Model: 23 Inch Caged Ceiling Fan (ASIN: B0F1MX2GGZ)

Brand: LEDIARY

INTRODUCTION

This user manual provides comprehensive instructions for the installation, operation, and maintenance of your LEDIARY 23-inch Caged Ceiling Fan with Light. This low-profile, bladeless fan features a farmhouse and modern design with a vintage white and gold finish. It offers 6 wind speeds, a reversible mode for year-round comfort, and convenient control via both a remote and a mobile application. Please read this manual thoroughly before installation and use to ensure safe and efficient operation.

SAFETY INFORMATION

WARNING: To reduce the risk of fire, electric shock, or personal injury, always follow these basic precautions:

- Read all instructions carefully before installing the fan.
- Ensure the power is turned off at the circuit breaker before beginning installation or performing any maintenance.
- All electrical connections must be in accordance with local codes, ordinances, and the National Electric Code. If you are unfamiliar with proper electrical wiring, consult a qualified electrician.
- Mounting structure must be capable of supporting the fan's weight (approximately 10 pounds).
- Do not operate the fan with a damaged power cord or plug.
- Keep hands, hair, and clothing away from moving parts.
- Do not attempt to repair or modify the fan yourself. Contact customer support for assistance.

WHAT'S IN THE BOX

Carefully unpack all components and ensure you have received all items listed below. If any parts are missing or damaged, contact LEDIARY customer service.

- Caged Ceiling Fan Unit
- Remote Control (2 AAA batteries included)
- Instruction Manual
- Mounting Hardware Kit



Image: Overview of the LEDIARY 23-inch Caged Ceiling Fan, including the main unit, remote control, and a visual representation of the app control.

SETUP AND INSTALLATION

This section provides step-by-step instructions for installing your ceiling fan. It is recommended to have a second person assist during installation.

1. Prepare for Installation

1. Turn off power at the main circuit breaker to prevent electrical shock.
2. Ensure the mounting location is suitable and the electrical box is securely attached to the building structure and can support the fan's weight.
3. Gather necessary tools: screwdriver, wire strippers, electrical tape, ladder.

2. Mounting the Bracket

Attach the mounting bracket to the electrical junction box using the screws provided. Ensure it is firmly secured.

3. Wiring Connections

Connect the fan's electrical wires to the household wiring. This fan typically requires two wires (live and neutral) plus a ground wire. Use wire nuts to secure connections. The fan comes with a hook on a wire to temporarily hang the fan during wiring, making installation easier.

- Connect the green/yellow ground wire from the fan to the bare copper or green ground wire from the outlet box.
- Connect the white (neutral) wire from the fan to the white (neutral) wire from the outlet box.
- Connect the black (live) wire from the fan to the black (live) wire from the outlet box.

4. Attaching the Fan Unit

Carefully lift the fan unit and align it with the mounting bracket. Secure the fan to the bracket using the provided screws. Ensure all connections are tight and secure.



Quiet Enjoyment



6 Fan Speeds



1/2/4/8H Timing



Quiet Operation



Powerful Motor



Low Running Noise <35dB

20dB



40dB



50dB



70dB




Image: The LEDIARY 23-inch Caged Ceiling Fan installed, demonstrating its low-profile, flush-mount design suitable for various rooms.

5. Install Light Bulbs (Not Included)

This fan requires 4 E26 base bulbs. Recommended bulbs include A19, ST19, T45 incandescent bulbs (up to 60W) or LED bulbs (up to 10W). Screw the bulbs into the sockets.



23" for Normal Size Room



E26*4 (Not Included)

Recommended bulbs :



LED Edison
Bulb A19



LED Bulb
ST19



LED Bulb
A19



LED Edison
Bulb ST19



Edison LED
Bulb T14



E26 Medium Base

LED Light Bulb - Max 10W

Image: Dimensional diagram of the 23-inch fan, highlighting its 23-inch diameter and 5.3-inch height, along with visual examples of compatible E26 bulb types (A19, ST19, T45).

6. Restore Power

Once installation is complete, turn the power back on at the main circuit breaker.

OPERATING INSTRUCTIONS

Your LEDIARY ceiling fan can be controlled via the included remote control or a dedicated mobile application.

Remote Control Functions

The remote control allows for easy adjustment of fan speed, light settings, and other features.

- **Power On/Off:** Turns the fan and light on or off.
- **Fan Speed:** Select from 6 wind speeds (1-6).
- **Light On/Off:** Controls the light independently.
- **Timer:** Set the fan to automatically turn off after 1, 2, 4, or 8 hours.
- **Reversible Mode (F/R):** Changes the direction of fan rotation.

APP & Remote Control

✧ Tips: APP control needs Bluetooth



Speed Control



Timer Setting



F/R Reverse Function



Turn On/Off



Fan On/Off



Image: The remote control and a smartphone displaying the LEDIARY app, illustrating the various control options including speed, timer, reverse function, and light/fan on/off.

App Control Functions

For enhanced control, download the LEDIARY app (requires Bluetooth connection). The app provides all remote control

functions and potentially more advanced settings.

- **Download App:** Search for "LEDIARY" in your device's app store.
- **Pairing:** Follow in-app instructions to pair your fan via Bluetooth.
- **Features:** Access speed control, timer settings, reversible mode, light and fan on/off, and potentially natural breeze mode.

Reversible Mode

The reversible motor allows for year-round use:

- **Summer Mode (Downward Airflow):** Creates a cooling breeze by pushing air downwards.
- **Winter Mode (Upward Airflow):** Circulates warm air trapped near the ceiling, distributing it throughout the room.

Reversible Motor

Cool in Summer and Warm in Winter



Image: Visual explanation of the reversible motor, depicting how downward airflow provides cooling in summer and upward airflow helps distribute warm air in winter.

MAINTENANCE

Regular maintenance ensures optimal performance and longevity of your LEDIARY ceiling fan.

- **Cleaning:** Dust the fan and light fixture regularly with a soft, damp cloth. Do not use abrasive cleaners or solvents. Ensure power is off before cleaning.
- **Bulb Replacement:** Turn off power before replacing bulbs. Allow bulbs to cool before handling.
- **Motor:** The pure copper DC motor is designed for quiet operation and energy efficiency, requiring minimal maintenance.

Powerful
Copper Motor



Light Golden Painted



7 Fan Blades



Farmhouse
Style



Image: Detailed views of the fan's internal components, showcasing the powerful copper motor, the light golden painted finish of the cage, and the 7 fan blades, emphasizing the quality of construction.

Troubleshooting

If you encounter issues with your fan, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Fan does not operate.	No power; loose wiring; remote control battery dead.	Check circuit breaker. Ensure all wiring connections are secure. Replace remote control batteries.
Light does not turn on.	Bulbs not installed or faulty; loose wiring; light switch off.	Install or replace bulbs. Check wiring connections. Ensure light function is activated on remote/app.
Fan makes excessive noise.	Loose screws; fan not mounted securely.	Tighten all mounting screws. Ensure the fan is flush with the ceiling.
Remote control not working.	Dead batteries; remote not paired.	Replace AAA batteries. Refer to pairing instructions in the full manual (if applicable).

Specifications

Feature	Detail
Brand	LEDIARY
Model	23 Inch Caged Ceiling Fan (ASIN: B0F1MX2GGZ)
Color	Gold-dusted White
Material	Iron
Style	Farmhouse
Light Fixture Form	Ceiling Fan Light
Fan Diameter	23 inches
Height	Approximately 5.3 inches (flush mount)
Indoor/Outdoor Usage	Indoor
Power Source	DC Motor
Special Features	Remote Controlled, Energy Efficient, Timer, 6 Wind Speeds, Reversible Mode
Control Method	App, Remote Control

Feature	Detail
Number of Light Sources	4
Voltage	120 Volts
Bulb Base	E26 (Bulbs Not Included)
Recommended Bulb Wattage	Incandescent up to 60W, LED up to 10W
Mounting Type	Flush Mount
Item Weight	10 pounds
Batteries (Remote)	2 AAA batteries (included)

WARRANTY AND SUPPORT

LEDIARY is committed to providing high-quality products and customer satisfaction. For any technical support or warranty inquiries, please contact LEDIARY customer service.

- **Customer Service:** Refer to the contact information provided with your product packaging or visit the official LEDIARY website.
- **Warranty:** Information regarding product warranty can be found on the LEDIARY official website or by contacting customer support.



Image: The LEDIARY brand logo, representing the manufacturer.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question