

Finnhomy 7952

Finnhomy 66.3-inch Fluted Door Sideboard Cabinet User Manual

Model: 7952

INTRODUCTION

This manual provides comprehensive instructions for the assembly, operation, and maintenance of your Finnhomy 66.3-inch Fluted Door Sideboard Cabinet. Please read all instructions carefully before beginning assembly and retain this manual for future reference.

Important Safety Information:

- Heavy objects require careful handling. Always follow assembly instructions and use appropriate safety gear.
- Keep away from children and pets during assembly.
- Ensure all fasteners are securely tightened before use.
- Do not overload the cabinet shelves.

PACKAGE CONTENTS

Before assembly, verify that all components are present and undamaged. If any parts are missing or damaged, please contact customer support.

Components:

- Cabinet panels (top, bottom, sides, back, shelves)
- Fluted doors (3 units)
- Metal legs and hardware
- Door hinges and handles
- Assembly hardware (screws, dowels, cam locks, etc.)
- Instruction manual

Tools Required (Not Included):

- Phillips head screwdriver

- Hammer (optional, for dowels)

SETUP AND ASSEMBLY

Assembly typically requires two adults and takes approximately 75 minutes. Follow the numbered steps provided in the included instruction booklet. All parts and screws are labeled for easy identification.

Step 1: Prepare the Workspace

Clear a spacious, flat, and clean area for assembly. Lay out all components and hardware, matching them to the parts list in your instruction booklet.

Step 2: Assemble the Base Frame

Attach the metal legs to the bottom panel of the cabinet using the provided screws. Ensure the adjustable levelers on the legs are facing downwards.



Image: This image displays the Finnhome sideboard cabinet with all three doors open, revealing the interior storage layout. Key dimensions are overlaid, indicating an overall width of 66.3 inches, a depth of 17.72 inches, and a height of 28.74 inches. The internal compartments are shown with approximate widths of 19.66 inches each, and shelf heights of 8.15 inches and 10.51 inches, demonstrating the storage capacity.

Step 3: Construct the Cabinet Body

Connect the side panels and internal dividers to the bottom panel using dowels and cam locks. Secure the back panel to complete the main structure.

Step 4: Install Shelves

Insert the adjustable shelves into the desired positions. The shelves can be moved to accommodate items of various heights.



Image: A detailed view of the Finnhome sideboard cabinet's features. It highlights the golden metal handles, the adjustable shelf mechanism within a compartment, and the 5.9-inch high-quality adjustable tall legs with levelers, indicating customizable storage and stability features.

Step 5: Attach Doors and Handles

Mount the hinges to the fluted doors and then attach the doors to the cabinet frame. Install the golden metal handles onto the doors.



Image: This diagram illustrates the four steps for adjusting cabinet door hinges. It shows how to manipulate screws to

move the cabinet door up/down, in/out, and right/left, enabling precise alignment and ensuring minimal gaps between doors for a flush appearance.

Step 6: Final Adjustments

Adjust the door hinges as needed to ensure proper alignment and smooth operation. Use the adjustable levelers on the legs to stabilize the cabinet on uneven floors.

OPERATING INSTRUCTIONS

The Finnhome Sideboard Cabinet is designed for storage in living rooms, dining rooms, or kitchens.

- **Door Operation:** Gently open and close the fluted doors using the metal handles. Avoid forcing the doors.
- **Shelf Adjustment:** To adjust shelf height, remove all items from the shelf, lift the shelf, and reposition the shelf pins in the desired holes. Ensure the shelf is level and securely seated before placing items back.
- **Weight Capacity:** Distribute weight evenly across shelves. Do not exceed the recommended weight capacity for each shelf (specific weight capacity not provided, general caution advised).

MAINTENANCE

Regular maintenance will help preserve the appearance and longevity of your cabinet.

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals that may damage the finish.
- **Spills:** Clean spills immediately to prevent staining, especially on the natural wood finish.
- **Hardware:** Periodically check all screws and fasteners to ensure they remain tight. Retighten as necessary.
- **Sunlight Exposure:** Avoid prolonged exposure to direct sunlight to prevent fading or discoloration of the wood.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Doors are misaligned or do not close properly.	Hinges require adjustment.	Refer to the hinge adjustment diagram in the assembly section or your instruction booklet. Adjust screws on hinges to align doors.
Cabinet wobbles.	Uneven floor or loose legs.	Adjust the levelers on the bottom of the metal legs until the cabinet is stable. Ensure all leg screws are tight.
Missing parts during assembly.	Packaging error.	Contact Finnhome customer support with your purchase details and a list of missing parts.

SPECIFICATIONS

- **Brand:** Finnhome

- **Model Name:** Fluted Door Sideboard 7952
- **Product Dimensions:** 66.3" W x 17.7" D x 28.7" H
- **Color:** Natural
- **Material:** Engineered Wood (P2 grade MDF), Metal legs
- **Number of Doors:** 3
- **Number of Shelves:** 3 (adjustable)
- **Item Weight:** Approximately 128 Pounds
- **Mounting Type:** Floor Mount, Freestanding
- **Assembly Required:** Yes

WARRANTY AND SUPPORT

Finnhomy offers a quality guarantee for its products. For any quality issues, please contact customer service for a replacement or refund.

Customer Support:

If you have any questions, concerns, or require assistance with your Finnhome Sideboard Cabinet, please contact us via email. We aim to respond within 24 hours.

For further assistance, please visit the official Finnhome store on Amazon: [Finnhome Store](#)