

HomeRunPet CF20N

Homerunpet Cat Water Fountain Porcelain-Tray Instruction Manual

Model: CF20N

PRODUCT OVERVIEW

The Homerunpet Cat Water Fountain provides fresh, filtered water for your pets. It features a durable porcelain tray, a wireless self-cleaning pump, and a 4-stage filtration system. Designed for quiet operation and easy maintenance, it encourages healthy hydration for cats and dogs.

- **Premium Porcelain Tray:** Made with Blanc de Chine porcelain, the non-porous, smooth surface resists grease and reduces debris buildup. It is dishwasher-safe and durable for easy maintenance. *Note: Only the tray is porcelain.*
- **Self-Cleaning Wireless Pump:** The wireless pump cycles every 2 minutes to keep water clean. It is supported by a 4-stage filtration system that removes 99.98% of impurities for better-tasting, odor-free water. *Note: Only the pump is wireless.*
- **Pet-Friendly Design:** A gentle spring-like water flow and a 4.18° tilted surface encourage hydration while protecting your pet's neck and back. Smart LED indicators alert you to low water levels.
- **Ultra-Quiet Operation:** Operating at just 20dB, this fountain is quieter than a whisper, creating a stress-free drinking experience for your pets.

Advanced Filtration System Removes 99.9% of Dust/Dirt/ Pet Hair



99.9%
Impurity Removal




Image Description: A cat drinking from the Homerunpet Cat Water Fountain, highlighting its pet-friendly design.

PACKAGE CONTENTS

Please ensure all components are present before assembly:

- Water Fountain Base (ABS material)
- Water Reservoir (2L/68oz capacity)
- Porcelain Tray
- Wireless Pump

- 4-Stage Filter (one included, replacements available)
- USB Power Adapter and Cable
- User Manual

SETUP AND ASSEMBLY

1. **Clean Components:** Before first use, thoroughly rinse all parts (reservoir, tray, pump, filter) with water. Soak the filter in water for approximately 5 minutes.
2. **Insert Wireless Pump:** Place the wireless pump into its designated slot at the bottom of the water reservoir. Ensure it is securely seated.
3. **Place Filter:** Insert the 4-stage filter into the filter tray.
4. **Assemble Tray:** Place the porcelain tray onto the reservoir, ensuring it aligns correctly with the pump's water outlet.
5. **Fill with Water:** Fill the reservoir with clean water up to the maximum fill line.
6. **Connect Power:** Place the assembled fountain onto the power base. Connect the USB cable to the power adapter and plug it into a wall outlet.



Image Description: A fully assembled Homerunpet Cat Water Fountain, white in color with a clear top, showing water circulating. The brand logo is visible on the front.

Video Description: An official product video demonstrating the step-by-step assembly of the Homerunpet Cat Water Fountain, including cleaning components, inserting the pump, placing the filter, and filling the reservoir.

OPERATING INSTRUCTIONS

The fountain features smart LED indicators and multiple operating modes for convenient use.

Power On/Off

Long press the power button for 3 seconds to turn the fountain on or off.

Operating Modes

- **Normal Mode:** Provides continuous water flow.
- **Intelligent Mode (Smart Mode):** The pump cycles water every 2 minutes. This mode conserves energy and ensures fresh water availability.

LED Indicators

- **Blue Light:** Indicates Intelligent Mode.
- **White Light:** Indicates Normal Mode.
- **Red Light (Flashing):** Alerts to low water levels. The pump will stop working when water volume is between 150ml and 200ml to prevent dry burning.
- **Purple Light:** Indicates it's time to replace the filter.

Advanced Wireless System Ensures Superior Quality and Safety




Image Description: A close-up of the Homerunpet Cat Water Fountain's control panel, highlighting the LED indicators for different operating modes and alerts.

Video Description: An official product video demonstrating the various operating modes and LED indicators of the Homerunpet Cat Water Fountain, including how to switch between modes and interpret the light signals.

MAINTENANCE

Regular cleaning and filter replacement are essential for optimal performance and your pet's health.

Daily/Weekly Cleaning

- Detachable components and a seamless design make daily cleaning quick and easy.
- The porcelain tray is dishwasher-safe.

Pump Cleaning

- Clean the wireless pump every two weeks to maintain performance and extend its lifespan.
- The pump can be easily disassembled for thorough cleaning of all parts, including the impeller.

Filter Replacement

- The 4-stage filter should be replaced approximately every 2-3 months, depending on usage and water quality.
- The purple LED indicator will remind you when it's time for replacement. Long press the filter reminder reset button for 5 seconds after replacing the filter.

Dishwasher Safe, Easy Clean Porcelain Top



Dishwasher-Safe



Image Description: A close-up of the 4-stage filtration system, showing the filter components designed to remove impurities from the water.

Whisper Quiet

45dB
Refrigerator

30dB
Falling leaves

<20dB
Whisper from 6 feet away

SILENT



Image Description: A hand pouring water over the porcelain tray of the Homerunpet Cat Water Fountain, demonstrating its easy-to-clean, dishwasher-safe surface.

SPECIFICATIONS

Feature	Detail
Brand	HomeRunPet

Feature	Detail
Model Name	CF20N
Item Weight	3.78 pounds
Item Package Dimensions	8.98 x 8.9 x 7.44 inches
Capacity	2L / 68oz (Water Reservoir)
Material	Acrylonitrile Butadiene Styrene (ABS) for body, Blanc de Chine porcelain for tray
Power Source	Wireless (for pump), Wall Adapter (for base)
Operation Noise Level	Ultra-Quiet (20dB)
First Available Date	December 28, 2022

WARRANTY AND SUPPORT

The Homerunpet Cat Water Fountain comes with a 1-year warranty. For support or warranty claims, please contact HomeRunPet customer service. Refer to the contact information provided in the Quick Start Guide or on the official HomeRunPet website.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Email

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Details

Submit question