

[Manuals.plus](#) /

› [InnovaGoods](#) /

› InnovaGoods Retractable Blade Ceiling Fan with LED Light User Manual

InnovaGoods 8435527827564

InnovaGoods Retractable Blade Ceiling Fan with LED Light User Manual

Model: 8435527827564

INTRODUCTION

Thank you for purchasing the InnovaGoods Retractable Blade Ceiling Fan with LED Light. This manual provides important information regarding the safe operation, installation, and maintenance of your new ceiling fan. Please read it thoroughly before use and retain it for future reference.

SAFETY INSTRUCTIONS

- Always disconnect power before installation, cleaning, or maintenance.
- Installation must be performed by a qualified electrician in accordance with local electrical codes.
- Ensure the mounting structure can support the fan's weight (approximately 4.38 kg).
- Do not insert objects into the fan blades while in operation.
- Keep children and pets away from the fan during operation.
- Use only the remote control provided with the fan.
- Do not expose the fan to water or excessive humidity.

PACKAGE CONTENTS

Please check that all components are present and undamaged:

- Ceiling Fan Unit with Retractable Blades and LED Light
- Remote Control (requires 2 x AAA batteries, not included)
- Mounting Bracket
- Downrod
- Canopy

- Hardware Pack (screws, wire nuts, etc.)
- User Manual

SETUP AND INSTALLATION

Follow these steps carefully for proper installation. It is recommended to have two people for installation.

1. Prepare for Installation

1. Turn off power at the circuit breaker to the fan's location.
2. Ensure the ceiling joist or support structure is strong enough to hold the fan's weight.
3. Unpack all components and lay them out on a soft surface to prevent scratches.

2. Mount the Bracket

Secure the mounting bracket to the ceiling outlet box using the provided screws. Ensure it is firmly attached.



Image: The InnovaGoods ceiling fan with its retractable blades fully extended, showcasing its design and functionality.

3. Assemble the Fan

1. Attach the downrod to the fan motor assembly.
2. Carefully lift the fan and hang it on the mounting bracket.
3. Connect the electrical wires according to the wiring diagram in the detailed instructions (Live, Neutral, Ground). Use wire nuts to secure connections.

4. Install the Canopy and Light Kit

1. Slide the canopy up to cover the mounting bracket and secure it with screws.
2. Connect the LED light kit wires to the fan's light wires.
3. Attach the light kit to the fan body.



Image: The InnovaGoods ceiling fan with its blades fully retracted, appearing as a sleek, modern light fixture.

OPERATING INSTRUCTIONS

Your InnovaGoods ceiling fan is controlled by the included remote control.

Remote Control Functions



Image: A hand holding the remote control, positioned next to the InnovaGoods ceiling fan, illustrating the primary control method.

- **Power On/Off:** Press the power button to turn the fan and light on or off.
- **Fan Speed:** Cycle through 6 speeds (170-230 r.p.m.) using the fan speed buttons.
- **Light Control:**
 - Press the light button to turn the LED light on or off.
 - Cycle through 3 light modes: Cold (6500K), Warm (3500K), and Neutral (4300K).




Image: A visual representation of the three distinct light temperatures (cold, warm, neutral) emitted by the fan's LED light.

- **Timer Function:** Set the fan to turn off automatically after 1, 2, or 4 hours.
- **Summer/Winter Function:**

This function allows you to reverse the direction of the fan blades to optimize air circulation for different seasons.

 - **Summer Mode:** Blades rotate counter-clockwise, pushing air downwards to create a cooling breeze.
 - **Winter Mode:** Blades rotate clockwise, drawing air upwards to circulate warm air trapped near the ceiling.



Image: Diagram showing arrows indicating the two rotation directions of the fan blades for Summer (counter-clockwise) and Winter (clockwise) modes.

- **Retractable Blades:** The fan's 4 blades automatically retract when the fan is turned off and extend when the fan is turned on.



Image: A four-panel sequence demonstrating the fan blades transitioning from extended to fully retracted positions.

MAINTENANCE

- **Cleaning:** Before cleaning, ensure the fan is turned off and power is disconnected. Use a soft, damp cloth to wipe down the fan body and blades. Do not use abrasive cleaners or solvents.
- **Blade Care:** The retractable blades are made of PC material. Handle them gently.
- **Regular Checks:** Periodically check all screws and connections to ensure they are secure.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Fan does not turn on	No power supply; Remote control batteries are dead; Loose wiring connection.	Check circuit breaker; Replace remote control batteries; Check wiring connections (ensure power is off).

Problem	Possible Cause	Solution
Light does not work	Loose wiring connection; LED module failure.	Check light kit wiring (ensure power is off); Contact customer support if LED module is faulty.
Fan makes excessive noise	Loose screws; Improper installation; Blades unbalanced.	Tighten all screws; Re-check installation steps; Ensure blades are properly seated.
Remote control not working	Dead batteries; Obstruction between remote and receiver; Remote not paired.	Replace batteries; Remove obstructions; Refer to pairing instructions (if applicable, usually automatic).

SPECIFICATIONS

Feature	Detail
Brand	InnovaGoods
Model Number	8435527827564
Power	72 W (Fan), 40 W (LED Light)
Voltage	230 Volts (AC)
Dimensions (Extended)	Ø 104 cm (diameter) x 42 cm (height)
Dimensions (Retracted)	Ø 49 cm (diameter) x 42 cm (height)
Weight	4.38 kg
Fan Speeds	6 speeds (170-230 r.p.m.)
LED Light	48 SMD LED, 4000 lm
Light Color Temperatures	Cold (6500K), Warm (3500K), Neutral (4300K)
Timer	1, 2, 4 hours
Energy Efficiency Class	E
Suitable Room Size	10-25 m²




Image: The energy efficiency label for the InnovaGoods ceiling fan, indicating an 'E' rating.

For more detailed energy information, visit the [EPREL database](#).

SUPPORT

For any questions, technical support, or warranty claims, please contact InnovaGoods customer service.

- **Brand Website:** www.innovagoods.com
- **Email:** info@innovagoods.com

Please have your model number (8435527827564) and purchase details ready when contacting support.