

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Nuvita](#) /

› [Nuvita 1180 Lattespresso Instant Formula Milk Maker User Manual](#)

Nuvita NU-ALSC0026

Nuvita 1180 Lattespresso

INSTANT FORMULA MILK MAKER USER MANUAL

Model: NU-ALSC0026

[Introduction](#) [Safety Information](#) [Setup](#) [Operation](#) [Maintenance](#) [Troubleshooting](#) [Specifications](#)
[Warranty & Support](#)

1. Introduction

The Nuvita 1180 Lattespresso is an instant formula milk maker designed to simplify the preparation of baby bottles. This device automatically heats, doses, mixes, and dispenses powdered milk, ensuring a consistent temperature and lump-free consistency in approximately 10 seconds. It offers customizable temperature settings and is compatible with various powder milk brands.



Image 1.1: Nuvita 1180 Lattespesso product in its retail packaging.

Key Features:

- **Automatic and Instant Preparation:** Heats, doses, mixes, and dispenses powdered milk in approximately 10 seconds.
- **Customizable Temperatures:** Offers 4 temperature settings: 22°C, 37°C, 42°C (for milk), and 50°C (for water only).
- **Adjustable Bottle Base:** Accommodates bottles from 60 ml to 300 ml.
- **Powder Milk Compatibility:** Features 10 selectable dosing programs for compatibility with major powder milk brands.
- **Large Capacity:** 1.3 L water tank and 350 g powder milk container, capable of preparing up to 14 bottles (120 ml each) per refill.
- **Hygienic Design:** Closed system for powder and removable, dishwasher-safe water tank.
- **Safety and Efficiency:** Automatic shut-off after each cycle.

2. Important Safety Information

Please read all instructions carefully before using the Nuvita 1180 Lattespresso. Failure to follow these instructions may result in injury or damage to the appliance.

- Always keep the appliance out of reach of children.
- Do not immerse the main unit in water or other liquids.
- Ensure the appliance is placed on a stable, level, heat-resistant surface.
- Do not operate the appliance if the power cord or plug is damaged.
- Unplug the appliance from the power outlet before cleaning or when not in use.
- Use only clean, potable water in the water tank.
- Do not use the appliance for purposes other than preparing formula milk.
- Always check the temperature of the prepared milk before feeding to ensure it is safe for the baby.
- Regularly clean all parts that come into contact with milk or water to prevent bacterial growth.

3. Setup and First Use

3.1 Unpacking

1. Carefully remove the Lattespresso from its packaging.
2. Remove all packaging materials, stickers, and labels.
3. Inspect the appliance for any signs of damage. Do not use if damaged.

3.2 Initial Cleaning

1. Remove the water tank and powder container. Wash them with warm soapy water, rinse thoroughly, and dry completely. The water tank is dishwasher safe.
2. Wipe the exterior of the main unit with a damp cloth. Do not immerse the main unit in water.
3. Perform a cleaning cycle with water only:
 - Fill the water tank with clean water.
 - Place an empty bottle or container under the dispenser.
 - Select the 50°C temperature setting (water only) and initiate a dispensing cycle.
 - Discard the water after the cycle. Repeat this process once more.

3.3 Filling the Water Tank and Powder Container



Image 3.1: Side view illustrating the removable water tank.

- 1. Water Tank:** Remove the water tank from the back of the unit. Fill it with clean, potable water up to the MAX line (1.3 L capacity). Reinsert the tank securely.
- 2. Powder Container:** Open the lid of the powder container located on top of the unit. Carefully pour your chosen powdered milk formula into the container (350 g capacity). Ensure the lid is closed tightly after filling to maintain hygiene.

4. Operating Instructions

4.1 Powering On and Initial Settings

1. Plug the appliance into a suitable power outlet. The display will illuminate.
2. **Select Temperature:** Use the temperature selection buttons to choose the desired milk temperature. Available settings for milk are 22°C, 37°C, and 42°C. A 50°C setting is available for water only (e.g., for cleaning or preparing other beverages).



TRANQUILLITÀ

Prepara fino a **14 biberon** di latte da 120 ml con una sola ricarica e **si spegne da solo** dopo ogni utilizzo, riducendo il consumo energetico e garantendo la massima sicurezza.

Image 4.1: Control panel showing temperature selection buttons.

3. **Select Dosing Program:** The Lattespresso offers 10 selectable dosing programs to match various powder milk brands. Consult your formula's instructions and the Lattespresso manual for the correct program setting. Adjust the program using the dedicated buttons.
4. **Adjust Bottle Base:** Adjust the height of the bottle base to fit your baby bottle (60 ml to 300 ml). Ensure the bottle is positioned directly under the dispenser.

4.2 Preparing a Bottle

1. Ensure the water tank is filled and the powder container has sufficient formula.
2. Place a clean, empty baby bottle on the adjustable base.
3. Confirm your desired temperature and dosing program are selected on the display.
4. Press the start button to begin the preparation cycle. The appliance will automatically heat the water, dispense the correct amount of powder, and mix them.



RAPIDITÀ

In soli **10 secondi*** il latte è pronto, caldo e senza grumi. Pensa a tutto lui.

*biberon da 60 ml



LIBERTÀ

Grazie ai **10 programmi di dosaggio selezionabili**, si adatta alle marche di latte in polvere più vendute e a biberon di ogni dimensione (da 60 a 300 ml).

Image 4.2: Initiating a preparation cycle with a single button press.

5. The preparation process takes approximately 10 seconds. The appliance will automatically stop once the bottle is ready.
6. Carefully remove the bottle. **Always check the milk temperature on your wrist before feeding your baby.**

5. Cleaning and Maintenance

Regular cleaning is essential to ensure hygiene and optimal performance of your Lattespresso.

5.1 Daily Cleaning

- Dispenser and Mixing Funnel:** After every 4 bottles, remove the mixing funnel and dispenser. Wash them with warm soapy water, rinse thoroughly, and dry completely. Ensure no powder residue remains.
- Water Tank:** The water tank should be emptied and refilled daily with fresh water. It is removable and dishwasher safe for thorough cleaning.
- Exterior:** Wipe the exterior surfaces of the appliance with a clean, damp cloth.

5.2 Deep Cleaning / Descaling

Depending on water hardness, descaling may be required periodically to prevent mineral buildup. Refer to the full product manual for detailed descaling instructions. Generally, this involves running a cycle with a descaling solution (e.g., white vinegar diluted with water) followed by several rinse cycles with clean water.

6. Troubleshooting

If you encounter issues with your Nuvita 1180 Lattespresso, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Appliance does not power on.	Not plugged in; power outlet issue.	Ensure the power cord is securely plugged into a working outlet.

Problem	Possible Cause	Solution
No milk dispensed.	Water tank empty; powder container empty; dispenser clogged.	Refill water tank and/or powder container. Clean the dispenser and mixing funnel.
Milk has clumps.	Incorrect dosing program; powder residue in dispenser; old powder.	Verify the correct dosing program for your formula. Clean the dispenser thoroughly. Ensure powder is fresh and stored correctly.
Incorrect milk temperature.	Incorrect temperature setting selected; appliance not preheated.	Check the selected temperature setting. Allow a few moments for the water to heat if starting from cold.

If the problem persists after attempting these solutions, please contact Nuvita customer support.

7. Product Specifications

- **Brand:** Nuvita
- **Model Number:** NU-ALSC0026
- **Color:** Black
- **Product Dimensions (L x W x H):** 42 x 27 x 29 cm (16.5 x 10.6 x 11.4 inches)
- **Item Weight:** 3.86 Kilograms (8.5 lbs)
- **Water Tank Capacity:** 1300 Milliliters (1.3 Liters)
- **Powder Container Capacity:** 350 grams
- **Material:** Plastic
- **Special Features:** Automatic preparation, temperature and format adjustment, compatibility with powder milk brands, large capacity, optimal safety.

8. Warranty and Support

8.1 Warranty Information

The Nuvita 1180 Lattespresso comes with a manufacturer's warranty against defects in materials and workmanship. The specific terms and duration of the warranty may vary by region. Please retain your proof of purchase for warranty claims. For detailed warranty information, refer to the warranty card included with your product or visit the official Nuvita website.

8.2 Customer Support

For technical assistance, troubleshooting not covered in this manual, or spare parts inquiries, please contact Nuvita customer support. Contact details can typically be found on the Nuvita official website or on the product packaging.

Please visit www.nuvita.com for the latest information and support resources.