

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Spigen](#) /

› [Spigen S581W MagFit+ 57-inch Extendable Selfie Stick Tripod with Bluetooth Remote Control User Manual](#)

## Spigen S581W

# Spigen S581W MagFit+ 57-inch Extendable Selfie Stick Tripod with Bluetooth Remote Control User Manual

Model: S581W | Brand: Spigen

## INTRODUCTION

Welcome to the user manual for your new Spigen S581W MagFit+ Selfie Stick Tripod. This device combines the functionality of an extendable selfie stick with a stable tripod, featuring a magnetic phone mount and a detachable Bluetooth remote control. Please read this manual carefully to ensure proper use and maintenance of your product.

## SAFETY INFORMATION

- Avoid exposing the device to extreme temperatures or direct sunlight for prolonged periods.
- Keep the device away from water and other liquids.
- Do not attempt to disassemble or repair the device yourself. Contact customer support if needed.
- Ensure your phone is securely attached before extending the stick or using the tripod function.
- Keep the Bluetooth remote away from small children to prevent choking hazards.

## PACKAGE CONTENTS

- Spigen S581W Selfie Stick Tripod
- Bluetooth Remote Control
- Universal Magnetic Phone Ring (for non-MagSafe cases)
- USB Charging Cable (for remote)
- User Manual (this document)

## PRODUCT OVERVIEW

Familiarize yourself with the components of your Spigen S581W.



Image Description: The Spigen S581W Selfie Stick Tripod in its compact form, extended as a selfie stick, and deployed as a tripod, showcasing its magnetic phone mount and detachable Bluetooth remote.

## SETUP

### 1. Charging the Bluetooth Remote

The Bluetooth remote control comes with a rechargeable battery. Use the provided USB charging cable to charge it.

- Locate the charging port on the side of the remote.
- Connect the USB cable to the remote and a power source.
- The indicator light will show charging status (e.g., red for charging, blue/off for fully charged).

### 2. Pairing the Bluetooth Remote

To use the remote shutter function, you must pair the remote with your smartphone.

- Ensure the remote is charged.
- Turn on the remote by pressing and holding the button until the indicator light flashes.
- On your smartphone, go to Bluetooth settings and search for available devices.
- Select "Spigen Remote" (or similar name) from the list to pair.
- The indicator light on the remote will stop flashing once successfully paired.

### 3. Attaching Your Phone

The Spigen S581W offers two methods for attaching your smartphone:

#### For MagSafe Compatible Phones/Cases:

Simply align your MagSafe-compatible phone or case with the magnetic head of the selfie stick. The strong magnetic base will securely hold your device.



#### MagFit Plus Tech

Dual-sided MagSafe holds your accessories right on the back - no more losing them.



No MagSafe?  
We've got your back  
Metal Ring included.



Image Description: A smartphone with a MagSafe case magnetically attaching to the circular magnetic mount on the selfie stick.

#### For Non-MagSafe Phones/Cases:

Use the included universal magnetic phone ring.

- Clean the back of your phone or case thoroughly.
- Peel off the adhesive backing from the magnetic phone ring.
- Center and firmly press the ring onto the back of your phone or case.

- Once the ring is attached, you can magnetically connect your phone to the selfie stick head.



**Selfie stick mode.**

Take steady selfies anytime, anywhere with the wrist strap!



Image Description: A universal magnetic phone ring being applied to the back of a non-MagSafe phone case.

## OPERATING INSTRUCTIONS

### 1. Selfie Stick Mode

To use the device as a selfie stick:

- Ensure the tripod legs are folded and secured.
- Pull the top section of the stick upwards to extend it to your desired length.
- Adjust the angle of your phone using the rotatable head.
- Use the Bluetooth remote to capture photos or start/stop videos.

**Tripod mode.**

Durable double structure  
for perfect balance!  
hands-free, worry-free.



Lightweight yet durable aluminum.



Stable triangular structure.



Image Description: A person holding the Spigen selfie stick extended, capturing a group photo.

## 2. Tripod Mode

To use the device as a stable tripod:


- With the stick in its compact form, press the button at the bottom of the handle. The tripod legs will automatically deploy.
- Place the tripod on a flat, stable surface.
- Extend the main pole to your desired height. The maximum height is 168.5 cm (66.34 inches).
- Adjust the phone's angle as needed.
- Use the Bluetooth remote for hands-free operation.

One push Opening Tripod.

Pops open automatically with a single press.



1. ONE TAP



2. AUTO OPEN

Anti-slip silicone pads.



Honeycomb Structure.



Image Description: The Spigen selfie stick tripod deployed on a surface, extended to its full height with a smartphone attached.

### 3. Using the Bluetooth Remote

The detachable Bluetooth remote allows for convenient shooting from a distance.

- Once paired, open your phone's camera app.
- Press the button on the remote to trigger the shutter for photos or to start/stop video recording.
- The remote has a range of up to 10 meters (may vary by environment).

Bluetooth 4.2 remote control.

Snaps on magnetically,  
shoots from  
up to 10m away.

\*Up to 10m range (may vary by environment)



Image Description: A hand holding the detachable Bluetooth remote control, with a blue light indicating it's active.

## MAINTENANCE

- **Cleaning:** Wipe the device with a soft, dry cloth. Do not use harsh chemicals or abrasive cleaners.
- **Storage:** Store the selfie stick tripod in a cool, dry place when not in use. Ensure it is fully retracted and the remote is securely stored in its slot.
- **Battery Care:** Recharge the Bluetooth remote regularly to maintain battery health. Avoid fully depleting the battery for extended periods.

## TROUBLESHOOTING

### Remote Not Pairing:

- Ensure the remote is charged and turned on.
- Check your phone's Bluetooth settings to ensure it's discoverable.
- Try unpairing and re-pairing the remote.
- Restart your phone and the remote.

### Phone Not Holding Securely:

- For MagSafe, ensure your phone/case is MagSafe compatible and properly aligned.
- For non-MagSafe, ensure the universal magnetic ring is securely attached and clean.
- Avoid excessive shaking or sudden movements that could dislodge the phone.

### Tripod Legs Not Deploying/Retracting:

- Ensure the release button at the bottom is fully pressed.
- Check for any obstructions in the leg mechanism.
- Do not force the legs; if stuck, gently wiggle them while pressing the button.

## SPECIFICATIONS

Feature	Detail
Model Name	S581W (AMP09534)
Brand	Spigen
Material	Metal Alloy
Maximum Height	168.5 Centimeters (57 inches)
Item Weight	330 Grams (11.6 ounces)
Product Dimensions (Folded)	1.38 x 2.4 x 1.38 inches
Special Feature	Portable, Rotatable
Tripod Head Type	3-Way Head
Compatible Devices	iPhone 12 Series and newer (MagSafe), Pixel 10 Series, MagSafe Compatible Cases for Galaxy S25, S24, Z Fold 7, Z Flip 7 Series and More
Bluetooth Remote	Detachable, up to 10m range
Battery	1 Lithium Metal battery (included)

## WARRANTY AND SUPPORT

For warranty information, product support, or service inquiries, please visit the official Spigen website or contact their customer service. Keep your purchase receipt for warranty claims.


## Related Documents - S581W

	<p><a href="#"><b>Spigen Gimbal Selfie Stick Tripod S620W User Manual</b></a></p> <p>User manual for the Spigen S620W Gimbal Selfie Stick Tripod, detailing its components, operation modes including handheld dolly shot and AI tracking, charging instructions, remote control functions, specifications, and important cautions.</p>
	<p><a href="#"><b>Spigen ArcField Dual Wireless Charger PF2100 User Manual</b></a></p> <p>Official user manual for the Spigen ArcField Dual Wireless Charger PF2100, detailing setup, safety instructions, specifications, and warranty information.</p>
	<p><a href="#"><b>Spigen Essential Qi2.2 Peltier Wireless Car Charger EV25MFAQ User Manual</b></a></p> <p>User manual for the Spigen Essential Qi2.2 Peltier Wireless Car Charger (Model EV25MFAQ), detailing installation, features, specifications, and safety information.</p>



## [Spigen ArcHybrid Mag Wireless Portable Charger PH2100 User Manual](#)

User manual and safety instructions for the Spigen ArcHybrid Mag Wireless Portable Charger PH2100, a 5000mAh magnetic charging power bank with fast wireless charging capabilities for iPhones.



## [Spigen ArcStation Pro GaN 1402 Wall Charger User Manual](#)

User manual for the Spigen ArcStation Pro GaN 1402 Wall Charger, providing instructions, safety guidelines, specifications, and warranty information for this 140W dual USB-C power adapter.



## [Spigen ArcField Wireless Charger PF2402 User Manual & Safety Guide](#)

Official user manual and safety instructions for the Spigen ArcField Wireless Charger PF2402, detailing setup, operation, LED indicators, specifications, and regulatory compliance information.