

[Manuals.plus](#) /

› [VINGLI](#) /

› VINGLI Rattan Nightstands with Charging Station (Model RN01S1D) User Manual

VINGLI RN01S1D

VINGLI Rattan Nightstands with Charging Station (Model RN01S1D) User Manual

Detailed instructions for assembly, operation, and maintenance.

1. INTRODUCTION

Thank you for choosing the VINGLI Rattan Nightstands with Charging Station. This manual provides essential information for the safe and correct assembly, operation, and care of your new nightstand. Please read all instructions carefully before beginning assembly and retain this manual for future reference.

Important Safety Information

- Always follow the assembly instructions carefully to avoid injury.
- Keep the table away from water sources to prevent damage and ensure stability.
- Do not exceed the maximum weight recommendation of 66 pounds (30 kg) on the tabletop.
- Ensure all connections for the charging station are secure before use.
- This product is intended for indoor use only.

2. PACKAGE CONTENTS

Before assembly, verify that all parts listed below are present and undamaged. If any parts are missing or damaged, please contact customer support.

- Top Panel
- Side Panels (Left & Right)
- Bottom Panel
- Back Panel
- Drawer Front with Rattan Panel
- Drawer Side Panels (2)
- Drawer Back Panel
- Drawer Bottom Panel
- V-Shaped Metal Legs (2)
- Adjustable Feet (4)
- Charging Station (with 2 USB ports and 2 AC outlets)
- Hardware Pack (screws, dowels, cam locks, drawer slides, etc.)

Ample Storage Space




Image: Overview of nightstand dimensions and components, including the drawer and open shelf.

3. SETUP AND ASSEMBLY INSTRUCTIONS

Assembly typically requires a Phillips head screwdriver. Ensure you have a clear, flat surface to work on.

1. **Prepare Components:** Unpack all components and hardware. Lay them out on a soft, clean surface to prevent scratches.
2. **Assemble the Main Frame:** Attach the side panels to the bottom panel using the provided screws and dowels. Ensure the pre-drilled holes for the drawer slides are correctly oriented.
3. **Install Drawer Slides:** Secure the drawer slides to the inner sides of the nightstand frame using the designated screws. Ensure they are level and aligned.
4. **Assemble the Drawer:** Connect the drawer side panels, back panel, and bottom panel to the drawer front with the rattan panel. Install the remaining drawer slide components onto the drawer sides.
5. **Insert Drawer:** Carefully slide the assembled drawer into the nightstand frame, ensuring the drawer slides engage smoothly.

6. **Attach Back Panel:** Secure the back panel to the main frame using small nails or screws.
7. **Install V-Shaped Legs:** Attach the two V-shaped metal legs to the bottom of the nightstand using the provided screws. Ensure they are firmly secured.
8. **Install Adjustable Feet:** Screw the adjustable feet into the bottom of the V-shaped legs. Adjust them to level the nightstand on uneven surfaces.
9. **Integrate Charging Station:** Place the charging station into the designated cutout on the top panel. Secure it if necessary and route the power cord through the concealed cable hole at the back.



Image: Details of the metal silent drawer slide, concealed cable hole for cable management, and the waterproof finish.

4. OPERATING INSTRUCTIONS

Using the Charging Station

The integrated charging station provides convenient power access for your electronic devices.

- **Power Connection:** Plug the nightstand's power cord into a standard wall outlet.
- **USB Ports:** Use the two 5V/2A USB ports to charge smartphones, tablets, e-readers, and other USB-powered devices.
- **AC Outlets:** Use the two 125V/12A AC outlets for laptops, lamps, or other small appliances.
- **Safety:** Do not overload the charging station. Avoid plugging in high-power appliances that exceed the specified limits.

Multi-Device Charging



Image: The nightstand's charging station in use, powering multiple electronic devices.

Using the Drawer and Shelf

- **Drawer:** The smooth-gliding drawer provides enclosed storage for personal items. Pull the drawer front gently to open and push to close.
- **Open Shelf:** The open shelf offers easy access storage for books, decorative items, or other essentials.

5. MAINTENANCE

Cleaning and Care

- **General Cleaning:** Wipe the nightstand surfaces with a dry, soft cloth. For stubborn marks, a slightly damp cloth can be used, followed immediately by a dry cloth.
- **Waterproof Surface:** The nightstand features a waterproof finish. In case of spills, wipe them immediately to prevent liquid from seeping into seams or edges.
- **Rattan Care:** The natural rattan panel can be gently dusted with a soft brush or cloth. Avoid harsh chemicals or excessive

moisture.

- **Avoid Harsh Cleaners:** Do not use abrasive cleaners, strong chemicals, or solvents, as these can damage the finish and materials.
- **Sunlight Exposure:** Avoid prolonged direct sunlight exposure to prevent fading or discoloration of the wood and rattan.



Image: Demonstrating the waterproof surface, which allows for easy cleaning of spills.

6. TROUBLESHOOTING

If you encounter any issues with your VINGLI Rattan Nightstand, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Nightstand is wobbly.	Uneven floor or loose leg connections.	Adjust the leveling feet at the bottom of the legs. Tighten all leg screws.

Problem	Possible Cause	Solution
Drawer does not slide smoothly.	Drawer slides misaligned or dirty.	Ensure drawer slides are correctly installed and aligned. Clean any debris from the slides.
Charging station not working.	Power cord not plugged in, outlet issue, or device compatibility.	Check if the nightstand's power cord is securely plugged into a working wall outlet. Test the outlet with another device. Ensure your device is compatible with USB 5V/2A or AC 125V/12A.
Parts missing or damaged during assembly.	Shipping damage or packaging error.	Do not proceed with assembly. Contact VINGLI customer support immediately for replacement parts.

7. SPECIFICATIONS

- Brand:** VINGLI
- Model Number:** RN01S1D
- Product Dimensions (D x W x H):** 15.75" x 17.56" x 23.46" (40cm x 44.6cm x 59.6cm)
- Item Weight:** 25.4 Pounds (11.5 kg)
- Maximum Weight Recommendation:** 66 Pounds (30 kg)
- Frame Material:** Engineered Wood
- Top Material:** Wood
- Accent Material:** Natural Rattan
- Base Type:** Leg (V-shaped metal)
- Number of Drawers:** 1
- Charging Station:** 2 USB Ports (5V/2A), 2 AC Outlets (125V/12A)
- Power Cord Length:** Approximately 4.9 feet
- Color:** Oak
- Style:** Boho
- Assembly Required:** Yes
- Indoor/Outdoor Usage:** Indoor



Image: Detailed view of the drawer's internal dimensions.

8. WARRANTY & SUPPORT

Warranty Information

This VINGLI Rattan Nightstand is covered by a **1-Year Quality Warranty** from the date of purchase. This warranty covers manufacturing defects and material flaws under normal use. It does not cover damage caused by misuse, accidents, unauthorized

repairs, or normal wear and tear.

Customer Support

VINGLI values your shopping experience. If you have any questions, require assistance with assembly, or need to report missing/damaged parts, please do not hesitate to contact our customer support team. We are committed to providing professional service and resolving any issues you may encounter.

For support, please refer to the contact information provided with your purchase or visit the official VINGLI store page on Amazon.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Email

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Details

Submit question

Open the live page

<https://manuals.plus/asin/B0F1SZLX8W>

More documents and user manuals: <https://manuals.plus/>