

[Manuals.plus](#) /

› [COLAMY](#) /

› COLAMY Ergonomic Mesh Office Chair with Footrest, Model 5188-New-BK User Manual

COLAMY 5188-New-BK

COLAMY Ergonomic Mesh Office Chair with Footrest

MODEL: 5188-NEW-BK USER MANUAL

1. Safety Information

Please read all instructions carefully before assembly and use. Keep this manual for future reference.

- Do not stand on the chair.
- Do not use the chair if any components are damaged or missing.
- Ensure all bolts and screws are securely tightened before use. Re-tighten periodically.
- Keep children away from the assembly area. Small parts may be a choking hazard.
- Maximum weight capacity: 300 pounds (136 kg).

2. Package Contents

Verify all parts are present before beginning assembly. If any parts are missing or damaged, contact customer support.

Truly Eco-Friendly and Skin-Friendly Mesh Material




Image: Exploded view showing all individual components of the COLAMY Ergonomic Mesh Office Chair, including the base, casters, gas lift, seat, backrest, headrest, armrests, and hardware.

- Chair Backrest
- Seat Cushion with Mechanism
- Headrest
- Armrests (Left and Right)
- Gas Lift Cylinder
- Five-Star Base
- Casters (5 pieces)
- Hardware Pack (screws, washers, Allen wrench)

3. Assembly Instructions

Follow these steps to assemble your COLAMY Ergonomic Mesh Office Chair.

1. **Attach Casters to Base:** Insert each of the five casters into the holes at the end of each leg of the five-star base. Push firmly until they click into place.
2. **Insert Gas Lift:** Place the gas lift cylinder into the center hole of the five-star base.
3. **Attach Armrests to Seat:** Secure the left and right armrests to the underside of the seat cushion using the provided screws. Ensure the armrests are oriented correctly.
4. **Attach Backrest to Seat:** Align the backrest with the seat mechanism and secure it using the designated screws.
5. **Attach Headrest:** Slide the headrest into the top of the backrest until it locks into position.
6. **Connect Seat to Gas Lift:** Carefully place the assembled seat and backrest onto the gas lift cylinder, ensuring the center hole of the seat mechanism aligns with the top of the gas lift. Press down firmly.



Image: Front view of the fully assembled COLAMY Ergonomic Mesh Office Chair, showcasing its high back, headrest, armrests, and seat.

4. Operating Instructions and Adjustments

Your COLAMY office chair offers multiple adjustments for personalized comfort.

- **Seat Height Adjustment:** Pull the lever located under the right side of the seat upwards to raise or lower the seat. Release the lever at the desired height.
- **Tilt Lock and Recline:** Pull the same lever outwards to unlock the tilt function, allowing the chair to recline between 100° and 130°. Push the lever inwards to lock the chair in an upright position.
- **Tilt Tension Adjustment:** Rotate the round knob located under the front-center of the seat to adjust the tension of the recline. Turn clockwise to increase tension (harder to recline) and counter-clockwise to decrease tension (easier to recline).
- **3D Armrest Adjustment:** The armrests can be adjusted in three dimensions: height, forward/backward, and pivot. Use the buttons or levers on the armrests to make these adjustments.
- **Adjustable Headrest:** The headrest can be moved up and down and tilted to support your neck and head.
- **Dynamic Lumbar Support:** The chair features a dynamic lumbar support system that automatically adjusts to your sitting posture and weight, providing continuous lower back support.
- **Retractable Footrest:** Pull the footrest out from under the seat when desired, and push it back in when not in use.

Multi-Adjustable Ergonomic Office Chair



Enlarged and Widened
Adjustable Headrest (16" * 7")




Patented Breadloaf-style
3D Armrest



Seat Height Adjustment

Image: Detailed view illustrating the adjustable headrest, patented 3D armrest, and seat height adjustment mechanisms of the chair.


Multi-Adjustable Ergonomic Office Chair



100°-130°
Tilt Lock Function



Tilt Tension Adjustment



Hidden Retractable Footrest

Image: Detailed view illustrating the 100°-130° tilt lock function, tilt tension adjustment knob, and the hidden retractable footrest.



Image: Close-up view of the chair's backrest, highlighting the ergonomic dynamic lumbar support system designed to relieve pressure and guard spine health.

Your browser does not support the video tag.

Video: Demonstrates the various ergonomic adjustments of the COLAMY mesh chair, including seat height, tilt, armrests, and footrest, showcasing its functionality for different user needs.

5. Maintenance

Proper care will extend the life of your office chair.

- **Cleaning:** Wipe clean with a damp cloth. For mesh areas, use a mild soap solution and a soft brush, then wipe with a clean, damp cloth. Avoid harsh chemicals.
- **Inspection:** Periodically check all screws and bolts to ensure they are tight. Re-tighten as necessary.
- **Casters:** Keep casters free of hair and debris to ensure smooth rolling.
- **Gas Lift:** Do not attempt to disassemble the gas lift cylinder.



Image: Close-up view of the imported, high-elasticity mesh material, highlighting its breathable and skin-friendly properties.

6. Troubleshooting

Refer to this section for common issues and their solutions.

Problem	Possible Cause	Solution
Chair does not adjust height	Gas lift cylinder malfunction or lever not engaged.	Ensure the height adjustment lever is fully pulled up. If issue persists, the gas lift may need replacement.
Chair wobbles or feels unstable	Loose screws or improper assembly.	Check and tighten all assembly screws, especially those connecting the seat to the mechanism and the backrest. Ensure the gas lift is fully seated in the base.
Casters do not roll smoothly	Debris caught in casters.	Remove any hair, dust, or debris from the caster wheels.
Backrest does not recline or lock	Tilt lock lever not engaged or tilt tension too high.	Ensure the tilt lock lever is pulled outwards to allow recline. Adjust the tilt tension knob counter-clockwise to reduce tension.

7. Specifications

Key specifications for the COLAMY Ergonomic Mesh Office Chair, Model 5188-New-BK.

Product Dimensions



Image: Diagram illustrating the precise dimensions of the COLAMY Ergonomic Mesh Office Chair, including height, width, depth, and weight capacity.

- **Model Name:** 5188-New-BK
- **Material:** Mesh (Imported high elasticity)
- **Frame Material:** Metal
- **Product Dimensions (D x W x H):** 28.15" x 28.15" x 48.62"
- **Item Weight:** 49 pounds
- **Maximum Weight Recommendation:** 300 pounds
- **Back Style:** High Mesh Back
- **Arm Style:** Adjustable 3D Armrests
- **Reclining Position Count:** 1 (100°-130° tilt lock)
- **Additional Features:** Adjustable Headrest, Adjustable Height, Dynamic Lumbar Support, Retractable Footrest
- **Certifications:** SGS Class 4 Gas Cylinder, BIFIMA certified

8. Warranty and Support

COLAMY stands behind the quality of its products. For warranty information, technical support, or to order replacement parts, please contact COLAMY customer service through the retailer where the product was purchased or visit the official COLAMY website.

Please have your model number (5188-New-BK) and purchase date available when contacting support.

© 2026 COLAMY. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question