PUPKIDS non

PUPKIDS Dog Training Collar with Remote

User Instruction Manual

1. Introduction

The PUPKIDS Dog Training Collar is designed to assist in effective and humane dog training. Utilizing advanced Micro Pulse Technology, it delivers gentle, short-duration electrical pulses, ensuring the safety and comfort of your pet. This system helps reinforce basic commands and correct undesirable behaviors, promoting a better relationship between you and your dog.
This manual provides comprehensive instructions for the proper setup, operation, and maintenance of your new training collar system.

2. Important Safety Information

- **Not for Small Dogs:** This collar is designed for medium to large dogs weighing 20-140 lbs with neck sizes of 12-25 inches. It is not suitable for small dogs.
- **Age Recommendation:** Suitable for dogs over 6 months old.
- **Proper Fit:** Ensure the collar fits snugly but comfortably. Improper fit can lead to skin irritation or ineffective training.
- **Supervised Use:** Always supervise your dog when using the training collar.
- **Avoid Prolonged Use:** Do not leave the collar on your dog for more than 12 hours per day to prevent pressure necrosis.
- **Remote is NOT Waterproof:** While the collar receiver is IPX7 waterproof, the remote control is not. Avoid exposing the remote to water.
- **Regular Inspection:** Regularly check your dog's neck for any signs of irritation or rash. If irritation occurs, discontinue use and consult a veterinarian.

3. Package Contents

Your PUPKIDS Dog Training Collar package includes the following items:

- 1 x Remote Control
- 1 x Collar Receiver (Blue)
- 1 x Adjustable Collar Strap
- 1 x USB Charging Cable
- 1 x User Manual (this document)



Image: The PUPKIDS remote control and collar receiver, along with two additional contact points. The remote is dark blue with orange and black buttons, and the collar is a matching dark blue.

4. Product Overview

4.1. Remote Control Features

- **Display Screen:** Shows battery level, mode, and intensity levels.
- **Static Button:** Activates static correction (0-100 HI levels).
- **Vibrate Button:** Activates vibration (1-8 levels).
- **Tone Button:** Activates audible tone (1-8 levels).
- **Lock/Unlock Switch:** Prevents accidental button presses.
- **Light Button:** Activates night-light modes on the receiver.
- **Channel Switch:** Allows control of up to two collars simultaneously.
- **Intensity Adjustment Knob:** Rotates to adjust static, vibrate, and tone levels.
- **Range:** Up to 4200 feet (1400 yards) in unobstructed space.

4.2. Collar Receiver Features

- **Micro Pulse Technology:** Delivers gentle and effective stimulation.
- **Four Contact Points:** Ensures even energy distribution for gentler training.
- **Magnetic Switch:** Innovative magnetic dot for turning the collar on/off.
- **Night-Lights:** Three safety anti-lost night-light modes (seven-color breathing, colorful streamer, high-bright).
- **IPX7 Waterproof:** Fully waterproof for use in all weather conditions, including swimming.
- **Rechargeable Battery:** Long-lasting battery life.

5. Setup Guide

5.1. Charging the Devices

Both the remote control and the collar receiver are rechargeable via USB-C.

1. Connect the USB charging cable to the charging port on both the remote and the receiver.
2. Plug the other end of the cable into a standard USB power adapter (not included).
3. Allow approximately 2 hours for a full charge. The battery indicator on the remote will show charging status, and the receiver will indicate charging completion.



Image: Illustration showing the USB-C charging ports on both the remote and the collar receiver, highlighting their quick charging capability and long battery life (15 days work time for collar, 30 days for remote).

5.2. Turning On/Off and Pairing

1. **Turning on the Collar Receiver:** The collar uses an innovative magnetic switch. Touch the magnetic dot on the back of the remote to the red dot on the collar receiver to turn it on. The collar will blink to indicate it's on.
2. **Turning on the Remote Control:** Slide the lock/unlock switch on the side of the remote to the unlock position. The screen will illuminate.
3. **Pairing:** The collar and remote are pre-paired from the factory. If re-pairing is needed, refer to the detailed instructions in the full user manual.



Image: Diagram illustrating the magnetic dot on the remote and the corresponding red dot on the collar receiver for turning the collar on and off.

5.3. Fitting the Collar

Proper fit is essential for effective and safe use.

1. Place the collar around your dog's neck, ensuring the contact points touch the skin.
2. Adjust the strap so that you can fit two fingers snugly between the collar and your dog's neck.
3. The collar is adjustable for neck sizes 12-25 inches. Excess strap can be cut off for a custom fit.




Image: Visual guide showing the adjustable collar for dogs weighing 20-140 lbs, with a neck size range of 12-25 inches. It explicitly states "Not Suitable for Small Dogs" (under 20 lbs).

6. Operating Instructions

The PUPKIDS training collar offers four humane training modes to suit various training needs.



Image: Infographic detailing the four effective and powerful modes: Night-Light (3 modes), Static (0-100 HI levels), Vibrate (1-8 levels), and Tone (1-8 levels).

6.1. Training Modes

- **Tone Mode (1-8 Levels):** Press the Tone button on the remote to emit an audible sound. Use the adjustment knob to select the desired tone level. This mode is ideal for calling your dog back or as a warning signal.
- **Vibrate Mode (1-8 Levels):** Press the Vibrate button to activate vibration on the collar. Adjust the intensity using the knob. This mode provides a gentle physical cue for your dog.
- **Static Mode (0-100 HI Levels):** Press the Static button to deliver a static correction. Use the adjustment knob to set the intensity from 0 to 100 HI levels. Start with the lowest effective level and increase gradually if needed. This mode is for correcting unwanted behaviors.



Image: Illustration showing how to adjust training levels using the knob on the remote control, with a safety lock feature to prevent accidental changes.

6.2. Night-Light Modes

The collar receiver features three night-light modes for enhanced visibility and locating your dog in low-light conditions:

- **Seven-color Breathing Lights:** A gentle, cycling light display.
- **Colorful Streamer Lights:** A dynamic, flowing light pattern.
- **High-bright Lights:** A steady, bright light for maximum visibility.

Press the Light button on the side of the remote to cycle through these modes and turn the light on/off.




Image: Visual representation of the three colorful and safe night-light modes (seven-color breathing lights, colorful streamer lights, high-bright lights) helping to quickly locate a pet in the dark.

6.3. Multi-Dog Training (2 Channels)

The remote control supports training up to two dogs simultaneously.

- Ensure you have two collar receivers paired to your remote.
- Use the channel switch on the remote to select which dog's collar you wish to control, or to control both at once.



Image: Illustration showing the remote control being used to train two dogs simultaneously, indicating the 2-channel capability.

7. Maintenance

- **Cleaning:** Wipe the collar and remote with a damp cloth. Do not use harsh chemicals.
- **Storage:** Store the device in a cool, dry place when not in use.
- **Battery Care:** Charge the battery regularly, even if not in frequent use, to maintain battery health.
- **Water Resistance:** The collar receiver is IPX7 waterproof, meaning it can withstand submersion up to 1 meter for 30 minutes. The remote is NOT waterproof.



Image: A golden retriever running through water, illustrating the 100% IPX7 waterproof feature of the dog collar receiver. Text clarifies that the remote is not waterproof.

8. Troubleshooting

Problem	Possible Solution
Collar not responding to remote.	Ensure both devices are fully charged. Check if the remote is unlocked. Verify the collar is turned on (magnetic switch). Re-pair the collar and remote if necessary (refer to full manual for pairing steps). Ensure you are within the 4200ft operating range.

Problem	Possible Solution
No static correction.	Increase the static intensity level using the adjustment knob. Ensure the contact points are making proper contact with your dog's skin. Trim your dog's fur if it is too thick and preventing contact.
Collar light not working.	Ensure the collar is turned on. Press the Light button on the remote to activate or cycle through modes.

9. Specifications

Feature	Detail
Brand	PUPKIDS
Model Name	non
Color	Blue
Training Modes	Tone (1-8 levels), Vibrate (1-8 levels), Static (0-100 HI levels), Night-Light (3 modes)
Remote Range	Up to 4200 FT (1400 Yards)
Channels	2 (trains 2 dogs simultaneously)
Collar Waterproof Rating	IPX7 (100% Waterproof)
Remote Waterproof Rating	Not Waterproof
Charging Time	Approx. 2 hours
Collar Battery Life (Work Time)	Up to 15 days
Remote Battery Life (Work Time)	Up to 30 days
Collar Adjustable Size	12-25 inches
Recommended Dog Weight	20-140 lbs (Medium to Large Dogs)
Item Weight	13.7 ounces
Package Dimensions	7.8 x 6.42 x 2.13 inches



Image: Illustration demonstrating the remote control's range of up to 4200 feet (1400 yards) in an open, unobstructed environment.

10. Warranty & Support

PUPKIDS is committed to providing high-quality products and excellent customer service. Your training collar comes with a **12-month warranty** and a **Lifetime Guarantee**.
If you encounter any issues with your product, or have questions regarding its use, please do not hesitate to contact our customer support team. We are available 24 hours a day, 7 days a week.
Customer Support Email: support@pupkids.net
We value your experience and are dedicated to ensuring your satisfaction and the well-being of your pet.

© 2025 PUPKIDS. All rights reserved.